

<https://wiki.teltonika-gps.com/view/Talk:Routing>

## Talk:Routing

Trying to setup a IPsec tunnel. VPN settings all ok but can't see any "VPN instances" in routing, interface as per Wiki. Do I need to enable something else?

G3YGL