

Template:FM36 GSM Parameters

GPRS

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
1240	S8	1	0	1	0 - GPRS is not allowed 1 - GPRS is allowed	GPRS content activation
1242	S8[32]	""	Empty	32 char string	string	APN Name
1243	S8[30]	""	Empty	30 char string	string	APN username
1244	S8[30]	""	Empty	30 char string	string	APN Password
1245	S8[16]	""	Empty	31 char string	string	Domain
1246	S8[16]	0	Empty	65535	number	Target Server Port
1247	U8	0	0	1	0 - TCP 1 - UDP	Protocol
1248	U8	0	0	1	0 - work with all networks 1 - work with 2G network 2 - work with 3G network 3 - work with 4G network	Network Type

SMS

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
ID	Uint8	default	min	max	0 - value = 0 1 - value = 1	Name
ID	Uint8	default	min	max	Value	Name
1252	S8[5]	""	Empty	5 char string	string	SMS Login
1253	S8[5]	""	Empty	5 char string	string	SMS Password
1254	U8	0	-720	+840	minutes	SMS Time Zone
1250	U8	0	0	1	0 - SMS use is not allowed 1 - SMS use is allowed	SMS data sending settings
1273		For detail info				SMS Data send week time schedule
1260-1269	S8[17]	""	0 digit	16 digit	string	Authorized phone numbers
5000-5009	S8[17]	""	0 digit	16 digit	string	SMS Event PreDefined Numbers

Operator list

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
1271		For detailed info				Operator list