

Template:FM36 PC Connection

PC Connection (Windows)

1. Power-up [FM36YX](#) with **DC voltage (10 - 30 V)** power supply using **supplied power cable**. LED's should start blinking, see "[LED behaviour description](#)".
2. Connect device to computer using **Micro-USB cable**:
 - You will need to install USB drivers, see "[How to install USB drivers \(Windows\)](#)"
3. You are now ready to use the device on your computer.