

# Template:FM36 System Parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>1000</b>	U8	0	0	2	0 - Disabled 1 - GPS Sleep 2 - Deep Sleep	Sleep Settings
<b>200</b>	U8	1	1	3000	-	Sleep Timeout
<b>1001</b>	U8	0	0	1	0 - 10V 1 - 30V	Analog Input value range
<b>1002</b>	U8	1	0	3	0 - ignition 1 - Msensor 2 - GPS 3 - ignition + Msensor	Stop Detection Source
<b>1003</b>	U8	0	0	1	0 - Disabled 1 - Enabled	Static Navigation
<b>1004</b>		0	0	2	0 - Power voltage 1 - Digital input 1 2 - Msensor	Ignition Source
<b>1005</b>		30000 mV	13000 mV	30000 mV		High Voltage Level
<b>1006</b>		13000 mV	0	30000 mV		Low Voltage Level
<b>1008</b>		0	0	1	0 - Manual 1 - Automatic	Ignition Detection
<b>1009</b>	U8	10	0	65535		Ignition Detection Timeout
<b>1007</b>	U8	60	0	65535		GNSS FIX Timeout for Time Synchronization via NTP
<b>201</b>	U8	0	0	1	0 - Disabled 1 - Enabled	Saving/Sending without time synchronization
<b>202</b>	U8	0	0	2	0 - GNSS (all available) 1 - GPS 2 - GLONASS	Satellite System