

Template:FM36 first start config

How to install FM3612 drivers (Windows)

1. Please download COM port drivers from [here](#).
2. Extract and run **VCPDriver_V1.3.1_Setup.exe**. This driver is used to detect FM3612 device when it is connected to the computer.
3. Click **Next** in driver installation window.
4. In the following window click **Install** button.
5. Setup will continue installing the driver and eventually the confirmation window will appear. Click **Finish** to complete the setup. You are now ready to use the device on your computer.