

# Template:FMC640 manual supported frequency bands table

Product code	Region (operator)	Module name	Supported bands
FMC640 <b>UX****</b>	Latin America/Australia & New Zealand market	• Quectel EG91-AUX	<ul style="list-style-type: none"><li>• <b>4G (LTE-FDD)</b>: B1 (2100 MHz), B2 (1900 MHz), B3 (1800 MHz), B4 (1700 MHz), B5 (850 MHz), B7 (2600 MHz), B8 (900 MHz), B28 (700 MHz), B66 (1700/2100 MHz)</li><li>• <b>3G</b>: B1 (2100 MHz), B2 (1900 MHz), B5 (850 MHz), B8 (900 MHz)</li><li>• <b>2G</b>: B2 (1900 MHz), B3 (1800 MHz), B5 (850 MHz), B8 (900 MHz)</li></ul>
FMC640 <b>25****</b>	EMEA market	• Quectel EG91-EX	<ul style="list-style-type: none"><li>• <b>4G (LTE-FDD)</b>: B1 (2100 MHz), B3 (1800 MHz), B7 (2600 MHz), B8 (900 MHz), B20 (800 MHz), B28 (700 MHz)</li><li>• <b>3G</b>: B1 (2100 MHz), B8 (900 MHz)</li><li>• <b>2G</b>: B3 (1800 MHz), B8 (900 MHz)</li></ul>