## Template:FMM640 Open Link Timeout

## **Open Link Timeout**

Used to set timeout of link between FMM640 and AVL application termination. If FMM640 has already sent all records it waits for new records before closing link (except Deep Sleep mode, more information in Deep Sleep mode chapter). If new records are generated in the period of this timeout, and minimum count of timer to send is reached, they are sent to AVL application. This option is useful when GSM operator charge money for link activation.