

# Template:FMM640 Operands

□

## Contents

- [1 Operands](#)
  - [1.1 Operand On Exit](#)
  - [1.2 Operand On Entrance](#)
  - [1.3 Operand On Both](#)
  - [1.4 Operand Monitoring](#)
  - [1.5 Operand On Hysteresis](#)
  - [1.6 Operand On Change](#)
  - [1.7 Operand On Delta Change](#)

## Operands

### Operand On Exit

Record is generated when input value leaves a range between low and high level limits.



### Operand On Entrance

---

Record is generated when input value enters a range between low and high level limits.



### Operand On Both

---

Record is generated by both On Exit and On Entrance operands' logic at same time.



### Operand Monitoring

---


No event at all. Values are recorded only when other triggers worked.



## Operand On Hysteresis

---

Record is generated when input value crosses the high limit value from below the low limit value or vice versa.



## Operand On Change

---

Record is generated when input value changes.



## Operand On Delta Change

---

Record is generated when input value changes and the absolute change becomes equal to or higher than the limit value.

