

## FM36 getinfo

| Response details | Description                                                                                            |
|------------------|--------------------------------------------------------------------------------------------------------|
| <b>INI</b>       | Device Initialization Time                                                                             |
| <b>RTC</b>       | RTC Time                                                                                               |
| <b>RST</b>       | Restart Counter                                                                                        |
| <b>ERR</b>       | Error Counter                                                                                          |
| <b>SR</b>        | Number of Sent Records                                                                                 |
| <b>BR</b>        | Number of broken records                                                                               |
| <b>CF</b>        | Profile CRC Fail counter                                                                               |
| <b>FG</b>        | Failed GPRS counter                                                                                    |
| <b>FL</b>        | Failed link counter                                                                                    |
| <b>UT</b>        | UPD Timeout counter                                                                                    |
| <b>SMS</b>       | Sent SMS Counter                                                                                       |
| <b>NOGPS</b>     | No GPS Timer                                                                                           |
| <b>GPS</b>       | GPS receiver state. 0 - OFF, 1 - restarting, 2 - ON but no fix, 3 - ON and operational, 4 - sleep mode |
| <b>SAT</b>       | Average satellites                                                                                     |

|           |                                                                                                                                                                    |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>RS</b> | Reset Source Identification<br>1 - Low Power,<br>2 - Watchdog,<br>3 - I Watchdog,<br>4 - Software reset,<br>5 - Power On,<br>6 - Pin Reset                         |
| <b>MD</b> | Data Mode state. 0 - Home and Stop,<br>1 - Home and Moving,<br>2 - Roaming and Stop,<br>3 - Roaming and Moving,<br>4 - Unknown and Stop,<br>5 - Unknown and Moving |
| <b>RF</b> | Records Found - number of records in the memory.                                                                                                                   |

Example: INI:2013/10/11 8:44 RTC:2013/10/11 8:59 RST:1 ERR:0 SR:0 BR:0 CF:0 FG:0 FL:0 UT:0  
[SMS:1](#) NOGPS:0:14 GPS:2 SAT:0 RS:3 MD:4 RF:0