


# FM36 setparam 1271

Up to 20 operator codes may be configured in 1 SMS.

- Example: Setparam 1271 16 24602,24603,24605, here 16<sup>th</sup>, 17<sup>th</sup> and 18<sup>th</sup> operator codes are set.

 Note! Other operator codes are left unchanged in the configuration.