FMA110 Accessories

<u>Main Page</u> > <u>EOL Products</u> > <u>FMA110</u> > <u>FMA110 Manual</u> > **FMA110 Accessories**

Please order accessories separately as they are not included into device package.


Accessory and its description

Accessory connection schematic

Fuel tank sensors

A fuel tank level sensor which indicates the approximate fuel level on the driver's indicator panel exists in most cars. If the sensor returns analogue signal proportional to fuel level it can be connected to FMA110 Analog input. After connection to the tank fuel level sensor a calibration is needed because most fuel tank sensors are not linear. Calibration is performed by measuring voltage values resulting from the volume of fuel in tank.

Fuel sensor connection to FMA110



Alarm buttons, door sensors etc.

Alarm buttons, door sensors, ignition, etc. have two output states: high or low. FMA110 Digital inputs are used to detect these states.

Relays

In cases when sensor output signal is negative, an additional relay has to be installed to convert negative signal to positive.

Immobilizer relay

Panic button connection to FMA110


×

Inverting relay connection to FMA110

×

Immobilizer relay connection to FMA110 output

When connected as shown on the right hand side, FMA110 disables engine starter when output is ON.



Automotive relay

An ordinary automotive relay is used to invert input signal or to immobilize engine starter. Note that relays can be 12 V or 24 V capable.




1-Wire devices

One of the implemented features on FMA110 is 1-Wire® data protocol, which enables connection to devices such as thermometer (DS1820, DS18S20 and DS18B20) and I-Button types: DS1990, DS1991, DS1994, DS1993, DS1992, DS1982, DS1995, DS1985, DS1996, DS1986, DS1971, DS1963L, DS1921, DS1973, DS1904, DS1972, DS1977, DS2413, DS1922/1923, DS1990A, DS1982U, DS1985U, DS1986U.

Automotive relay pinout



Digital thermometer DS1820 and TTJ100 connection to FMA110



TTJ sensor pinout



I-Button DS1990A connection to FMA110

