

FMB240 Teltonika Data Sending Parameters ID

[Main Page](#) > [CAN Trackers & Adapters](#) > [FMB240](#) > **FMB240 Teltonika Data Sending Parameters ID**

Document updated according firmware FMB.Ver.03.29.00 and newer.

FMB AVL ID's consist of these **parameters groups**:

□

Contents

- [1 Permanent I/O elements](#)
- [2 Eventual I/O elements](#)
- [3 OBD elements](#)
- [4 OBD OEM elements](#)
- [5 BLE Sensors I/O elements](#)
- [6 CAN adapters elements](#)

Permanent I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
239	Ignition	1	Unsigned	0	1	-	-	0 - Ignition Off 1 - Ignition On	FMBXXX	Permanent I/O Elements
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMB130	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
									FMU125	
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

240	Movement	1	Unsigned	0	1	-	-	0 - Movement Off 1 - Movement On	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements
80	Data Mode	1	Unsigned	0	5	-	-	0 - Home On Stop 1 - Home On Moving 2 - Roaming On Stop 3 - Roaming On Moving 4 - Unknown On Stop 5 - Unknown On Moving	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O Elements

										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
21	GSM Signal	1	Unsigned	0	5	-	-	Value in range 1-5		Permanent I/O Elements	
200	Sleep Mode	1	Unsigned	0	4	-	-	0 - No Sleep 1 - GPS Sleep 2 - Deep Sleep 3 - Online Sleep 4 - Ultra Sleep		Permanent I/O Elements	

									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
69	GNSS Status	1	Unsign ed	0	3	-	-	0 - GNSS OFF 1 - GNSS ON with fix 2 - GNSS ON without fix 3 - GNSS sleep	0	Permanent I/O Elements
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	
									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
181	GNSS PDOP	2	Unsign ed	0	500	0.1		Coefficient, calculation formula	FMB900	Permanent I/O Elements
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

182	GNSS HDOP	2	Unsigned	0	500	0.1	Coefficient, calculation formula	FMBXXX	Permanent I/O Elements
								FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
66	External Voltage	2	Unsigned	0	65535	0.001	V Voltage	FMBXXX	Permanent I/O elements
								FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

										FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
68	Battery Current	2	Unsigned	0	65535	0.001	A	Current		Permanent I/O elements	
241	Active GSM Operator	4	Unsigned	0	42949 67295	-	-	Currently used GSM Operator code		Permanent I/O elements	

									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
199	Trip Odometer	4	Unsigned	0	2147483647	-	m	Trip Odometer value	0	Permanent I/O elements
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	
									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	Permanent I/O elements
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	
16	Total Odometer	4	Unsigned	0	2147483647	-	-	Total Odometer value in meters		

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	
1	Digital Input 1	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	

ID	Name	Size	Unit	Address	Value	Scale	Min	Max
12	Fuel Used GPS	4	Unsigned	0	4294967295	0.001	1	Fuel Used
13	Fuel Rate GPS	2	Unsigned	0	32767	0.01	1/100km	Average Fuel Use

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

[illegible]

										FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 FMBXXX FMB900 FMB910 FMB920 FMC920 FMM92 0 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0 FMB140	
10	SD Status	1	Unsigned	0	1	-	-	0 - not present 1 - present		Permanent I/O elements	
2	Digital Input 2	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
3	Digital Input 3	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
6	Analog Input 2	2	Unsigned	0	65535	0.001	V	Voltage		Permanent I/O elements	

								Degrees (°C), -55 - +115, if 850 – Sensor not ready if 2000 – Value read error if 3000 – Not connected if 4000 – ID failed if 5000 – same as 850	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	
75	Dallas Temperature 4	4	Signed	-550	1150	0.1	°C		FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
76	Dallas Temperature ID 1	8	Unsign ed	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
77	Dallas Temperature ID 2	8	Unsign ed	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements
79	Dallas Temperature ID 3	8	Unsign ed	0	0xffffffff ffffffff	-	-	Dallas sensor ID	FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU130 FMC130 FMM13 0 FMB202 FMB204 FMB206	Permanent I/O elements

[illegible]

212	LLS 4 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
213	LLS 4 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
214	LLS 5 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
215	LLS 5 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
15	Eco Score	2	Unsigned	0	65535	0.01	-	Average amount of events on some distance	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150	Permanent I/O elements
113	Battery Level	1	Unsigned	0	100	-	%	Battery capacity level	FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMB800 FMM800	Permanent I/O elements

								FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB202 FMB204 FMB206 FMT100 FMP100 FMC001 FMC125 FMC130 FMM00 1 FMM12 5 FMM13 0 FMC800 FMM80 0 FMM80 A FMC880 FMM88 0	
238	User ID	8	Unsigned	0	0xffffffff	-	-	MAC address of NMEA receiver device connected via Bluetooth	Permanent I/O elements
								FMBXXX FM3001 FMU125 FMU126 FMU130 FMC125 FMC130 FMC150 FMM12 5 FMM13 0 FMM15 0 FMC001 FMM00 1 FMC800 FMM80 0 FMC880 FMM88 0	
237	Network Type	1	Unsigned	0	1	-	-	0 - 3G 1 - GSM 2 - 4G 3 - LTE CAT M1 4 - LTE CAT NB1 99 - Unknown	Permanent I/O elements
								FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0	
4	Pulse Counter Din1	4	Unsigned	0	4294967295	-	-	Counts pulses, count is reset when records are saved	Permanent I/O elements
								FMBXXX FMB110 FMB120 FMB122 FMB125 FMU130 FMC130 FMM13 0	
5	Pulse Counter Din2	4	Unsigned	0	4294967295	-	-	Counts pulses, count is reset when records are saved	Permanent I/O elements
								FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0	

263	BT Status	1	Unsigned	0	4	-	-	0 - BT is disabled 1 - BT Enabled, not device connected 2 - Device connected, BTv3 Only 3 - Device connected, BLE only 4 - Device connected, BLE + BT	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 0 FMB140 FMB150 FMC150 FMM150 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 0 FMM80A FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 5 FMB130 FMU130 FMC130 FMM130 0 FMB140 FMB150 FMC150 FMM150 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	Permanent I/O elements
264	Barcode ID	Variable	ASCII	0	32	-	-	Barcode ID	FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 5 FMB130 FMU130 FMC130 FMM130 0 FMB140 FMB150 FMC150 FMM150 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMBXXX FMB130 FMU130 FMC130 FMC150 FMM13 0 FMB130 FMU130 FMC130 FMM13 0 FMB140	
303	Instant Movement	1	Unsigned	0	1	-	-	Logic: 0/1 returns movement value		Permanent I/O elements	
327	UL202-02 Sensor Fuel level	2	Signed	-150	32767	0.1	mm	UL202-02 Sensor Fuel level		Permanent I/O elements	
483	UL202-02 Sensor Status	1	Unsigned	0	255	-	-	UL202-02 sensor status codes		Permanent I/O elements	
380	Digital output 3	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
381	Ground Sense	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	

[illegible]

329	AIN Speed	2	Unsigned	0	65535	-	-		MSP500	Permanent I/O elements
500	MSP500 vendor name	40	ASCII	0	40	-	-	Name of the integrator who installed the device	MSP500	Permanent I/O elements
501	MSP500 vehicle number	40	ASCII	0	40	-	-	Vehicle number on which the device is installed	MSP500	Permanent I/O elements
502	MSP500 speed sensor	1	unsigned	0	1	-	-	Status of the speed sensor	MSP500	Permanent I/O elements
637	Wake Reason	1	Unsigned	0	1	-	-	True if device was woken by RTC alarm	FMB965	Permanent I/O elements
									FMBXXX	
									[Expand]	
									FMB001	
									FMB010	
									FMB100	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMB130	
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FM3010	
									FMB202	
									FMB204	
									FMB206	
									FMB207	
									FMT100	
									MTB100	
10800	EYE Temperature 1	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 1	TMT250	Permanent I/O elements
									GH5200	
									FMB140	
									FMB020	
									FMB002	
									FMB003	
									FMU120	
									FMU122	
									FMU125	
									FMU126	
									FMU130	
									FMC120	
									FMC122	
									FMC125	
									FMC130	
									FMM12	
									5	
									FMM13	
									0	
									FMC001	
									FMM00	
									1	
									TFT100	
									FMB910	

FMB910

FMB910

FMB910

10803	EYE Temperature 4	2	Signed -32768 32767	0.01	°C	Temperature measured by EYE Sensor 4
-------	-------------------	---	---------------------	------	----	--------------------------------------

10808	EYE Magnet 1	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10809	EYE Magnet 2	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 2	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10810	EYE Magnet 3	1	Unsigned	0	1	-	-	Magnet measured by EYE Sensor by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------	---	----------	---	---	---	---	---	--	------------------------

10812	EYE Movement 1	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10814	EYE Movement 3	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10815	EYE Movement 4	2	Unsigned	0	0xFFFF	-	-	Movement state measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	----------------	---	----------	---	--------	---	---	--	--	------------------------

10836	EYE Movement count 1	2	Unsign ed	0	32767	-	-	Movement count measure by EYE Sensor 1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	-------------------------	---	--------------	---	-------	---	---	--	--	---------------------------

10842	EYE Magnet count 3	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------------	---	----------	---	-------	---	---	--	--	------------------------

10843	EYE Magnet count 4	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 4	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------------	---	----------	---	-------	---	---	--	--	------------------------

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

622	Frequency DIN1	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN1	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 EMP100 EMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Permanent I/O elements
-----	----------------	---	----------	---	-------	-----	----	---	--	------------------------

										FMBXXX	
										[Expand]	
										FMB001	
										FMB010	
										FMB100	
										FMB110	
										FMB120	
										FMB122	
										FMB125	
										FMB130	
										FMB900	
										FMB920	
										FMB962	
										FMB964	
										FM3001	
										FM3010	
										FMB202	
										FMB204	
										FMB206	
										FMB207	
										FMB208	
										FMB209	
										FMT100	
										MTB100	
										TMT250	
										GH5200	
										FMB140	
										FMB020	
										FMB002	
623	Frequency DIN2	2	Unsigned	0	65535	0.1	Hz	Frequency of input signal present on DIN2	Permanent I/O elements	FMB003	
										FMU120	
										FMU122	
										FMU125	
										FMU126	
										FMU130	
										FMC120	
										FMC122	
										FMC125	
										FMC130	
										FMM125	
										FMM130	
										FMC001	
										FMM001	
										TFT100	
										FMB910	
										FMP100	
										FMP1M1	
										MSP500	
										FMC800	
										FMM800	
										FMC880	
										FMM880	
										FMM800	
										A	

Eventual I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	SW Support	Parameter Group
				Min	Max					
155	Guidance zone 01	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding road 3 - over speeding start	FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMB208 FMB209 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMC120 FMC122 FMC125 FMC130 FMM125 FMM130 FMC001 FMM001 TFT100 FMB910 FMP100 FMP1M1 MSP500 FMC800 FMM800 FMC880 FMM880 FMM80A	Eventual I/O elements

[illegible]

98	Confidence score 20	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0001	Eventual IO elements
									24/0001	
									24/0002	
									24/0003	
									24/0004	
									24/0005	
									24/0006	
									24/0007	
									24/0008	
									24/0009	
99	Confidence score 21	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0010	Eventual IO elements
									24/0010	
									24/0011	
									24/0012	
									24/0013	
									24/0014	
									24/0015	
									24/0016	
									24/0017	
									24/0018	
153	Confidence score 22	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0019	Eventual IO elements
									24/0019	
									24/0020	
									24/0021	
									24/0022	
									24/0023	
									24/0024	
									24/0025	
									24/0026	
									24/0027	
154	Confidence score 23	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0028	Eventual IO elements
									24/0028	
									24/0029	
									24/0030	
									24/0031	
									24/0032	
									24/0033	
									24/0034	
									24/0035	
									24/0036	
190	Confidence score 24	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0037	Eventual IO elements
									24/0037	
									24/0038	
									24/0039	
									24/0040	
									24/0041	
									24/0042	
									24/0043	
									24/0044	
									24/0045	
191	Confidence score 25	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0046	Eventual IO elements
									24/0046	
									24/0047	
									24/0048	
									24/0049	
									24/0050	
									24/0051	
									24/0052	
									24/0053	
									24/0054	
192	Confidence score 26	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0055	Eventual IO elements
									24/0055	
									24/0056	
									24/0057	
									24/0058	
									24/0059	
									24/0060	
									24/0061	
									24/0062	
									24/0063	
193	Confidence score 27	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0064	Eventual IO elements
									24/0064	
									24/0065	
									24/0066	
									24/0067	
									24/0068	
									24/0069	
									24/0070	
									24/0071	
									24/0072	
194	Confidence score 28	1	Unassigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over spending end 3 - over spending start	FMHXXN 24/0073	Eventual IO elements
									24/0073	
									24/0074	
									24/0075	
									24/0076	
									24/0077	
									24/0078	
									24/0079	
									24/0080	
									24/0081	

228	Confidence zone 47	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
229	Confidence zone 48	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
230	Confidence zone 49	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
231	Confidence zone 50	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
175	Auto Confidence	1	Unsigned	0	1	-	-	0 - target left zone 1 - target entered zone	Eventual IO elements
210	Trip	1	Unsigned	0	1	-	-	0 - trip stop 1 - trip start From 61.00.24 to version available with ET app new values: 2 - Business Status 3 - Private Status 4.0 - Custom Status	Eventual IO elements
255	Over Speeding	1	Unsigned	0	255	-	km/h	At over speeding start km/h, at over speeding end km/h	Eventual IO elements
217	Crash trace data	Variable	HEX	0	1200	-	-	Crash trace data	Eventual IO elements
285	Blood alcohol content	2	Unsigned	0	9999	-	-	Alcohol content in blood in perfumes and mode. First 14 bits from MSB are perfumes multiplied by 1000 and last to bits are 0 - Passive test, 1 Active test, 2 and 3 are reserved.	Eventual IO elements
211	Idling	1	Unsigned	0	1	-	-	0 - moving 1 - idling	Eventual IO elements

253	Green driving type	1	Unsigned	1	3	-	-	1 - harsh acceleration 2 - harsh braking 3 - harsh cornering	Eventual IO elements
246	Twining	1	Unsigned	0	1	-	-	0 - steady 1 - twining	Eventual IO elements
252	Unplug	1	Unsigned	0	1	-	-	0 - battery present 1 - battery unplugged	Eventual IO elements
247	Crash detection	1	Unsigned	1	6	-	-	1 - real crash detected (device is calibrated) 2 - limited crash threat (device not calibrated) 3 - limited crash threat (device is calibrated) 4 - full crash threat (device not calibrated) 5 - full crash threat (device is calibrated) 6 - real crash detected (device not calibrated)	Eventual IO elements
248	Immobilizer	1	Unsigned	0	2	-	-	0 - (device not connected) 1 - (device connected (tamabilliar) 2 - (device connected (aftermarket wiring)	Eventual IO elements
254	Green Driving Value	1	Unsigned	0	255	acc and braking 0-01	G or red	Depending on green driving type if harsh acceleration or braking - g*100 (value 123 -> 1.23g). If Green driving source is „GPS“ - harsh cornering value is rad/*100. If source is „Accelerometer“ - g*100.	Eventual IO elements
249	Jumping	1	Unsigned	0	1	-	-	0 - jumping stop 1 - jumping start	Eventual IO elements
14	ECU02	8	Unsigned	0	0xFFFFFFFF	-	-	Value of SMI ECU02, LSB	Eventual IO elements
243	Green driving event duration	2	Unsigned	0	65535	-	ms	Duration of event that did generate Green driving	Eventual IO elements
236	Alarm	1	Unsigned	0	1	-	-	0 - Reserved 1 - Alarm event occurred Element stores maximum accelerometer values in mg on all axis during Eco driving event 8 Bytes 28 Datas 28 - X axis 28 - Y axis 28 - Z axis	Eventual IO elements
238	EcoMaximum	8	Unsigned	0	0xFFFFFFFF	-	-	Element stores average accelerometer values in mg on all axis during Eco driving event 8 Bytes 28 Datas 28 - X axis 28 - Y axis 28 - Z axis Duration of Eco driving event in milliseconds	Eventual IO elements
239	EcoAverage	8	Unsigned	0	0xFFFFFFFF	-	-		Eventual IO elements
260	EcoDuration	2	Unsigned	0	65535	-	ms		Eventual IO elements

283	Driving State	1	Unsigned	0	3	-	-	1 - Ignition ON 2 - Driving 3 - Ignition OFF	FMB110	Eventual IO elements
284	Driving Records	2	Unsigned	0	65535	-	-	Number of Records between Ignition ON and Ignition OFF	FMB120	Eventual IO elements
317	Crash event counter	1	Unsigned	0	255	-	-	Contacts trace with specific eventual crash record	FMBXXX 0x0001	Eventual IO elements
									FMB120	
									FMB121	
									FMB122	
									FMB123	
									FMB124	
									FMB125	
									FMB126	
									FMB127	
									FMB128	
									FMB129	
									FMB130	
									FMB131	
									FMB132	
									FMB133	
318	GNSS jamming	1	Unsigned	0	2	-	-	GNSS jamming state: 0 - GPS jamming ended/healthy state 1 - GPS jamming warning state 2 - GPS jamming critical state	FMBXXX 0x0001	Eventual IO elements
									FMB120	
									FMB121	
									FMB122	
									FMB123	
									FMB124	
									FMB125	
									FMB126	
									FMB127	
									FMB128	
									FMB129	
									FMB130	
									FMB131	
									FMB132	
									FMB133	
391	Private mode	1	Unsigned	0	255	-	-	Private mode state: 0 - Private mode off 1 - Private mode on	FMBXXX 0x0001	Eventual IO elements
									FMB120	
									FMB121	
									FMB122	
									FMB123	
									FMB124	
									FMB125	
									FMB126	
									FMB127	
									FMB128	
									FMB129	
									FMB130	
									FMB131	
									FMB132	
									FMB133	
449	Ignition On Counter	4	Unsigned	0	2147483647	-	s	Duration in seconds which is counted while Ignition state is On	FMBXXX 0x0001	Eventual IO elements
									FMB120	
									FMB121	
									FMB122	
									FMB123	
									FMB124	
									FMB125	
									FMB126	
									FMB127	
									FMB128	
									FMB129	
									FMB130	
									FMB131	
									FMB132	
									FMB133	

OBD elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
Min	Max									
256	VIN	17	ASCII	0	0xff	-	-	VIN number	FMBXXX	OBD elements
									FMB001	
									FMC001	
									FMB010	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMC125	
									FMM125	
									FMB130	
									FMU130	
									FMC130	
									FMM130	
									FMB140	
									FMB150	
									FMC150	
									FMM150	
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMT100	
									MTB100	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMB140	

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
30	Number of DTC	1	Unsigned	0	255	-	-	Number of DTC	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
31	Engine Load	1	Unsigned	0	100	-	%	Calculated engine load value	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
32	Coolant Temperature	1	Signed	-128	127	-	°C	Engine coolant temperature	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
33	Short Fuel Trim	1	Signed	-100	99	-	%	Short term fuel trim 1	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
34	Fuel pressure	2	Unsigned	0	765	-	kPa	Fuel pressure	OBD elements	
35	Intake MAP	1	Unsigned	0	255	-	kPa	Intake manifold absolute pressure	OBD elements	
36	Engine RPM	2	Unsigned	0	16384	-	rpm	Engine RPM	OBD elements	
37	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle speed	OBD elements	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
38	Timing Advance	1	Signed	-64	64	-	°	Timing advance		OBD elements	
39	Intake Air Temperature	1	Signed	-128	127	-	°C	Intake air temperature		OBD elements	
40	MAF	2	Unsigned	0	65535	0.01	g/sec	MAF air flow rate		OBD elements	
41	Throttle Position	1	Unsigned	0	100	-	%	Throttle position		OBD elements	

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
42	Runtime since engine start	2	Unsigned	0	65535	-	s	Runtime since engine start	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
43	Distance Traveled MIL On	2	Unsigned	0	65535	-	km	Distance ormattin MIL on	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
44	Relative Fuel Rail Pressure	2	Unsigned	0	5178	0.1	kPa	Relative fuel rail pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
45	Direct Fuel Rail Pressure	2	Unsigned	0	65535	10	kPa	Direct Fuel Rail Pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
46	Commanded EGR	1	Unsigned	0	100	-	%	Commanded EGR		OBD elements	
47	EGR Error	1	Signed	-100	100	-	%	EGR error		OBD elements	
48	Fuel Level	1	Unsigned	0	100	-	%	Fuel level		OBD elements	
49	Distance Since Codes Clear	2	Unsigned	0	65535	-	km	Distance traveled since codes cleared		OBD elements	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
53	Ambient Air Temperature	1	Signed	-128	127	-	°C	Ambient air temperature			
54	Time Run With MIL On	2	Unsigned	0	65535	-	min	Time run with MIL on			
55	Time Since Codes Cleared	2	Unsigned	0	65535	-	min	Time since codes cleared			
56	Absolute Fuel Rail Pressure	2	Unsigned	0	65535	0.1	kPa	Absolute fuel rail pressure			

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
57	Hybrid battery pack life	1	Unsigned	0	100	-	%	Hybrid battery pack remaining life		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
58	Engine Oil Temperature	1	Unsigned	0	215	-	°C	Engine oil temperature		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
59	Fuel injection timing	2	Signed	-21000	30200	0.01	°	Fuel injection timing		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
540	Throttle position group	1	Unsigned	0	100	-	%	Throttle Position Value From PID Group		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC003 FMC00A FMM003 FMM00A	
541	Commanded Equivalence R	1	Unsigned	0	200	0.01	-	Fuel-Air Commanded Equivalence Ratio		FMBXXX FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements
										FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	
542	Intake MAP 2 bytes	2	Unsigned	0	2048	-	kPa	Intake Manifold Absolute Pressure		FMBXXX FMB001 FMB003 FMC003 FMC00A FMM003 FMM00A	OBD elements

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
543	Hybrid System Voltage	2	Unsigned	0	1024	-	V	Hybrid vehicle system voltage		OBD elements
544	Hybrid System Current	2	Signed	-3277	3277	-	A	Hybrid vehicle system current		OBD elements
281	Fault Codes	variable	ASCII	0	128	-	-	Fault Codes (values separated via ",")		OBD elements
60	Fuel Rate	2	Unsigned	0	32767	0.01	L/h	Engine fuel rate, L/h*100		OBD elements

OBD OEM elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
389	OBD OEM Total Mileage	4	Unsigned	0	0xffffffff	-	km	Total mileage received by requesting vehicle specific PID	FMB003	OBD OEM elements
390	OBD OEM Fuel Level	4	Unsigned	0	0xffffffff	0.1	l	Fuel level in litres received by requesting vehicle specific PID	FMB003	OBD OEM elements
402	OEM Distance Until Service	4	Unsigned	0	0xffffffff	-	km	Distance till next service received by requesting vehicle specific PID	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
410	OEM Battery charge state	1	Unsigned	0	1	-	-	0 - Not charging 1 - Charging	FMM003	OBD OEM elements
									FMC003	
									FMM003	
									FMB001	
									FMC001	
411	OEM Battery charge level	1	Unsigned	0	100	-	%	Represents battery charged level	FMM001	OBD OEM elements
									FMB003	
									FMC003	
									FMM003	
									FMB001	
412	OEM Battery power consumption	2	Unsigned	0	65535	-	kWh/100km	Represents battery power consumption	FMC001	OBD OEM elements
									FMM001	
									FMB003	
									FMC003	
									FMM003	
755	OEM Remaining distance	2	Unsigned	0	65535	-	km	Remaining distance until fuel tank empty or battery (EV) depleted	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
1151	OEM Battery State Of Health	2	Unsigned	0	65535	-	%	Battery State of Health	FMM003	OBD OEM elements
									FMC003	
									FMM003	
									FMB001	
									FMC001	
1152	OEM Battery Temperature	2	Signed	-32768	32767	-	°C	Battery pack temperature	FMM001	OBD OEM elements
									FMB003	
									FMC003	
									FMM003	
									FMB001	

BLE Sensors I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					

25	BLE Temperature #1	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

26	BLE Temperature #2	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

27	BLE Temperature #3	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

28	BLE Temperature #4	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

[illegible]

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

[illegible]

[illegible]

336	BLE Luminosity #2	2	Unsigned	0	0xFF FF	-	lx	Luminosity value of BLE sensor	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
-----	-------------------	---	----------	---	------------	---	----	--------------------------------	--	-------------------------

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																															</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

										FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
465	BLE 1 Custom #4	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy		

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

CAN adapters elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	ECU Support	Parameter Group
				Min	Max					
81	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle Speed	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
82	Accelerator Pedal Position	1	Unsigned	0	102	-	%	Value in percentages	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
83	Fuel Consumed	4	Unsigned	0	2147483647	0.1	l	Value in liters	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
84	Fuel Level	2	Unsigned	0	65535	0.1	l	Value in liters	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
85	Engine RPM	2	Unsigned	0	16384	-	rpm	Value in rounds per minute	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
87	Total Mileage	4	Unsigned	0	4294967295	-	m	Value in meters	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
89	Fuel level	1	Unsigned	0	100	-	%	Value in percentages	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
90	Door Status	2	Unsigned	0	16128	-	-	Door status values: Min = 0, Max = 16128 Door status is represented as bitmask converted to decimal value. Possible values: 0 - all doors closed 0x000 (000) - front left door is opened 0x200 (512) - front right door is opened 0x400 (1024) - rear left door is opened 0x800 (2048) - rear right door is opened 0x1000 (4096) - hood is opened 0x2000 (8192) - trunk is opened 0x3F00 (16128) - all doors are opened or combinations of values	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
100	Program Number	4	Unsigned	0	99999	-	-	Value: Min = 0, Max = 99999	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
101	Module ID 8B	8	Unsigned	0	0a7fffffff	-	-	Module ID 8 Bytes	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
108	Module ID 17B	17	HEX	0	0a7fffffff	-	-	Module ID 17 Bytes	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
102	Engine Worktime	4	Unsigned	0	1677215	-	min	Engine work time	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	ALLCAN300, CANCONTROL
103	Engine Worktime (rounded)	4	Unsigned	0	1677215	-	min	Total engine work time	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	ALLCAN300, CANCONTROL
105	Total Mileage (rounded)	4	Unsigned	0	4294967295	-	m	Total Vehicle Mileage	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
107	Fuel Consumed (rounded)	4	Unsigned	0	2147483647	0.1	l	Total Fuel Consumed	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	LUCAN200, ALLCAN300, CANCONTROL
110	Fuel Rate	2	Unsigned	0	32768	0.1	l/h	Fuel rate	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	ALLCAN300
111	AdBlue Level	1	Unsigned	0	100	-	%	AdBlue	FHX3XX Data110 Data111 Data112 Data113 Data114 Data115 Data116 Data117 Data118 Data119	ALLCAN300

133	Tachograph Total Vehicle Distance	4	Unsigned	0	4294967295	-	m	Tacho Total Vehicle Distance	ALLCAN300
134	Trip Distance	4	Unsigned	0	4294967295	-	m	Trip distance	ALLCAN300
135	Tachograph Vehicle Speed	2	Unsigned	0	255	-	km/h	Tacho vehicle speed	ALLCAN300
136	Tacho Driver Card Presence	1	Unsigned	0	3	-	-	Tacho Driver Card Presence	ALLCAN300
137	Driver 1 Status	1	Unsigned	0	255	-	-	Driver 1 Status	ALLCAN300
138	Driver 2 Status	1	Unsigned	0	255	-	-	Driver 2 Status	ALLCAN300
139	Driver 1 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Continuous Driving Time, minutes	ALLCAN300
140	Driver 2 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Continuous Driving Time, minutes	ALLCAN300
141	Driver 1 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Break Time, minutes	ALLCAN300
142	Driver 2 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Break Time, minutes	ALLCAN300
143	Driver 1 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 1 Duration Of Selected Activity, minutes	ALLCAN300
144	Driver 2 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 2 Duration Of Selected Activity, minutes	ALLCAN300
145	Driver 1 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Driving Time, minutes	ALLCAN300
146	Driver 2 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Driving Time, minutes	ALLCAN300
147	Driver 1 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID High	ALLCAN300
148	Driver 1 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID Low	ALLCAN300
149	Driver 2 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID High	ALLCAN300
150	Driver 2 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID Low	ALLCAN300
151	Battery Temperature	2	Signed	-400	1270	0.1	°C	Battery temperature in Celsius	ALLCAN300
152	HV Battery Level	1	Unsigned	0	100	-	%	Battery level in percent	ALLCAN300, CANCONTROL
160	DTC Faults	1	Unsigned	0	255	-	-	DTC Faults Count	ALLCAN300, CANCONTROL
161	Slope of Arm	2	Signed	-3276	3276	-	Degrees °	Slope Of Arm	ALLCAN300
162	Rotation of Arm	2	Signed	-180	180	-	Degrees °	Rotation Of Arm	ALLCAN300
163	Eject of Arm	2	Unsigned	0	6553	-	m	Eject of arm	ALLCAN300

164	Horizontal Distance Arm Vehicle	2	Unassigned	0	6553	-	m	Horizontal Distance Arm Vehicle	ALLCAN300
165	Height Arm Above Ground	2	Unassigned	0	6553	-	m	Height Arm Above Ground	ALLCAN300
166	DoS RPM	2	Unassigned	0	65535	-	rpm	DoS RPM	ALLCAN300
167	Amount Of Spread Salt Square Meter	2	Unassigned	0	655	-	g/m ²	Amount Of Spread Salt Square Meter	ALLCAN300
168	Battery Voltage	2	Unassigned	0	6553	-	V	Battery Voltage	ALLCAN300
169	Amount Of Spread Fine Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Spread Fine Grained Salt	ALLCAN300
170	Amount Of Coarse Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Coarse Grained Salt	ALLCAN300
171	Amount Of Spread DMS	4	Unassigned	0	1677722	-	T	Amount Of Spread DMS	ALLCAN300
172	Amount Of Spread Coarse Grained Calcium	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Coarse Grained Calcium	ALLCAN300
173	Amount Of Spread Calcium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Calcium Chloride	ALLCAN300
174	Amount Of Spread Sodium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Sodium Chloride	ALLCAN300
176	Amount Of Spread Magnesium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Magnesium Chloride	ALLCAN300
177	Amount Of Spread Gravel	4	Unassigned	0	1677722	-	T	Amount Of Spread Gravel	ALLCAN300
178	Amount Of Spread Sand	4	Unassigned	0	1677722	-	T	Amount Of Spread Sand	ALLCAN300
183	Width Pouring Left	2	Unassigned	0	655	-	m	Width Pouring Left	ALLCAN300
184	Width Pouring Right	2	Unassigned	0	655	-	m	Width Pouring Right	ALLCAN300
185	Salt Spreader Working Hours	4	Unassigned	0	167722	-	h	Salt Spreader Working Hours	ALLCAN300
186	Distance During Salting	4	Unassigned	0	167722	-	km	Distance During Salting	ALLCAN300
187	Load Weight	4	Unassigned	0	16772215	-	kg	Load Weight	ALLCAN300
188	Retarder Load	1	Unassigned	0	130	-	%	Retarder Load in percent	ALLCAN300
189	Cruise Time	4	Unassigned	0	16772215	-	min	Cruise time in minutes	ALLCAN300
232	CNG Status	1	Unassigned	0	1	-	-	CNG Status	LUCAN200, CANCONTROL
233	CNG Used	4	Unassigned	0	16772215	-	kg	CNG used	LUCAN200, CANCONTROL

214	CNG Level	1	Unsigned	0	100	-	%	CNG Level	FMI00XX FMI001 FMI002 FMI003 FMI004 FMI005 FMI006 FMI007 FMI008 FMI009 FMI010 FMI011 FMI012 FMI013 FMI014 FMI015 FMI016 FMI017 FMI018 FMI019 FMI020	LVCAN200, CANCONTROL
225	Oil Level	1	Unsigned	0	1	-	-	Engine Oil Level Indicator Status	FMI00XX FMI021 FMI022 FMI023 FMI024 FMI025 FMI026 FMI027 FMI028 FMI029 FMI030	ALLCAN300, CANCONTROL
304	Vehicles Range On Battery	4	Unsigned	0	16771215	-	m	Vehicle Range on Battery	FMI00XX FMI031 FMI032 FMI033 FMI034 FMI035 FMI036 FMI037 FMI038 FMI039 FMI040	ALLCAN300, CANCONTROL
305	Vehicles Range On Additional Fuel	4	Unsigned	0	16771215	-	m	Vehicle Range On Additional Fuel	FMI00XX FMI041 FMI042 FMI043 FMI044 FMI045 FMI046 FMI047 FMI048 FMI049	ALLCAN300, CANCONTROL
325	VIN	17	ASCII	0	0aFF	-	-	VIN number	FMI00XX FMI050 FMI051 FMI052 FMI053 FMI054 FMI055 FMI056 FMI057 FMI058 FMI059 FMI060	CANCONTROL
282	Fault Codes	Variable	-	0	128	-	-	DTC Fault codes	FMI00XX FMI061 FMI062 FMI063 FMI064 FMI065 FMI066 FMI067 FMI068 FMI069	LV-CAN200 + DTC
517	Security State Flags P4	8	HEX	0	0a000000	-	-	Security state flags protocol 4, more information click here Link	FMI00XX FMI070	ALLCAN300
518	Control State Flags P4	8	HEX	0	0a000000	-	-	Control state flags protocol 4, more information click here Link	FMI00XX FMI071	ALLCAN300
519	Indicator State Flags P4	8	HEX	0	0a000000	-	-	Indicator state flags protocol 4, more information click here Link	FMI00XX FMI072	ALLCAN300
520	Agricultural State Flags P4	8	HEX	0	0a000000	-	-	Agricultural state flags protocol 4, more information click here Link	FMI00XX FMI073	ALLCAN300
521	Utility State Flags P4	8	HEX	0	0a000000	-	-	Utility state flags protocol 4, more information click here Link	FMI00XX FMI074	ALLCAN300
522	Custom State Flags P4	8	HEX	0	0a000000	-	-	Custom state flags protocol 4, more information click here Link	FMI00XX FMI075	ALLCAN300
855	LNG Used	4	Unsigned	0	214748364	-	kg	Total LNG used in kilograms	FMI00XX FMI076	ALLCAN300, CANCONTROL
856	LNG Used (converted)	4	Unsigned	0	214748364	-	kg	Total LNG used converted in kg	FMI00XX FMI077	ALLCAN300, CANCONTROL
857	LNG Level	2	Unsigned	0	100	-	%	LNG level in perc	FMI00XX FMI078	ALLCAN300, CANCONTROL
858	LNG Level	2	Unsigned	0	6535	-	kg	LNG level in kg	FMI00XX FMI079	ALLCAN300, CANCONTROL
1100	Total LPG Used	4	Unsigned	0	4296987295	-	l	Total LPG used in liters	FMI00XX FMI080	LVCAN
1101	Total LPG Used Counted	4	Unsigned	0	4296987295	-	l	Total LPG used counted in liters	FMI00XX FMI081	LVCAN
1102	LPG Level Prec	2	Unsigned	0	6535	-	%	LPG level in perc	FMI00XX FMI082	LVCAN
1103	LPG Level Liters	2	Unsigned	0	6535	-	l	LPG level in liters	FMI00XX FMI083	LVCAN
898	SSF Ignition	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI084 FMI085 FMI086 FMI087 FMI088 FMI089 FMI090	LVCAN, ALLCAN300, CANCONTROL
652	SSF KeySignalStatusLock	1	Unsigned	0	1	-	-	0 - No key in lock 1 - Key in lock	FMI00XX FMI091 FMI092 FMI093 FMI094 FMI095 FMI096 FMI097	ALLCAN300, CANCONTROL
899	SSF Windows	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI098 FMI099 FMI100 FMI101 FMI102 FMI103	ALLCAN300
900	SSF Engine Working	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI104 FMI105 FMI106 FMI107 FMI108 FMI109	ALLCAN300, CANCONTROL
901	SSF Standalone Engine	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI110 FMI111 FMI112 FMI113	ALLCAN300
902	SSF Ready To Drive	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI114 FMI115 FMI116 FMI117 FMI118	ALLCAN300, CANCONTROL
903	SSF Engine Working On CNG	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI119 FMI120 FMI121 FMI122	ALLCAN300, CANCONTROL
904	SSF Work Mode	1	Unsigned	0	1	-	-	0 - Private 1 - Company	FMI00XX FMI123 FMI124 FMI125 FMI126	ALLCAN300
905	SSF Operator	1	Unsigned	0	1	-	-	0 - Not present 1 - Present	FMI00XX FMI127 FMI128 FMI129 FMI130	ALLCAN300
906	SSF Interlock	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI131 FMI132 FMI133 FMI134	ALLCAN300
907	SSF Engine Lock Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMI00XX FMI135 FMI136 FMI137 FMI138	CANCONTROL
908	SSF Request To Lock Engine	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI139 FMI140 FMI141 FMI142	CANCONTROL
653	SSF Handbrake Is Active	1	Unsigned	0	1	-	-	0 - Handbrake inactive 1 - Handbrake active	FMI00XX FMI143 FMI144 FMI145 FMI146	ALLCAN300, CANCONTROL
910	SSF Footbrake Is Active	1	Unsigned	0	1	-	-	0 - Footbrake inactive 1 - Footbrake active	FMI00XX FMI147 FMI148 FMI149 FMI150	ALLCAN300, CANCONTROL
911	SSF Clutch Pushed	1	Unsigned	0	1	-	-	0 - Clutch is pushed 1 - Clutch is not pushed	FMI00XX FMI151 FMI152 FMI153 FMI154	ALLCAN300, CANCONTROL
912	SSF Hazard Warning Lights	1	Unsigned	0	1	-	-	0 - Hazard warning lights on 1 - Hazard warning lights off	FMI00XX FMI155 FMI156 FMI157 FMI158	ALLCAN300, CANCONTROL

971	ISF FAP Indicator	1	Unassigned	0	1	-	-	0 - Off 1 - On	PMHXXY Page 10 256-100 256-101 256-102 256-103 256-104 256-105 256-106 256-107 256-108 256-109 256-110 256-111 256-112 256-113 256-114 256-115 256-116 256-117 256-118 256-119 256-120 256-121 256-122 256-123 256-124 256-125 256-126 256-127 256-128 256-129 256-130 256-131 256-132 256-133 256-134 256-135 256-136 256-137 256-138 256-139 256-140 256-141 256-142 256-143 256-144 256-145 256-146 256-147 256-148 256-149 256-150 256-151 256-152 256-153 256-154 256-155 256-156 256-157 256-158 256-159 256-160 256-161 256-162 256-163 256-164 256-165 256-166 256-167 256-168 256-169 256-170 256-171 256-172 256-173 256-174 256-175 256-176 256-177 256-178 256-179 256-180 256-181 256-182 256-183 256-184 256-185 256-186 256-187 256-188 256-189 256-190 256-191 256-192 256-193 256-194 256-195 256-196 256-197 256-198 256-199 256-200 256-201 256-202 256-203 256-204 256-205 256-206 256-207 256-208 256-209 256-210 256-211 256-212 256-213 256-214 256-215 256-216 256-217 256-218 256-219 256-220 256-221 256-222 256-223 256-224 256-225 256-226 256-227 256-228 256-229 256-230 256-231 256-232 256-233 256-234 256-235 256-236 256-237 256-238 256-239 256-240 256-241 256-242 256-243 256-244 256-245 256-246 256-247 256-248 256-249 256-250 256-251 256-252 256-253 256-254 256-255 256-256 256-257 256-258 256-259 256-260 256-261 256-262 256-263 256-264 256-265 256-266 256-267 256-268 256-269 256-270 256-271 256-272 256-273 256-274 256-275 256-276 256-277 256-278 256-279 256-280 256-281 256-282 256-283 256-284 256-285 256-286 256-287 256-288 256-289 256-290 256-291 256-292 256-293 256-294 256-295 256-296 256-297 256-298 256-299 256-300 256-301 256-302 256-303 256-304 256-305 256-306 256-307 256-308 256-309 256-310 256-311 256-312 256-313 256-314 256-315 256-316 256-317 256-318 256-319 256-320 256-321 256-322 256-323 256-324 256-325 256-326 256-327 256-328 256-329 256-330 256-331 256-332 256-333 256-334 256-335 256-336 256-337 256-338 256-339 256-340 256-341 256-342 256-343 256-344 256-345 256-346 256-347 256-348 256-349 256-350 256-351 256-352 256-353 256-354 256-355 256-356 256-357 256-358 256-359 256-360 256-361 256-362 256-363 256-364 256-365 256-366 256-367 256-368 256-369 256-370 256-371 256-372 256-373 256-374 256-375 256-376 256-377 256-378 256-379 256-380 256-381 256-382 256-383 256-384 256-385 256-386 256-387 256-388 256-389 256-390 256-391 256-392 256-393 256-394 256-395 256-396 256-397 256-398 256-399 256-400 256-401 256-402 256-403 256-404 256-405 256-406 256-407 256-408 256-409 256-410 256-411 256-412 256-413 256-414 256-415 256-416 256-417 256-418 256-419 256-420 256-421 256-422 256-423 256-424 256-425 256-426 256-427 256-428 256-429 256-430 256-431 256-432 256-433 256-434 256-435 256-436 256-437 256-438 256-439 256-440 256-441 256-442 256-443 256-444 256-445 256-446 256-447 256-448 256-449 256-450 256-451 256-452 256-453 256-454 256-455 256-456 256-457 256-458 256-459 256-460 256-461 256-462 256-463 256-464 256-465 256-466 256-467 256-468 256-469 256-470 256-471 256-472 256-473 256-474 256-475 256-476 256-477 256-478 256-479 256-480 256-481 256-482 256-483 256-484 256-485 256-486 256-487 256-488 256-489 256-490 256-491 256-492 256-493 256-494 256-495 256-496 256-497 256-498 256-499 256-500 256-501 256-502 256-503 256-504 256-505 256-506 256-507 256-508 256-509 256-510 256-511 256-512 256-513 256-514 256-515 256-516 256-517 256-518 256-519 256-520 256-521 256-522 256-523 256-524 256-525 256-526 256-527 256-528 256-529 256-530 256-531 256-532 256-533 256-534 256-535 256-536 256-537 256-538 256-539 256-540 256-541 256-542 256-543 256-544 256-545
-----	-------------------	---	------------	---	---	---	---	-------------------	--

995	ASF Right Joystick Moved Forward Active	1	Unassigned	0	1	-	-	0 - Inactive 1 - Active	PMBXN3 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544 1060545 1060546 1060547 1060548 1060549 1060550 1060551 1060552 1060553 1060554 1060555 10
-----	---	---	------------	---	---	---	---	----------------------------	---

1019	ASF Unloader Drive	1	Unassigned	0	1	-	-	0 - Off 1 - On	PM80XX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544	ALLCAN000
1020	ASF Cleaning Fan Control Turned Off	1	Unassigned	0	1	-	-	0 - No 1 - Yes	PM80XX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544	ALLCAN000
1021	ASF Threshing Drum Control Turned Off	1	Unassigned	0	1	-	-	0 - No 1 - Yes	PM80XX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544	ALLCAN000
1022	ASF Straw Walker is Chopped	1	Unassigned	0	1	-	-	0 - No 1 - Yes	PM80XX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 	

Item ID	Item Name	Quantity	Unit	Material	Part Number	Manufacturer	Notes	Comments	Location
1004	ASF Section 5 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1005	ASF Section 6 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1006	ASF Section 7 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1007	ASF Section 8 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1008	ASF Section 9 Spraying	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1009	USF Spreading	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1010	USF Paving Chemicals	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1011	USF Conveyor Belt	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1012	USF Salt Spreader's Drive Wheel	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1013	USF Brushes	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1014	USF Vacuum Cleaner	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1015	USF Water Supply	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1016	USF Spreading	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1017	USF Liquid pump	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1018	USF Unloading From The Hopper	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1019	USF Low Salt (Steel) Level In Container Indicator	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1020	USF Low Water Level In Container Indicator	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1021	USF Chemicals	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1022	USF Compressor	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1023	USF Water Valve Is Opened	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1024	USF Cabin Moved Up Status Active	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1025	USF Cabin Moved Down Status Active	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1026	USF Hydraulics Work Not Permitted	1	Unsprayed	0	1	-	0 - OE 1 - On		ALLCAN000
1027	OSF Section 1 Presence Of Fluid In The Downspout	1	Unsprayed	0	1	-	0 - No pressure 1 - Present		ALLCAN000

[illegible]

430	CNG Level Kg	2	Unsigned	0	65535	10	Kg	CNG Level Kg (appears only if CNG level percentage is not available)	CAN adapters
839	Distance from need of service	4	Unsigned	0	4294967295	-	km	Service - distance elapsed since the occurrence of the need for servicing	CAN adapters
840	Distance from last service	4	Unsigned	0	4294967295	-	km	Service - distance from the last service	CAN adapters
861	Time to next service	2	Unsigned	0	65535	-	day	Service - time to next service	CAN adapters
862	Time from need of service	2	Unsigned	0	65535	-	day	Service - time elapsed since the occurrence of the need for servicing	CAN adapters
863	Time from last service	2	Unsigned	0	65535	-	day	Service - time elapsed since the last service	CAN adapters
864	Distance to next oil service	4	Unsigned	0	4294967295	-	km	Service - distance to next oil service	CAN adapters
865	Time to next oil service	2	Unsigned	0	65535	-	day	Service - time to next oil service	CAN adapters
866	LVCAN Vehicle Range	4	Unsigned	0	4294967295	-	km	Information about vehicle range	CAN adapters
867	LVCAN Total CNG counted	4	Unsigned	0	65535	-	kg	Information about Total CNG used in counted mode	CAN adapters
1079	Total Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Total Bule Count	CAN adapters
1080	Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Bule Count	CAN adapters
1081	Cut Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Cut Bule Count	CAN adapters
1082	Bule Slices	4	Unsigned	0	0aFFFFFF	-	-	Bule Slices	CAN adapters
1116	LVCAN MaxRoadSpeed	1	Unsigned	0	255	-	km/h	Maximum speed from road signs	CAN adapters
1117	LVCAN ExceededRoadSpeed	1	Unsigned	0	255	-	km/h	Exceeded speed from road signs	CAN adapters
1205	LVCAN RSP SpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value" is recognized/cancelled	CAN adapters
1206	LVCAN RSP EndOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "End of speed limit with value" is recognized/cancelled	CAN adapters
1207	LVCAN RSP SpeedExceeded	1	Unsigned	0	1	-	-	Information if speed is exceeded indicated by road sign "Speed limit with value"	CAN adapters
1208	LVCAN RSP TimeOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Conditional time-specific speed limit with value" is recognized/cancelled	CAN adapters
1209	LVCAN RSP WthrSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value due to weather conditions" is recognized/cancelled	CAN adapters