

FMB964 Teltonika Data Sending Parameters ID

[Main Page](#) > [EOL Products](#) > [FMB964](#) > **FMB964 Teltonika Data Sending Parameters ID**

Document updated according firmware FMB.Ver.03.29.00 and newer.

FMB AVL ID's consist of these **parameters groups**:

□

Contents

- [1 Permanent I/O elements](#)
- [2 Eventual I/O elements](#)
- [3 OBD elements](#)
- [4 OBD OEM elements](#)
- [5 BLE Sensors I/O elements](#)
- [6 CAN adapters elements](#)

Permanent I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
239	Ignition	1	Unsigned	0	1	-	-	0 - Ignition Off 1 - Ignition On	FMBXXX	Permanent I/O Elements
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMB130	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
									FMU125	
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

240	Movement	1	Unsigned	0	1	-	-	0 - Movement Off 1 - Movement On	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements
80	Data Mode	1	Unsigned	0	5	-	-	0 - Home On Stop 1 - Home On Moving 2 - Roaming On Stop 3 - Roaming On Moving 4 - Unknown On Stop 5 - Unknown On Moving	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O Elements

										FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
21	GSM Signal	1	Unsigned	0	5	-	-	Value in range 1-5		Permanent I/O Elements	

									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
69	GNSS Status	1	Unsign ed	0	3	-	-	0 - GNSS OFF 1 - GNSS ON with fix 2 - GNSS ON without fix 3 - GNSS sleep	0	Permanent I/O Elements
									FMB900	
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	
									FMBXXX	
									FMB001	
									FMC001	
									FMB010	
									FMB002	
									FMB020	
									FMB003	
									FMB110	
									FMB120	
									FMB122	
									FMB125	
									FMU125	
									FMB140	
									FMB150	
									FMC150	
									FMM15	
									0	
181	GNSS PDOP	2	Unsign ed	0	500	0.1		Coefficient, calculation formula	FMB900	Permanent I/O Elements
									FMB920	
									FMB962	
									FMB964	
									FM3001	
									FMB202	
									FMB204	
									FMB206	
									FMT100	
									MTB100	
									FMP100	
									MSP500	
									FMC800	
									FMM80	
									0	
									FMM80	
									A	

182	GNSS HDOP	2	Unsigned	0	500	0.1	Coefficient, calculation formula	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O Elements
66	External Voltage	2	Unsigned	0	65535	0.001	V Voltage	FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMU125 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements

									FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
24	Speed	2	Unsigned	0	350	-	km/h	GNSS Speed	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements
									FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
205	GSM Cell ID	2	Unsigned	0	65535	-	-	GSM base station ID	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements

[illegible]

										FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMC800 FMM80 0 FMM80 A FMBXXX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	
68	Battery Current	2	Unsigned	0	65535	0.001	A	Current		Permanent I/O elements	
241	Active GSM Operator	4	Unsigned	0	42949 67295	-	-	Currently used GSM Operator code		Permanent I/O elements	

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FMB202 FMB204 FMB206 MTB100	
1	Digital Input 1	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
		</									

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

									FMBXXX FMB001 EMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
19	Axis Z	2	Signed	-8000	8000	-	mG	Z axis value	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements
									FMBXXX FMB001 EMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMB140 FMB150 FMC150 FMM15	
11	ICCID1	8	Unsigned	0	0xffffffff ffffffff	-	-	Value of SIM ICCID, MSB	0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 MSP500 FMC800 FMM80 0 FMM80 A	Permanent I/O elements

										FMBXXX FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 FMBXXX FMB900 FMB910 FMB920 FMC920 FMM92 0 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB140 FMB150 FMC150 FMM15 0 FMB202 FMB204 FMB206 FMB640 FMBXXX FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0 FMB140	
10	SD Status	1	Unsigned	0	1	-	-	0 - not present 1 - present	Permanent I/O elements		
2	Digital Input 2	1	Unsigned	0	1	-	-	Logic: 0/1	Permanent I/O elements		
3	Digital Input 3	1	Unsigned	0	1	-	-	Logic: 0/1	Permanent I/O elements		
6	Analog Input 2	2	Unsigned	0	65535	0.001	V	Voltage	Permanent I/O elements		

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

212	LLS 4 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
213	LLS 4 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
214	LLS 5 Fuel Level	2	Signed	-4	32767	-	kvants or ltr	Fuel level measured by LLS sensor via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
215	LLS 5 Temperature	1	Signed	-128	127	-	°C	Fuel temperature measured by LLS via RS485	FMB125 FMB125 FMU125 FMC125 FMM125	Permanent I/O elements
15	Eco Score	2	Unsigned	0	65535	0.01	-	Average amount of events on some distance	FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMBXXX FMB001 FMC001 FMB010 FMB120 FMB122 FMB125 FMB130 FMB140 FMB150 FMC150 FMM150	Permanent I/O elements
113	Battery Level	1	Unsigned	0	100	-	%	Battery capacity level	FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM800 FMB800 FMM800 FMB800 FMM800 FMB800 FMM800	Permanent I/O elements

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMB130 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMC001 FMC125 FMC130 FMM00 1 FMM12 5 FMM13 0 FMU125 FMU130 FMC800 FMM80 0 FMM80 A FMBXXX FM3001 FMU125 FMU126 FMU130 FMC125 FMC130 FMC150 FMM12 5 FMM13 0 FMM15 0 FMC001 FMM00 1 FMC800 FMM80 0 FMC880 FMM88 0 FMM80 A FMBXXX FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0	
238	User ID	8	Unsigned	0	0xffffffff ffffffff	-	-	MAC address of NMEA receiver device connected via Bluetooth	Permanent I/O elements		
237	Network Type	1	Unsigned	0	1	-	-	0 - 3G 1 - GSM 2 - 4G 3 - LTE CAT M1 4 - LTE CAT NB1 99 - Unknown	Permanent I/O elements		
4	Pulse Counter Din1	4	Unsigned	0	4294967295	-	-	Counts pulses, count is reset when records are saved	Permanent I/O elements		

5	Pulse Counter Din2	4	Unsign ed	0	42949 67295	-	-	Counts pulses, count is reset when records are saved	FMBXXX	Permanent I/O elements
									FMB110 FMB120 FMB122 FMB130 FMU130 FMC130 FMM13 0	
263	BT Status	1	Unsign ed	0	4	-	-	0 - BT is disabled 1 - BT Enabled, not device connected 2 - Device connected, BTv3 Only 3 - Device connected, BLE only 4 - Device connected, BLE + BT	FMBXXX	Permanent I/O elements
									FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMC800 FMM80 0 FMM80 A	
264	Barcode ID	Variable	ASCII	0	32	-	-	Barcode ID	FMBXXX	
									FMB001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100	

										FMBXXX FMB001 FMC001 FMB010 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM12 5 FMB130 FMU130 FMC130 FMM13 0 FMB140 FMB150 FMC150 FMM15 0 FMB900 FMB920 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMB125 FMB125 FMU125 FMC125 FMM12 5 FMBXXX FMB130 FMU130 FMC130 FMC150 FMM13 0 FMB130 FMU130 FMC130 FMM13 0 FMB140	
303	Instant Movement	1	Unsigned	0	1	-	-	Logic: 0/1 returns movement value		Permanent I/O elements	
327	UL202-02 Sensor Fuel level	2	Signed	-150	32767	0.1	mm	UL202-02 Sensor Fuel level		Permanent I/O elements	
483	UL202-02 Sensor Status	1	Unsigned	0	255	-	-	UL202-02 sensor status codes		Permanent I/O elements	
380	Digital output 3	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	
381	Ground Sense	1	Unsigned	0	1	-	-	Logic: 0/1		Permanent I/O elements	

329	AIN Speed	2	Unsigned	0	65535	-	-		MSP500	Permanent I/O elements
500	MSP500 vendor name	40	ASCII	0	40	-	-	Name of the integrator who installed the device	MSP500	Permanent I/O elements
501	MSP500 vehicle number	40	ASCII	0	40	-	-	Vehicle number on which the device is installed	MSP500	Permanent I/O elements
502	MSP500 speed sensor	1	unsigned	0	1	-	-	Status of the speed sensor	MSP500	Permanent I/O elements
637	Wake Reason	1	Unsigned	0	1	-	-	True if device was woken by RTC alarm	FMB965	Permanent I/O elements
FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910										
10800	EYE Temperature 1	2	Signed	-32768	32767	0.01	°C	Temperature measured by EYE Sensor 1		Permanent I/O elements

FMB910

10802	EYE Temperature 3	2	Signed -32768 32767	0.01	°C	Temperature measured by EYE Sensor 3
-------	-------------------	---	---------------------	------	----	--------------------------------------

Permanent I/O
elements

10842	EYE Magnet count 3	2	Unsigned	0	65535	-	-	Magnet trigger count measure by EYE Sensor 3	FMBXXX [Expand] FMB001 FMB010 FMB100 FMB110 FMB120 FMB122 FMB125 FMB130 FMB900 FMB920 FMB962 FMB964 FM3001 FM3010 FMB202 FMB204 FMB206 FMB207 FMT100 MTB100 TMT250 GH5200 FMB140 FMB020 FMB002 FMB003 FMU120 FMU122 FMU125 FMU126 FMU130 FMC120 FMC122 FMC125 FMC130 FMM12 5 FMM13 0 FMC001 FMM00 1 TFT100 FMB910	Permanent I/O elements
-------	--------------------	---	----------	---	-------	---	---	--	--	------------------------

[illegible]

										FMBXXX	
										[Expand]	
										FMB001	
										FMB010	
										FMB100	
										FMB110	
										FMB120	
										FMB122	
										FMB125	
										FMB130	
										FMB900	
										FMB920	
										FMB962	
										FMB964	
										FM3001	
										FM3010	
										FMB202	
										FMB204	
										FMB206	
										FMB207	
										FMB208	
										FMB209	
										FMT100	
										MTB100	
										TMT250	
										GH5200	
										FMB140	
										FMB020	
										FMB002	
										FMB003	
										FMU120	
										FMU122	
										FMU125	
										FMU126	
										FMU130	
										FMC120	
										FMC122	
										FMC125	
										FMC130	
										FMM12	
										5	
										FMM13	
										0	
										FMC001	
										FMM00	
										1	
										TFT100	
										FMB910	
										EMP100	
										EMP1M	
										1	
										MSP500	
										FMC800	
										FMM80	
										0	
										FMC880	
										FMM88	
										0	
										FMM80	
										A	
453	BLE RFID #3	8	HEX	0	0xffffffff ffffffff	-	-	BLE NBL-T RFID ID for Connexionless mode #3 slot			Permanent I/O elements

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

ID	Name	Confidence zone	Count	Status	Min	Max	Unit	Description	Eventual IO elements
228	Gedance zone 47	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
229	Gedance zone 48	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
230	Gedance zone 49	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
231	Gedance zone 50	1	Unsigned	0	3	-	-	0 - target left zone 1 - target entered zone 2 - over speeding end 3 - over speeding start	Eventual IO elements
175	Auto Gedance	1	Unsigned	0	1	-	-	0 - target left zone 1 - target entered zone	Eventual IO elements
210	Trip	1	Unsigned	0	1	-	-	0 - trip stop 1 - trip start From 01.01.24 for version available with ET app new values: 2 - Business Station 3 - Private Station 4-9 - Custom Stations	Eventual IO elements
255	Over Speeding	1	Unsigned	0	255	-	km/h	At over speeding start km/h, at over speeding end km/h	Eventual IO elements
257	Crash trace data	Variable	HEX	0	1200	-	-	Crash trace data	Eventual IO elements
265	Blood alcohol content	2	Unsigned	0	9999	-	-	Alcohol content in blood in perfoms and mode. First 14 bits from MSB are perfoms multiplied by 1000 and last to bits are 0 - Passive test, 1 Active test, 2 and 3	Eventual IO elements

[illegible]

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
30	Number of DTC	1	Unsigned	0	255	-	-	Number of DTC	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
31	Engine Load	1	Unsigned	0	100	-	%	Calculated engine load value	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
32	Coolant Temperature	1	Signed	-128	127	-	°C	Engine coolant temperature	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
33	Short Fuel Trim	1	Signed	-100	99	-	%	Short term fuel trim 1	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
34	Fuel pressure	2	Unsigned	0	765	-	kPa	Fuel pressure	OBD elements	
35	Intake MAP	1	Unsigned	0	255	-	kPa	Intake manifold absolute pressure	OBD elements	
36	Engine RPM	2	Unsigned	0	16384	-	rpm	Engine RPM	OBD elements	
37	Vehicle Speed	1	Unsigned	0	255	-	km/h	Vehicle speed	OBD elements	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
38	Timing Advance	1	Signed	-64	64	-	°	Timing advance			
39	Intake Air Temperature	1	Signed	-128	127	-	°C	Intake air temperature			
40	MAF	2	Unsigned	0	65535	0.01	g/sec	MAF air flow rate			
41	Throttle Position	1	Unsigned	0	100	-	%	Throttle position			

									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
42	Runtime since engine start	2	Unsigned	0	65535	-	s	Runtime since engine start	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
43	Distance Traveled MIL On	2	Unsigned	0	65535	-	km	Distance ormattin MIL on	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
44	Relative Fuel Rail Pressure	2	Unsigned	0	5178	0.1	kPa	Relative fuel rail pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
									FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
45	Direct Fuel Rail Pressure	2	Unsigned	0	65535	10	kPa	Direct Fuel Rail Pressure	FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
46	Commanded EGR	1	Unsigned	0	100	-	%	Commanded EGR		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
47	EGR Error	1	Signed	-100	100	-	%	EGR error		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
48	Fuel Level	1	Unsigned	0	100	-	%	Fuel level		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	
49	Distance Since Codes Clear	2	Unsigned	0	65535	-	km	Distance traveled since codes cleared		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140 FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
53	Ambient Air Temperature	1	Signed	-128	127	-	°C	Ambient air temperature		OBD elements	
54	Time Run With MIL On	2	Unsigned	0	65535	-	min	Time run with MIL on		OBD elements	
55	Time Since Codes Cleared	2	Unsigned	0	65535	-	min	Time since codes cleared		OBD elements	
56	Absolute Fuel Rail Pressure	2	Unsigned	0	65535	0.1	kPa	Absolute fuel rail pressure		OBD elements	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
57	Hybrid battery pack life	1	Unsigned	0	100	-	%	Hybrid battery pack remaining life		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
58	Engine Oil Temperature	1	Unsigned	0	215	-	°C	Engine oil temperature		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
59	Fuel injection timing	2	Signed	-21000	30200	0.01	°	Fuel injection timing		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
540	Throttle position group	1	Unsigned	0	100	-	%	Throttle Position Value From PID Group		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
541	Commanded Equivalence R	1	Unsigned	0	200	0.01	-	Fuel-Air Commanded Equivalence Ratio		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	
542	Intake MAP 2 bytes	2	Unsigned	0	2048	-	kPa	Intake Manifold Absolute Pressure		FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMM125 FMC125 FMM125 FMB130 FMM130 FMC130 FMM130	

										FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	
543	Hybrid System Voltage	2	Unsigned	0	1024	-	V	Hybrid vehicle system voltage		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
544	Hybrid System Current	2	Signed	-3277	3277	-	A	Hybrid vehicle system current		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
281	Fault Codes	variable	ASCII	0	128	-	-	Fault Codes (values separated via ",")		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements
60	Fuel Rate	2	Unsigned	0	32767	0.01	L/h	Engine fuel rate, L/h*100		FMBXXX FMB001 FMC001 FMB010 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMM125 FMB130 FMU130 FMC130 FMM130 FMB140 FMC150 FMM150 FMB900 FMB920 FMB962 FMB964 FM3001 FMT100 MTB100 FMB202 FMB204 FMB206 FMT100 MTB100 FMB140	OBD elements

OBD OEM elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multiplier	Units	Description	HW Support	Parameter Group
				Min	Max					
389	OBD OEM Total Mileage	4	Unsigned	0	0xffffffff	-	km	Total mileage received by requesting vehicle specific PID	FMB003	OBD OEM elements
390	OBD OEM Fuel Level	4	Unsigned	0	0xffffffff	0.1	l	Fuel level in litres received by requesting vehicle specific PID	FMB003	OBD OEM elements
402	OEM Distance Until Service	4	Unsigned	0	0xffffffff	-	km	Distance till next service received by requesting vehicle specific PID	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
410	OEM Battery charge state	1	Unsigned	0	1	-	-	0 - Not charging 1 - Charging	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
411	OEM Battery charge level	1	Unsigned	0	100	-	%	Represents battery charged level	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
412	OEM Battery power consumption	2	Unsigned	0	65535	-	kWh/100km	Represents battery power consumption	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
755	OEM Remaining distance	2	Unsigned	0	65535	-	km	Remaining distance until fuel tank empty or battery (EV) depleted	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
1151	OEM Battery State Of Health	2	Unsigned	0	65535	-	%	Battery State of Health	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	
1152	OEM Battery Temperature	2	Signed	-32768	32767	-	°C	Battery pack temperature	FMB001	OBD OEM elements
									FMC001	
									FMM001	
									FMB003	
									FMC003	

BLE Sensors I/O elements

Property ID in AVL packet	Property Name	Bytes	Type	Value range		Multi plier	Units	Description	HW Supp ort	Parameter Group
				Min	Max					

25	BLE Temperature #1	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

26	BLE Temperature #2	2	Signe d	-4000 12500 0.01*	°C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	-------------------	----	--	--	-------------------------

27	BLE Temperature #3	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

28	BLE Temperature #4	2	Signe d	-4000 12500 0.01* °C	Degrees (°C), -40 - +125; Error codes: 4000 - abnormal sensor state 3000 - sensor not found 2000 - failed sensor data parsing From firmware version 03.28.00 and up: 32767 - sensor not found 32766 - failed sensor data parsing 32765 - abnormal sensor state	FMBX XX FMB0 01 FMC0 01 FMB0 10 FMB0 02 FMB0 20 FMB0 03 FMB1 10 FMB1 20 FMB1 22 FMB1 25 FMU1 25 FMC1 25 FMB1 30 FMU1 30 FMC1 30 FMB1 40 FMB1 50 FMC1 50 FMM 150 FMB9 00 FMB9 20 FMB9 10 FMB9 62 FMB9 64 FM30 01 FMB2 02 FMB2 04 FMB2 06 FMT1 00 MTB1 00 FMP1 00 FMB1 40 MSP5 00 FMC8 00 FMM 800 FMM 80A	Bluetooth Low Energy
----	--------------------	---	------------	----------------------	--	--	-------------------------

[illegible]

										FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
22	BLE Battery #3	1	Unsigned	0	100	-	%	Battery level of sensor #3		Bluetooth Low Energy	

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

[illegible]

[illegible]

[illegible]

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
465	BLE 1 Custom #4	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
468	BLE 2 Custom #3	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
473	BLE 3 Custom #4	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

									FMBX XX FMB001 FMC001 FMB010 FMB002 FMB020 FMB003 FMB110 FMB120 FMB122 FMB125 FMU125 FMC125 FMB130 FMU130 FMC130 FMB140 FMB150 FMC150 FMM150 FMB900 FMB920 FMB910 FMB962 FMB964 FM3001 FMB202 FMB204 FMB206 FMT100 MTB100 FMP100 FMB140 MSP500 FMC800 FMM800 FMM80A	
474	BLE 3 Custom #5	4	UNSI GNED LONG INT	0	42949 67295	-	-	Custom IO element for BLE sensor	Bluetooth Low Energy	

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

CAN adapters elements

[illegible]

133	Tachograph Total Vehicle Distance	4	Unsigned	0	4294967295	-	m	Tacho Total Vehicle Distance	ALLCAN300
134	Trip Distance	4	Unsigned	0	4294967295	-	m	Trip distance	ALLCAN300
135	Tachograph Vehicle Speed	2	Unsigned	0	255	-	km/h	Tacho vehicle speed	ALLCAN300
136	Tacho Driver Card Presence	1	Unsigned	0	3	-	-	Tacho Driver Card Presence	ALLCAN300
137	Driver 1 Status	1	Unsigned	0	255	-	-	Driver 1 Status	ALLCAN300
138	Driver 2 Status	1	Unsigned	0	255	-	-	Driver 2 Status	ALLCAN300
139	Driver 1 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Continuous Driving Time, minutes	ALLCAN300
140	Driver 2 Continuous Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Continuous Driving Time, minutes	ALLCAN300
141	Driver 1 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Break Time, minutes	ALLCAN300
142	Driver 2 Cumulative Break Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Break Time, minutes	ALLCAN300
143	Driver 1 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 1 Duration Of Selected Activity, minutes	ALLCAN300
144	Driver 2 Selected Activity Duration	2	Unsigned	0	65535	-	min.	Driver 2 Duration Of Selected Activity, minutes	ALLCAN300
145	Driver 1 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 1 Cumulative Driving Time, minutes	ALLCAN300
146	Driver 2 Cumulative Driving Time	2	Unsigned	0	65535	-	min.	Driver 2 Cumulative Driving Time, minutes	ALLCAN300
147	Driver 1 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID High	ALLCAN300
148	Driver 1 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 1 ID Low	ALLCAN300
149	Driver 2 ID High	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID High	ALLCAN300
150	Driver 2 ID Low	8	Unsigned	0	0xFFFFFFFF	-	-	Driver 2 ID Low	ALLCAN300
151	Battery Temperature	2	Signed	400	1270	0.1	°C	Battery temperature in Celsius	ALLCAN300
152	HV Battery Level	1	Unsigned	0	100	-	%	Battery level in percent	ALLCAN300, CANCONTROL
160	DTC Faults	1	Unsigned	0	255	-	-	DTC Faults Count	ALLCAN300, CANCONTROL
161	Slope of Arm	2	Signed	-3276	3276	-	Degrees *	Slope Of Arm	ALLCAN300
162	Rotation of Arm	2	Signed	-180	180	-	Degrees *	Rotation Of Arm	ALLCAN300
163	Eject of Arm	2	Unsigned	0	6553	-	m	Eject of arm	ALLCAN300

164	Horizontal Distance Arm Vehicle	2	Unassigned	0	6553	-	m	Horizontal Distance Arm Vehicle	ALLCAN300
165	Height Arm Above Ground	2	Unassigned	0	6553	-	m	Height Arm Above Ground	ALLCAN300
166	Doll RPM	2	Unassigned	0	65535	-	rpm	Doll RPM	ALLCAN300
167	Amount Of Spread Salt Square Meter	2	Unassigned	0	655	-	g/m ²	Amount Of Spread Salt Square Meter	ALLCAN300
168	Battery Voltage	2	Unassigned	0	6553	-	V	Battery Voltage	ALLCAN300
169	Amount Of Spread Fine Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Spread Fine Grained Salt	ALLCAN300
170	Amount Of Coarse Grained Salt	4	Unassigned	0	1677722	-	T	Amount Of Coarse Grained Salt	ALLCAN300
171	Amount Of Spread Dbls	4	Unassigned	0	1677722	-	T	Amount Of Spread Dbls	ALLCAN300
172	Amount Of Spread Coarse Grained Calcium	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Coarse Grained Calcium	ALLCAN300
173	Amount Of Spread Calcium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Calcium Chloride	ALLCAN300
174	Amount Of Spread Sodium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Sodium Chloride	ALLCAN300
176	Amount Of Spread Magnesium Chloride	4	Unassigned	0	1677722	-	m ³	Amount Of Spread Magnesium Chloride	ALLCAN300
177	Amount Of Spread Gravel	4	Unassigned	0	1677722	-	T	Amount Of Spread Gravel	ALLCAN300
178	Amount Of Spread Sand	4	Unassigned	0	1677722	-	T	Amount Of Spread Sand	ALLCAN300
183	Width Pouring Left	2	Unassigned	0	655	-	m	Width Pouring Left	ALLCAN300
184	Width Pouring Right	2	Unassigned	0	655	-	m	Width Pouring Right	ALLCAN300
185	Salt Spreader Working Hours	4	Unassigned	0	167722	-	h	Salt Spreader Working Hours	ALLCAN300
186	Distance During Salting	4	Unassigned	0	167722	-	km	Distance During Salting	ALLCAN300
187	Load Weight	4	Unassigned	0	16772215	-	kg	Load Weight	ALLCAN300
188	Retarder Load	1	Unassigned	0	130	-	%	Retarder Load in percent	ALLCAN300
189	Cruise Time	4	Unassigned	0	16772215	-	min	Cruise time in minutes	ALLCAN300
232	CNG Status	1	Unassigned	0	1	-	-	CNG Status	LUCAN200, CANCONTROL
233	CNG Used	4	Unassigned	0	16772215	-	kg	CNG used	LUCAN200, CANCONTROL

234	CNG Level	1	Unsigned	0	100	-	%	CNG Level	FMI00XX FMI001 FMI002 FMI003 FMI004 FMI005 FMI006 FMI007 FMI008 FMI009 FMI010 FMI011 FMI012 FMI013 FMI014 FMI015 FMI016 FMI017 FMI018 FMI019 FMI020	LVCAN200, CANCONTROL
235	Oil Level	1	Unsigned	0	1	-	-	Engine Oil Level Indicator Status	FMI00XX FMI021 FMI022 FMI023 FMI024 FMI025 FMI026 FMI027 FMI028 FMI029 FMI030	ALLCAN300, CANCONTROL
304	Vehicles Range On Battery	4	Unsigned	0	16771215	-	m	Vehicle Range on Battery	FMI00XX FMI031 FMI032 FMI033 FMI034 FMI035 FMI036 FMI037 FMI038 FMI039 FMI040	ALLCAN300, CANCONTROL
305	Vehicles Range On Additional Fuel	4	Unsigned	0	16771215	-	m	Vehicle Range On Additional Fuel	FMI00XX FMI041 FMI042 FMI043 FMI044 FMI045 FMI046 FMI047 FMI048 FMI049	ALLCAN300, CANCONTROL
325	VIN	17	ASCII	0	0aFF	-	-	VIN number	FMI00XX FMI050 FMI051 FMI052 FMI053 FMI054 FMI055 FMI056 FMI057 FMI058 FMI059 FMI060	CANCONTROL
282	Fault Codes	Variable	-	0	128	-	-	DTC Fault codes	FMI00XX FMI061 FMI062 FMI063 FMI064 FMI065 FMI066 FMI067 FMI068 FMI069	LV-CAN200 + DTC
517	Security State Flags P4	8	HEX	0	0a000000	-	-	Security state flags protocol 4, more information click here Link	FMI00XX FMI070	ALLCAN300
518	Control State Flags P4	8	HEX	0	0a000000	-	-	Control state flags protocol 4, more information click here Link	FMI00XX FMI071	ALLCAN300
519	Indicator State Flags P4	8	HEX	0	0a000000	-	-	Indicator state flags protocol 4, more information click here Link	FMI00XX FMI072	ALLCAN300
520	Agricultural State Flags P4	8	HEX	0	0a000000	-	-	Agricultural state flags protocol 4, more information click here Link	FMI00XX FMI073	ALLCAN300
521	Utility State Flags P4	8	HEX	0	0a000000	-	-	Utility state flags protocol 4, more information click here Link	FMI00XX FMI074	ALLCAN300
522	Custom State Flags P4	8	HEX	0	0a000000	-	-	Custom state flags protocol 4, more information click here Link	FMI00XX FMI075	ALLCAN300
855	LNG Used	4	Unsigned	0	214748364	-	kg	Total LNG used in kilograms	FMI00XX FMI076	ALLCAN300, CANCONTROL
856	LNG Used (converted)	4	Unsigned	0	214748364	-	kg	Total LNG used converted in kg	FMI00XX FMI077	ALLCAN300, CANCONTROL
857	LNG Level	2	Unsigned	0	100	-	%	LNG level in perc	FMI00XX FMI078	ALLCAN300, CANCONTROL
858	LNG Level	2	Unsigned	0	6535	-	kg	LNG level in kg	FMI00XX FMI079	ALLCAN300, CANCONTROL
1100	Total LPG Used	4	Unsigned	0	4296967295	-	l	Total LPG used in liters	FMI00XX FMI080	LVCAN
1101	Total LPG Used Counted	4	Unsigned	0	4296967295	-	l	Total LPG used counted in liters	FMI00XX FMI081	LVCAN
1102	LPG Level Prec.	2	Unsigned	0	6535	-	%	LPG level in perc.	FMI00XX FMI082	LVCAN
1103	LPG Level Liters	2	Unsigned	0	6535	-	l	LPG level in liters	FMI00XX FMI083	LVCAN
898	SSF Ignition	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI084 FMI085 FMI086 FMI087 FMI088 FMI089 FMI090	LVCAN, ALLCAN300, CANCONTROL
652	SSF KeyIgnitionLock	1	Unsigned	0	1	-	-	0 - No key in lock 1 - Key in lock	FMI00XX FMI091 FMI092 FMI093 FMI094 FMI095 FMI096 FMI097	ALLCAN300, CANCONTROL
899	SSF Windows	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI098 FMI099 FMI100 FMI101 FMI102 FMI103	ALLCAN300
900	SSF Engine Working	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI104 FMI105 FMI106 FMI107 FMI108 FMI109	ALLCAN300, CANCONTROL
901	SSF Standalone Engine	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI110 FMI111 FMI112 FMI113	ALLCAN300
902	SSF Ready To Drive	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI114 FMI115 FMI116 FMI117 FMI118	ALLCAN300, CANCONTROL
903	SSF Engine Working On CNG	1	Unsigned	0	1	-	-	0 - No 1 - Yes	FMI00XX FMI119 FMI120 FMI121 FMI122	ALLCAN300, CANCONTROL
904	SSF Work Mode	1	Unsigned	0	1	-	-	0 - Private 1 - Company	FMI00XX FMI123 FMI124 FMI125 FMI126	ALLCAN300
905	SSF Operator	1	Unsigned	0	1	-	-	0 - Not present 1 - Present	FMI00XX FMI127 FMI128 FMI129 FMI130	ALLCAN300
906	SSF Interlock	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI131 FMI132 FMI133 FMI134	ALLCAN300
907	SSF Engine Lock Active	1	Unsigned	0	1	-	-	0 - Inactive 1 - Active	FMI00XX FMI135 FMI136 FMI137 FMI138	CANCONTROL
908	SSF Request To Lock Engine	1	Unsigned	0	1	-	-	0 - Off 1 - On	FMI00XX FMI139 FMI140 FMI141 FMI142	CANCONTROL
653	SSF Handbrake Is Active	1	Unsigned	0	1	-	-	0 - Handbrake inactive 1 - Handbrake active	FMI00XX FMI143 FMI144 FMI145 FMI146	ALLCAN300, CANCONTROL
910	SSF Footbrake Is Active	1	Unsigned	0	1	-	-	0 - Footbrake inactive 1 - Footbrake active	FMI00XX FMI147 FMI148 FMI149 FMI150	ALLCAN300, CANCONTROL
911	SSF Clutch Pushed	1	Unsigned	0	1	-	-	0 - Clutch is pushed 1 - Clutch is not pushed	FMI00XX FMI151 FMI152 FMI153 FMI154	ALLCAN300, CANCONTROL
912	SSF Hazard Warning Lights	1	Unsigned	0	1	-	-	0 - Hazard warning lights on 1 - Hazard warning lights off	FMI00XX FMI155 FMI156 FMI157 FMI158	ALLCAN300, CANCONTROL

[illegible]

[illegible]

Item ID	Item Name	Item Type	Item Status	Item Count	Item Unit	Item Price	Item Total	Item Description	Item Location
1019	ASF Unloader Drive	1	Unassigned	0	1	-	0 - Off 1 - On	PM80XX 1060110 1060111 1060112 1060113 1060114 1060115 1060116 1060117 1060118 1060119 1060120 1060121 1060122 1060123 1060124 1060125 1060126 1060127 1060128 1060129 1060130 1060131 1060132 1060133 1060134 1060135 1060136 1060137 1060138 1060139 1060140 1060141 1060142 1060143 1060144 1060145 1060146 1060147 1060148 1060149 1060150 1060151 1060152 1060153 1060154 1060155 1060156 1060157 1060158 1060159 1060160 1060161 1060162 1060163 1060164 1060165 1060166 1060167 1060168 1060169 1060170 1060171 1060172 1060173 1060174 1060175 1060176 1060177 1060178 1060179 1060180 1060181 1060182 1060183 1060184 1060185 1060186 1060187 1060188 1060189 1060190 1060191 1060192 1060193 1060194 1060195 1060196 1060197 1060198 1060199 1060200 1060201 1060202 1060203 1060204 1060205 1060206 1060207 1060208 1060209 1060210 1060211 1060212 1060213 1060214 1060215 1060216 1060217 1060218 1060219 1060220 1060221 1060222 1060223 1060224 1060225 1060226 1060227 1060228 1060229 1060230 1060231 1060232 1060233 1060234 1060235 1060236 1060237 1060238 1060239 1060240 1060241 1060242 1060243 1060244 1060245 1060246 1060247 1060248 1060249 1060250 1060251 1060252 1060253 1060254 1060255 1060256 1060257 1060258 1060259 1060260 1060261 1060262 1060263 1060264 1060265 1060266 1060267 1060268 1060269 1060270 1060271 1060272 1060273 1060274 1060275 1060276 1060277 1060278 1060279 1060280 1060281 1060282 1060283 1060284 1060285 1060286 1060287 1060288 1060289 1060290 1060291 1060292 1060293 1060294 1060295 1060296 1060297 1060298 1060299 1060300 1060301 1060302 1060303 1060304 1060305 1060306 1060307 1060308 1060309 1060310 1060311 1060312 1060313 1060314 1060315 1060316 1060317 1060318 1060319 1060320 1060321 1060322 1060323 1060324 1060325 1060326 1060327 1060328 1060329 1060330 1060331 1060332 1060333 1060334 1060335 1060336 1060337 1060338 1060339 1060340 1060341 1060342 1060343 1060344 1060345 1060346 1060347 1060348 1060349 1060350 1060351 1060352 1060353 1060354 1060355 1060356 1060357 1060358 1060359 1060360 1060361 1060362 1060363 1060364 1060365 1060366 1060367 1060368 1060369 1060370 1060371 1060372 1060373 1060374 1060375 1060376 1060377 1060378 1060379 1060380 1060381 1060382 1060383 1060384 1060385 1060386 1060387 1060388 1060389 1060390 1060391 1060392 1060393 1060394 1060395 1060396 1060397 1060398 1060399 1060400 1060401 1060402 1060403 1060404 1060405 1060406 1060407 1060408 1060409 1060410 1060411 1060412 1060413 1060414 1060415 1060416 1060417 1060418 1060419 1060420 1060421 1060422 1060423 1060424 1060425 1060426 1060427 1060428 1060429 1060430 1060431 1060432 1060433 1060434 1060435 1060436 1060437 1060438 1060439 1060440 1060441 1060442 1060443 1060444 1060445 1060446 1060447 1060448 1060449 1060450 1060451 1060452 1060453 1060454 1060455 1060456 1060457 1060458 1060459 1060460 1060461 1060462 1060463 1060464 1060465 1060466 1060467 1060468 1060469 1060470 1060471 1060472 1060473 1060474 1060475 1060476 1060477 1060478 1060479 1060480 1060481 1060482 1060483 1060484 1060485 1060486 1060487 1060488 1060489 1060490 1060491 1060492 1060493 1060494 1060495 1060496 1060497 1060498 1060499 1060500 1060501 1060502 1060503 1060504 1060505 1060506 1060507 1060508 1060509 1060510 1060511 1060512 1060513 1060514 1060515 1060516 1060517 1060518 1060519 1060520 1060521 1060522 1060523 1060524 1060525 1060526 1060527 1060528 1060529 1060530 1060531 1060532 1060533 1060534 1060535 1060536 1060537 1060538 1060539 1060540 1060541 1060542 1060543 1060544	

1094	ASF Section 5 Spraying	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248110 1248111 1248112 1248113 1248114 1248115 1248116 1248117 1248118 1248119 FMHXKX 1248120 1248121 1248122 1248123 1248124 1248125 1248126 1248127 1248128 1248129 FMHXKX 1248130 1248131 1248132 1248133 1248134 1248135 1248136 1248137 1248138 1248139 FMHXKX 1248140 1248141 1248142 1248143 1248144 1248145 1248146 1248147 1248148 1248149 FMHXKX 1248150 1248151 1248152 1248153 1248154 1248155 1248156 1248157 1248158 1248159 FMHXKX 1248160 1248161 1248162 1248163 1248164 1248165 1248166 1248167 1248168 1248169 FMHXKX 1248170 1248171 1248172 1248173 1248174 1248175 1248176 1248177 1248178 1248179 FMHXKX 1248180 1248181 1248182 1248183 1248184 1248185 1248186 1248187 1248188 1248189 FMHXKX 1248190 1248191 1248192 1248193 1248194 1248195 1248196 1248197 1248198 1248199 ALLCAN300
1095	ASF Section 6 Spraying	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248200 1248201 1248202 1248203 1248204 1248205 1248206 1248207 1248208 1248209 FMHXKX 1248210 1248211 1248212 1248213 1248214 1248215 1248216 1248217 1248218 1248219 FMHXKX 1248220 1248221 1248222 1248223 1248224 1248225 1248226 1248227 1248228 1248229 FMHXKX 1248230 1248231 1248232 1248233 1248234 1248235 1248236 1248237 1248238 1248239 FMHXKX 1248240 1248241 1248242 1248243 1248244 1248245 1248246 1248247 1248248 1248249 FMHXKX 1248250 1248251 1248252 1248253 1248254 1248255 1248256 1248257 1248258 1248259 ALLCAN300
1096	ASF Section 7 Spraying	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248260 1248261 1248262 1248263 1248264 1248265 1248266 1248267 1248268 1248269 FMHXKX 1248270 1248271 1248272 1248273 1248274 1248275 1248276 1248277 1248278 1248279 FMHXKX 1248280 1248281 1248282 1248283 1248284 1248285 1248286 1248287 1248288 1248289 FMHXKX 1248290 1248291 1248292 1248293 1248294 1248295 1248296 1248297 1248298 1248299 ALLCAN300
1097	ASF Section 8 Spraying	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248300 1248301 1248302 1248303 1248304 1248305 1248306 1248307 1248308 1248309 FMHXKX 1248310 1248311 1248312 1248313 1248314 1248315 1248316 1248317 1248318 1248319 FMHXKX 1248320 1248321 1248322 1248323 1248324 1248325 1248326 1248327 1248328 1248329 FMHXKX 1248330 1248331 1248332 1248333 1248334 1248335 1248336 1248337 1248338 1248339 ALLCAN300
1098	ASF Section 9 Spraying	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248340 1248341 1248342 1248343 1248344 1248345 1248346 1248347 1248348 1248349 FMHXKX 1248350 1248351 1248352 1248353 1248354 1248355 1248356 1248357 1248358 1248359 FMHXKX 1248360 1248361 1248362 1248363 1248364 1248365 1248366 1248367 1248368 1248369 FMHXKX 1248370 1248371 1248372 1248373 1248374 1248375 1248376 1248377 1248378 1248379 ALLCAN300
1036	USF Spreading	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248380 1248381 1248382 1248383 1248384 1248385 1248386 1248387 1248388 1248389 FMHXKX 1248390 1248391 1248392 1248393 1248394 1248395 1248396 1248397 1248398 1248399 FMHXKX 1248400 1248401 1248402 1248403 1248404 1248405 1248406 1248407 1248408 1248409 FMHXKX 1248410 1248411 1248412 1248413 1248414 1248415 1248416 1248417 1248418 1248419 ALLCAN300
1037	USF Pumping Chemicals	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248420 1248421 1248422 1248423 1248424 1248425 1248426 1248427 1248428 1248429 FMHXKX 1248430 1248431 1248432 1248433 1248434 1248435 1248436 1248437 1248438 1248439 FMHXKX 1248440 1248441 1248442 1248443 1248444 1248445 1248446 1248447 1248448 1248449 FMHXKX 1248450 1248451 1248452 1248453 1248454 1248455 1248456 1248457 1248458 1248459 ALLCAN300
1038	USF Conveyor Belt	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248460 1248461 1248462 1248463 1248464 1248465 1248466 1248467 1248468 1248469 FMHXKX 1248470 1248471 1248472 1248473 1248474 1248475 1248476 1248477 1248478 1248479 FMHXKX 1248480 1248481 1248482 1248483 1248484 1248485 1248486 1248487 1248488 1248489 FMHXKX 1248490 1248491 1248492 1248493 1248494 1248495 1248496 1248497 1248498 1248499 ALLCAN300
1039	USF Salt Spreader's Drive Wheel	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248500 1248501 1248502 1248503 1248504 1248505 1248506 1248507 1248508 1248509 FMHXKX 1248510 1248511 1248512 1248513 1248514 1248515 1248516 1248517 1248518 1248519 FMHXKX 1248520 1248521 1248522 1248523 1248524 1248525 1248526 1248527 1248528 1248529 FMHXKX 1248530 1248531 1248532 1248533 1248534 1248535 1248536 1248537 1248538 1248539 ALLCAN300
1040	USF Brushes	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248540 1248541 1248542 1248543 1248544 1248545 1248546 1248547 1248548 1248549 FMHXKX 1248550 1248551 1248552 1248553 1248554 1248555 1248556 1248557 1248558 1248559 FMHXKX 1248560 1248561 1248562 1248563 1248564 1248565 1248566 1248567 1248568 1248569 FMHXKX 1248570 1248571 1248572 1248573 1248574 1248575 1248576 1248577 1248578 1248579 ALLCAN300
1041	USF Vacuum Cleaner	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248580 1248581 1248582 1248583 1248584 1248585 1248586 1248587 1248588 1248589 FMHXKX 1248590 1248591 1248592 1248593 1248594 1248595 1248596 1248597 1248598 1248599 FMHXKX 1248600 1248601 1248602 1248603 1248604 1248605 1248606 1248607 1248608 1248609 FMHXKX 1248610 1248611 1248612 1248613 1248614 1248615 1248616 1248617 1248618 1248619 ALLCAN300
1042	USF Water Supply	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248620 1248621 1248622 1248623 1248624 1248625 1248626 1248627 1248628 1248629 FMHXKX 1248630 1248631 1248632 1248633 1248634 1248635 1248636 1248637 1248638 1248639 FMHXKX 1248640 1248641 1248642 1248643 1248644 1248645 1248646 1248647 1248648 1248649 FMHXKX 1248650 1248651 1248652 1248653 1248654 1248655 1248656 1248657 1248658 1248659 ALLCAN300
1043	USF Spreading	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248660 1248661 1248662 1248663 1248664 1248665 1248666 1248667 1248668 1248669 FMHXKX 1248670 1248671 1248672 1248673 1248674 1248675 1248676 1248677 1248678 1248679 FMHXKX 1248680 1248681 1248682 1248683 1248684 1248685 1248686 1248687 1248688 1248689 FMHXKX 1248690 1248691 1248692 1248693 1248694 1248695 1248696 1248697 1248698 1248699 ALLCAN300
1044	USF Liquid pump	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248700 1248701 1248702 1248703 1248704 1248705 1248706 1248707 1248708 1248709 FMHXKX 1248710 1248711 1248712 1248713 1248714 1248715 1248716 1248717 1248718 1248719 FMHXKX 1248720 1248721 1248722 1248723 1248724 1248725 1248726 1248727 1248728 1248729 FMHXKX 1248730 1248731 1248732 1248733 1248734 1248735 1248736 1248737 1248738 1248739 ALLCAN300
1045	USF Unloading From The Hopper	1	Unassigned	0	1	-	-	0 - Off 1 - On	FMHXKX 1248740 1248741 1248742 1248743 1248744 1248745 1248746 1248747 1248748 1248749 FMHXKX 1248750 1248751 1248752 1248753 1248754 1248755 1248756 1248757 1248758 1248759 FMHXKX 1248760 1248761 1248762 1248763 1248764 1248765 1248766 1248767 1248768 1248769 FMHXKX 1248770 1248771 1248772 1248773 1248774 1248775

[illegible]

430	CNG Level Kg	2	Unsigned	0	65535	10	Kg	CNG Level Kg (appears only if CNG level percentage is not available)	CAN adapters
839	Distance from need of service	4	Unsigned	0	4294967295	-	km	Service - distance elapsed since the occurrence of the need for servicing	CAN adapters
840	Distance from last service	4	Unsigned	0	4294967295	-	km	Service - distance from the last service	CAN adapters
861	Time to next service	2	Unsigned	0	65535	-	day	Service - time to next service	CAN adapters
862	Time from need of service	2	Unsigned	0	65535	-	day	Service - time elapsed since the occurrence of the need for servicing	CAN adapters
863	Time from last service	2	Unsigned	0	65535	-	day	Service - time elapsed since the last service	CAN adapters
864	Distance to next oil service	4	Unsigned	0	4294967295	-	km	Service - distance to next oil service	CAN adapters
865	Time to next oil service	2	Unsigned	0	65535	-	day	Service - time to next oil service	CAN adapters
866	LVCAN Vehicle Range	4	Unsigned	0	4294967295	-	km	Information about vehicle range	CAN adapters
867	LVCAN Total CNG counted	4	Unsigned	0	65535	-	kg	Information about Total CNG used in counted mode	CAN adapters
1079	Total Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Total Bule Count	CAN adapters
1080	Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Bule Count	CAN adapters
1081	Cut Bule Count	4	Unsigned	0	0aFFFFFF	-	-	Cut Bule Count	CAN adapters
1082	Bule Slices	4	Unsigned	0	0aFFFFFF	-	-	Bule Slices	CAN adapters
1116	LVCAN MaxRoadSpeed	1	Unsigned	0	255	-	km/h	Maximum speed from road signs	CAN adapters
1117	LVCAN ExceededRoadSpeed	1	Unsigned	0	255	-	km/h	Exceeded speed from road signs	CAN adapters
1205	LVCAN RSP SpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value" is recognized/cancelled	CAN adapters
1206	LVCAN RSP EndOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "End of speed limit with value" is recognized/cancelled	CAN adapters
1207	LVCAN RSP SpeedExceeded	1	Unsigned	0	1	-	-	Information if speed is exceeded indicated by road sign "Speed limit with value"	CAN adapters
1208	LVCAN RSP TimeOfSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Conditional time-specific speed limit with value" is recognized/cancelled	CAN adapters
1209	LVCAN RSP WthrSpeedLimitSign	1	Unsigned	0	1	-	-	Information if road sign "Speed limit with value due to weather conditions" is recognized/cancelled	CAN adapters