

https://wiki.teltonika-gps.com/view/FMB_getio

FMB getio



Example:

DI1:0 DI2:0 DI3:0 AIN1:0 AIN2:0 DO1:0 DO2:0

Response details	Description	Example
DI1	Digital input 1 value	DI1:0
DI2	Digital input 2 value	DI2:0
DI3	Digital input 3 value	DI3:0
AIN1	Analog input 1 value	AIN1:0
AIN2	Analog input 2 value	AIN2:0
DO1	Digital output 1 value	DO1:0
DO2	Digital output 2 value	DO2:0