FMB lvcanfaultcodes

Possible OK answers from LV-CAN200 + DTC:

1. No fault codes detected;

2. "2:C0300,1:P0300,3:B0200,4:U0100" - detected 4 DTC codes: ABS controller (C0300), ENGINE controller (P0300), SRS controller (B0200), TCM controller (U0100).

Possible error answers:

1. Ignition is off (DTC reading is not possible);

2. DTC not supported;

3. Communication error;

4. Error – diagnostic computer connected;

5. Error – engine is working.