

# FMB readio



Example (if wrong AVL ID):

Not supported or not enabled IO element requested

Example:

Param ID:239 Value:0

<b>Response details</b>	<b>Description</b>	<b>Example</b>
<b>ID</b>	I/O element ID	Param ID:239
<b>Value</b>	I/O element value	Value:0