

FMB readio



Example (if wrong AVL ID):

Not supported or not enabled IO element requested

Example:

Param ID:239 Value:0

Response details	Description	Example
ID	I/O element ID	Param ID:239
Value	I/O element value	Value:0