

FMC640 Configuration

[Main Page](#) > [EOL Products](#) > [FMC640](#) > **FMC640 Configuration**

Teltonika Configurator

- [Status info](#) **[Show more]**
 - [Device Info](#)
 - [GNSS Info](#)
 - [GSM Info](#)
 - [I/O Info](#)
 - [FMS I/O Info](#)
 - [Tachograph Data Info](#)
 - [Maintenance](#)
 - [LLS Calibration](#)
 - [CAN Adapter Info](#)
- [Security info](#)
- [System settings](#) **[Show more]**
 - [Sleep Mode](#)
 - [System Settings](#)
 - [IO Global Settings](#)
 - [Protocol Settings](#)
 - [Records Settings](#)
 - [Static Navigation Settings](#)
 - [Ignition Source](#)
 - [Time Synchronization Settings](#)
- [GPRS settings](#)
- [Data acquisition settings](#)
- [SMS/Call settings](#) **[Show more]**
 - [SMS commands](#)
 - [Incoming Call settings](#)
 - [Hands Free Call settings](#)
- [SMS events](#)

- [GSM Operators settings](#)
- [Features settings](#) **[Show more]**
 - [Green Driving](#)
 - [Over Speeding](#)
 - [Jamming](#)
 - [DOUT Control via Call](#)
 - [Authorized driving/Immobilizer](#)
 - [iButton read notification](#)
 - [Short burst data settings](#)
- [Accelerometer Features settings](#) **[Show more]**
 - [Accelerometer Calibration](#)
 - [Excessive Idling](#)
 - [Towing Detection](#)
 - [Crash Detection](#)
- [Auto Geofence settings](#)
- [Manual Geofence settings](#)
- [Manual Geofence Zones](#)
- [Trip/Odometer settings](#) **[Show more]**
 - [Trip Settings](#)
 - [Advanced Trip Settings](#)
 - [Odometer](#)
- [iButton List settings](#)
- [I/O settings](#) **[Show more]**
 - [Operands](#)
 - [Avg Const](#)
- [LVCAN, FMS and Tachograph serial I/O](#) **[Show more]**
 - [LVCAN](#)
 - [FMS](#)

- [Tachograph Data](#)

- [Manual CAN IO](#) **[Show more]**
 - [Introduction](#)
 - [General description](#)
 - [Configuration](#)
 - [Example](#)

- [RS232 \ RS485](#) **[Show more]**
 - [RS-485 Interface](#)
 - [RS-232 Interface](#)
 - [LLS Sensor](#)
 - [Garmin protocols](#)

- [CAN \ Tachograph](#) **[Show more]**
 - [CAN \ Tachograph](#)
 - [Tachograph Settings](#)
 - [WEB Tacho Settings](#)
 - [FMS settings](#)

- [ContiPressureCheck](#) **[Show more]**
 - [Description](#)
 - [Configuration](#)
 - [External Links](#)

- [Custom scenarios](#)
- [Mobileye](#) **[Show more]**
 - [Introduction](#)
 - [Physical connection to Mobileye 5 CAN-A port](#)

- [FMB640 device configuration](#)

- [Reefer IO](#)
- [Bluetooth 4.0 Settings](#)
- [Beacon List](#) **[Show more]**
 - [Beacon Settings](#)
 - [Beacon List](#)