

# FMP100 User Interface

[Main Page](#) > [Fast & Easy Trackers](#) > [FMP100](#) > [FMP100 Manual](#) > [FMP100 Configuration](#) > **FMP100 User Interface**



## Contents

- [1 User Interface](#)
- [2 GSM Indication](#)
- [3 GNSS Indication](#)
- [4 Event Indication](#)

## User Interface

In user interface section, you can customize by different needs what kind of indication for the driver should be shown.

For available event indications, the possible configurable options are available to choose:

Column	Description
LED	Possibility to choose indication color between 3 different colors: Red, Green, Blue or none LED indication at all.
Additional Indication	Built in buzzer will be activated with the same configured time periods as LED indication.
Enable In Sleep	<b>Disable</b> - When device in sleep mode, indication will not be showed. <b>Enable</b> - Indication will work while device in sleep mode.
Period (ms)	<b>Disable</b> - Indication will be showed only when event occurs. <b>Enable</b> - indication will be showed by set period time.
Period (ms)	Set in milliseconds after how long the indication should be showed periodically.
On (ms)	Set in milliseconds how long the LED or buzzer will be turned on.
Off (ms)	Set in milliseconds how long the LED or buzzer will be turned off, while doing event indication.
Repeat	Set how many additionally times the event indication should be repeated.

## GSM Indication

There are 3 different available indications related to GSM work:

Indication	Description
GSM Error	When there will be error with GSM signal (no signal) indication will be showed.
GSM Signal Established	Event will be showed when device connects to GSM network.
Outgoing call	Outgoing call in progress.



Note: Periodic part can't be configured and preset needs to be used.

## GNSS Indication

There are 2 different available indication related to GNSS work:

Indication	Description
No GPS Fix	When the GPS Fix is not available, configured indication will be showed.
GPS Fix	When GPS Fix is available, configured indication will be showed.



Note: Periodic part can't be configured and preset needs to be used.

# Event Indication

There are 5 different available indication related to events:

Indication	Description
Sleep mode	Indicates if device is working in sleep mode
Key pressed	Indicates if button was pressed
Private Trip	Indication will be on when Private trip is active
Business Trip	Indication will be on when Business trip is active
Alarm	At Alarm event, indication will be turned on



Note: Some parameter can't be configured and presets needs to be used.