

Template:AWSdebug

Debugging

In the situation when the issue with information upload appears, device internal logs can be taken directly from device configuration software ([instructions](#)), via Terminal.exe by connecting selecting device USB connection port, or by receiving internal logs via FotaWEB in [task section](#).