Template:FMA2 Battery information

Ni-MH battery details.				
Internal back-up battery	Battery voltage (V)	Nominal capacity (mAh)	Power (Wh)	Charging temperature (°C)
Ni-MH Prismatic Battery pack	7.2[]7.5	400	2.95 - 3.07	0 - 50
Battery charging ranges.				
System voltage	(V) Chargin	g range (V)		
6	6.05-8			
12	12.1-16			
24	24.2-32			

FMA2YX internal battery is used for detecting external voltage disconnection.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Battery should not be disposed of with general household waste.

Bring damaged or worn-out batteries to your local recycling center or dispose them to battery recycle bin found in stores.

Warranty: batteries are covered by 6 months warranty support.