

Template:FMC130 manual supported frequency bands table

Product code	Region (operator)	Module name	Supported bands
FMC130 8H ****	EU, MEA	MeiG SLM320-PE1A (jamming detection), TM2500	4G (LTE-FDD): B1 (2100 MHz), B3 (1800 MHz), B5 (850 MHz), B7 (2600 MHz), B8 (900 MHz), B20 (800 MHz) 4G (LTE-TDD): B38 (2600 MHz), B40 (2300 MHz), B41 (2500 MHz) 2G: B2 (1900 MHz), B3 (1800 MHz), B5 (850 MHz), B8 (900 MHz)
FMC130 KY ****	EU, MEA	MeiG SLM320-PE2C (jamming detection), TM2500	4G (LTE-FDD): B1 (2100 MHz), B3 (1800 MHz), B7 (2600 MHz), B8 (900 MHz), B20 (800 MHz), B28(700 MHz) 4G (LTE-TDD): B38 (2600 MHz), B40 (2300 MHz), B41 (2500 MHz) 2G: B2 (1900 MHz), B3 (1800 MHz), B5 (850 MHz), B8 (900 MHz)
FMC130 4O ****	APAC, LATAM	MeiG SLM320-L16A (jamming detection), TM2500	4G (LTE-FDD): B1 (2100 MHz), B2 (1900 MHz), B3 (1800 MHz), B4 (1700 MHz), B5 (850 MHz), B7 (2600 MHz), B8 (900 MHz), B20 (800 MHz), B28(700 MHz) 4G (LTE-TDD): B40 (2300 MHz) 2G: B2 (1900 MHz), B3 (1800 MHz), B5 (850 MHz), B8 (900 MHz)