

Template:FMM640 Operands



Contents

- [1 Operands](#)
 - [1.1 Operand On Exit](#)
 - [1.2 Operand On Entrance](#)
 - [1.3 Operand On Both](#)
 - [1.4 Operand Monitoring](#)
 - [1.5 Operand On Hysteresis](#)
 - [1.6 Operand On Change](#)
 - [1.7 Operand On Delta Change](#)

Operands

Operand On Exit

Record is generated when input value leaves a range between low and high level limits.



Operand On Entrance

Record is generated when input value enters a range between low and high level limits.



Operand On Both

Record is generated by both On Exit and On Entrance operands' logic at same time.




Operand Monitoring

No event at all. Values are recorded only when other triggers worked.



Operand On Hysteresis

Record is generated when input value crosses the high limit value from below the low limit value or vice versa.



Operand On Change

Record is generated when input value changes.



Operand On Delta Change

Record is generated when input value changes and the absolute change becomes equal to or higher than the limit value.

