

Template:FMP1 First start card



Plug and Play tracker with GNSS, GSM and Bluetooth connectivity and cigarette lighter power connector for easy installation.



Contents

- [1 Know your device](#)
- [2 Set up your device](#)
 - [2.1 How to insert Micro-SIM card and connect the battery](#)

Know your device



Set up your device

How to insert Micro-SIM card and connect the battery

1. Insert the SIM tray removal tool into the hole on the SIM card tray and then push until the tray pops out.
2. Split device cover to access battery connector inside.
3. Connect the battery as shown to device.
4. Gently close device cover back.
5. Insert **Nano-SIM** card as shown with **PIN request disabled** or read our Wiki how to enter it later in Teltonika Configurator. Make sure that Nano-SIM card is fitted properly into the tray.
6. Insert the SIM card tray back.
7. After configuration, see see [PC Connection \(Windows\)](#).

Device is ready to be mounted.



Nano-SIM card insertion/removal must be performed when device is powered off -



external voltage and battery are disconnected. Otherwise Nano-SIM card might be damaged or device will not detect it.