

Template:FMX9 First start card



Small and smart tracker with Bluetooth



Contents

- [1 How to insert Micro-SIM card](#)

How to insert Micro-SIM card

1. Gently remove FMB9YX **cover** using **plastic pry tool** from both sides.
2. Insert **Micro-SIM** card as shown with **PIN request disabled** or read [Security info](#) how to enter it later in Configurator. Make sure that Micro-SIM card **cut-off corner** is pointing forward to slot.
3. Attach device **cover** back.
4. Device is ready to be connected.

1. Gently remove FMB9YX **cover** using **plastic pry tool** from both sides.
2. Insert **Micro-SIM** card as shown with **PIN request disabled** or read [Security info](#) how to enter it later in Configurator. Make sure that Micro-SIM card **cut-off corner** is pointing forward to slot.
3. Remove the adhesive tape protection.
4. Place the battery inside the casing of the FMB9YX. Make sure the adhesive tape sticks to the casing.
5. Connect the internal battery to the FMB9YX PCB.
6. Attach device **cover** back. Device is ready to be connected.



Micro-SIM card insertion/removal must be performed when device is powered off -

-  **external voltage and internal battery disconnected. Otherwise Micro-SIM card might be damaged or device will not detect it.**