

Template:FTX8XX/9XX SMS/call settings

SMS Security

Allow to set password, that will be use in SMS

Password — Configure the password that will be required for each SMS

On FTC platform **only a password** will be required **when sending SMS**. If no password is set, messages will be sent with one space in front.

Example of sending getio command (no password):

```
" getio"
```

Example of sending getio command (password:123):

```
"123 getio"
```

```
[[category:{{{model}}} Configuration]]
```