TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Passenger's seat belt | Driver's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Brake pedal position | Vehicle's range on CNG | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Brake pedal position | Vehicle's range on CNG | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Brake pedal position | Vehicle's range on CNG | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Brake pedal position | Vehicle's range on CNG | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery level | * HV battery temperature | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery level | HV battery temperature | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Brake pedal position | * Vehicle's range on CNG | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P Parking | Reverse | Neutral | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | * Total engine work time (dashboard) | * Engine lifetime - (counted) | * Total mileage of the vehicle (dashboard) | * Vehicle mileage - (counted) | * Total fuel consumption | * Total fuel consumption - (counted) | * Fuel level (in percent) | * Fuel level (in liters) | * Engine speed (RPM) | * Engine temperature | * Vehicle speed | * AdBlue level (in percent) | * AdBlue level (in liters) | * Acceleration pedal position | * Engine torque | * Retarder torque | * Distance to service | * Distance exceed service | * Distance after service | * Time to service | * Time exceed service | * Time after service | * Service - distance to next oil service | * Service - time to next oil service | * HV battery temperature | * HV battery level | * Outside temperature | * The amount of spread sand | * Total CNG consumption - (counted) | * CNG level (in percent) | * Vehicle range | * Gross comb. vehicle weight | * Vehicle's range on HV battery | * Vehicle's range on CNG | * Brake pedal position | * Total LNG use - (counted) | * LNG level (in percent) | * Tacho Level 1 |
|---|---|---

[en]=> (ALL-CAN300)

Cars

| | Ignition | Key inserted | Webasto | Engine working | Ready to drive | Engine is working on CNG | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | UCMD SLEEP | Original remote - 3x arm | P | Parking | R | Reverse | N | Neutral | D | Drive | Engine is working on LPG | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Glow plug indicator | Particulate filter (FAP/DPF) | Electronic Power Control | Alarm coolant level | Air filter is plugged | Fuel filter is plugged | Water in fuel | Washer fluid level indicator turned | First front hydraulic | Second front hydraulic | Third front hydraulic | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | The amount of spread sand | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Vehicle's range on HV battery | Vehicle's range on CNG | Brake pedal position | Total LNG use - (counted) | LNG level (in percent) | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Electric cars

| | Ignition | Key inserted | Engine working | Ready to drive | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Electronic Power Control | Alarm coolant level | Fuel filter is plugged | Washer fluid level indicator turned | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Acceleration pedal position | Engine torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | Vehicle range | Vehicle's range on HV battery |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Electric cars

| | Ignition | Key inserted | Engine working | Ready to drive | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Electronic Power Control | Alarm coolant level | Fuel filter is plugged | Washer fluid level indicator turned | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Acceleration pedal position | Engine torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | Vehicle range | Vehicle's range on HV battery |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Electric cars

| | Ignition | Key inserted | Engine working | Ready to drive | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Electronic Power Control | Alarm coolant level | Fuel filter is plugged | Washer fluid level indicator turned | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Acceleration pedal position | • Engine torque | • Distance to service | • Distance exceed service | • Distance after service | • Time to service | • Time exceed service | • Time after service | • Service - distance to next oil service | • Service - time to next oil service | • HV battery temperature | • HV battery level | • Outside temperature | • Vehicle range | • Vehicle's range on HV battery |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Electric cars

| | Ignition | Key inserted | Engine working | Ready to drive | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Rear left door | Rear right door | Trunk cover | Engine cover (Hood) | Charging cable connected | HV battery charging | Electric engine working | Central locking status | Status of the car locked with the factory remote control | Factory alarm | Alarm | Original remote - CLOSE | Original remote - OPEN | The original remote control of the Car - REARM | The original remote control of the car - OPEN TRUNK | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Driver's seat belt | Passenger's seat belt | Left rear seat belt | Right rear seat belt | Middle rear seat belt | Passenger's presence | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | AIRBAG | Electronic Power Steering System (EPS) | Warning | Lights failure | Low tire pressure | Wear of brake pads | Low fuel | Maintenance required | Electronic Power Control | Alarm coolant level | Fuel filter is plugged | Washer fluid level indicator turned | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Acceleration pedal position | Engine torque | Distance to service | Distance exceed service | Distance after service | Time to service | Time exceed service | Time after service | Service - distance to next oil service | Service - time to next oil service | HV battery temperature | HV battery level | Outside temperature | Vehicle range | Vehicle's range on HV battery |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | • Total engine work time (dashboard) | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Axle 1 load | • Axle 2 load | • Axle 3 load | • Axle 4 load | • Axle 5 load | • Fuel rate | • AdBlue level (in percent) | • Acceleration pedal position | • Engine torque | • Retarder torque | • Distance to service | • Distance exceed service | • Time to service | • Time exceed service | • Outside temperature | • Battery voltage | • Cargo weight | • Total CNG use | • Total CNG consumption - (counted) | • CNG level (in percent) | • Vehicle range | • Gross comb. vehicle weight | • Brake pedal position | • CNG level (in bars) | • Engine work time on CNG | • Total LNG use | • Total LNG use - (counted) | • LNG level (in percent) | • Engine work time on primary fuel since gas system has been installed | • Engine work time on dual fuel since gas system has been installed | • Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Time to service | Time exceed service | Outside temperature | Battery voltage | Cargo weight | Total CNG use | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Brake pedal position | CNG level (in bars) | Engine work time on CNG | Total LNG use | Total LNG use - (counted) | LNG level (in percent) | Engine work time on primary fuel since gas system has been installed | Engine work time on dual fuel since gas system has been installed | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | • Total engine work time (dashboard) | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Axle 1 load | • Axle 2 load | • Axle 3 load | • Axle 4 load | • Axle 5 load | • Fuel rate | • AdBlue level (in percent) | • Acceleration pedal position | • Engine torque | • Retarder torque | • Distance to service | • Distance exceed service | • Time to service | • Time exceed service | • Outside temperature | • Battery voltage | • Cargo weight | • Total CNG use | • Total CNG consumption - (counted) | • CNG level (in percent) | • Vehicle range | • Gross comb. vehicle weight | • Brake pedal position | • CNG level (in bars) | • Engine work time on CNG | • Total LNG use | • Total LNG use - (counted) | • LNG level (in percent) | • Engine work time on primary fuel since gas system has been installed | • Engine work time on dual fuel since gas system has been installed | • Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Time to service | Time exceed service | Outside temperature | Battery voltage | Cargo weight | Total CNG use | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Brake pedal position | CNG level (in bars) | Engine work time on CNG | Total LNG use | Total LNG use - (counted) | LNG level (in percent) | Engine work time on primary fuel since gas system has been installed | Engine work time on dual fuel since gas system has been installed | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | • Total engine work time (dashboard) | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Axle 1 load | • Axle 2 load | • Axle 3 load | • Axle 4 load | • Axle 5 load | • Fuel rate | • AdBlue level (in percent) | • Acceleration pedal position | • Engine torque | • Retarder torque | • Distance to service | • Distance exceed service | • Time to service | • Time exceed service | • Outside temperature | • Battery voltage | • Cargo weight | • Total CNG use | • Total CNG consumption - (counted) | • CNG level (in percent) | • Vehicle range | • Gross comb. vehicle weight | • Brake pedal position | • CNG level (in bars) | • Engine work time on CNG | • Total LNG use | • Total LNG use - (counted) | • LNG level (in percent) | • Engine work time on primary fuel since gas system has been installed | • Engine work time on dual fuel since gas system has been installed | • Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | • Total engine work time (dashboard) | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Axle 1 load | • Axle 2 load | • Axle 3 load | • Axle 4 load | • Axle 5 load | • Fuel rate | • AdBlue level (in percent) | • Acceleration pedal position | • Engine torque | • Retarder torque | • Distance to service | • Distance exceed service | • Time to service | • Time exceed service | • Outside temperature | • Battery voltage | • Cargo weight | • Total CNG use | • Total CNG consumption - (counted) | • CNG level (in percent) | • Vehicle range | • Gross comb. vehicle weight | • Brake pedal position | • CNG level (in bars) | • Engine work time on CNG | • Total LNG use | • Total LNG use - (counted) | • LNG level (in percent) | • Engine work time on primary fuel since gas system has been installed | • Engine work time on dual fuel since gas system has been installed | • Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Time to service | Time exceed service | Outside temperature | Battery voltage | Cargo weight | Total CNG use | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Brake pedal position | CNG level (in bars) | Engine work time on CNG | Total LNG use | Total LNG use - (counted) | LNG level (in percent) | Engine work time on primary fuel since gas system has been installed | Engine work time on dual fuel since gas system has been installed | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Time to service | Time exceed service | Outside temperature | Battery voltage | Cargo weight | Total CNG use | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Brake pedal position | CNG level (in bars) | Engine work time on CNG | Total LNG use | Total LNG use - (counted) | LNG level (in percent) | Engine work time on primary fuel since gas system has been installed | Engine work time on dual fuel since gas system has been installed | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | • Total engine work time (dashboard) | • Engine lifetime - (counted) | • Total mileage of the vehicle (dashboard) | • Vehicle mileage - (counted) | • Total fuel consumption | • Total fuel consumption - (counted) | • Fuel level (in percent) | • Fuel level (in liters) | • Engine speed (RPM) | • Engine temperature | • Vehicle speed | • Axle 1 load | • Axle 2 load | • Axle 3 load | • Axle 4 load | • Axle 5 load | • Fuel rate | • AdBlue level (in percent) | • Acceleration pedal position | • Engine torque | • Retarder torque | • Distance to service | • Distance exceed service | • Time to service | • Time exceed service | • Outside temperature | • Battery voltage | • Cargo weight | • Total CNG use | • Total CNG consumption - (counted) | • CNG level (in percent) | • Vehicle range | • Gross comb. vehicle weight | • Brake pedal position | • CNG level (in bars) | • Engine work time on CNG | • Total LNG use | • Total LNG use - (counted) | • LNG level (in percent) | • Engine work time on primary fuel since gas system has been installed | • Engine work time on dual fuel since gas system has been installed | • Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Trucks

| | Ignition | Key inserted | Webasto | Engine working | Engine is working on CNG | Vehicle working mode | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Front left door | Front right door | Central locking status | Status of the car locked with the factory remote control | Alarm | Original remote - CLOSE | Original remote - OPEN | Original remote - 3x arm | Parking | Reverse | Neutral | Drive | Engine is working on dual fuel | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | AC turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | ABS | Electronics Stability Control (ESP) | Electronic stability program off (ESP OFF) | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Warning | Low fuel | Glow plug indicator | Rear PTO turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | Retarder torque | Distance to service | Distance exceed service | Time to service | Time exceed service | Outside temperature | Battery voltage | Cargo weight | Total CNG use | Total CNG consumption - (counted) | CNG level (in percent) | Vehicle range | Gross comb. vehicle weight | Brake pedal position | CNG level (in bars) | Engine work time on CNG | Total LNG use | Total LNG use - (counted) | LNG level (in percent) | Engine work time on primary fuel since gas system has been installed | Engine work time on dual fuel since gas system has been installed | Tacho Level 1 |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Buses

	Ignition	Key inserted	Webasto	Engine working	Vehicle working mode	Handbrake	Footbrake	Clutch	Front left door	Front right door	Rear left door	Rear right door	Status of the car locked with the factory remote control	Alarm	Original remote - CLOSE	Original remote - OPEN	Original remote - 3x arm	Parking	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Rear fog lights	Front fog lights	Cruise	Automatic retarder	Manual retarder	Driver's seat belt	CHECK ENGINE (MIL)	Oil pressure / level	Coolant temperature / level	Battery charging	Handbrake system	Low fuel	Glow plug indicator	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	Axle 1 load	Axle 2 load	Axle 3 load	Axle 4 load	Axle 5 load	Fuel rate	AdBlue level (in percent)	AdBlue level (in liters)	Acceleration pedal position	Engine torque	Retarder torque	Outside temperature	Cargo weight	Gross comb. vehicle weight	Brake pedal position	Tacho Level 1
															REMOTE	REMOTE	REMOTE 3x	P	R	N	D							AUTO	MANUAL									•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
1) GOLAZ 525110 VOYAGE (EURO 5)																										year: 2012=>										program № 11221																															from 2019-03-18																		

[en]=> (ALL-CAN300)

Buses

	Ignition	Key inserted	Webasto	Engine working	Vehicle working mode	Handbrake	Footbrake	Clutch	Front left door	Front right door	Rear left door	Rear right door	Status of the car locked with the factory remote control	Alarm	Original remote - CLOSE	Original remote - OPEN	Original remote - 3x arm	Parking	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Rear fog lights	Front fog lights	Cruise	Automatic retarder	Manual retarder	Driver's seat belt	CHECK ENGINE (MIL)	Oil pressure / level	Coolant temperature / level	Battery charging	Handbrake system	Low fuel	Glow plug indicator	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	Axle 1 load	Axle 2 load	Axle 3 load	Axle 4 load	Axle 5 load	Fuel rate	AdBlue level (in percent)	AdBlue level (in liters)	Acceleration pedal position	Engine torque	Retarder torque	Outside temperature	Cargo weight	Gross comb. vehicle weight	Brake pedal position	Tacho Level 1
															REMOTE	REMOTE	REMOTE 3x	P	R	N	D							AUTO	MANUAL								•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
16) MAN LION'S CITY (EURO 4)																											year: **2005=>**										program № **11219**																															from **2017-09-01**																		

[en]=> (ALL-CAN300)

Buses

	Ignition	Key inserted	Webasto	Engine working	Vehicle working mode	Handbrake	Footbrake	Clutch	Front left door	Front right door	Rear left door	Rear right door	Status of the car locked with the factory remote control	Alarm	Original remote - CLOSE	Original remote - OPEN	Original remote - 3x arm	Parking	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Rear fog lights	Front fog lights	Cruise	Automatic retarder	Manual retarder	Driver's seat belt	CHECK ENGINE (MIL)	Oil pressure / level	Coolant temperature / level	Battery charging	Handbrake system	Low fuel	Glow plug indicator	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	Axle 1 load	Axle 2 load	Axle 3 load	Axle 4 load	Axle 5 load	Fuel rate	AdBlue level (in percent)	AdBlue level (in liters)	Acceleration pedal position	Engine torque	Retarder torque	Outside temperature	Cargo weight	Gross comb. vehicle weight	Brake pedal position	Tacho Level 1
															REMOTE	REMOTE	REMOTE 3x	P	R	N	D							AUTO	MANUAL									•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
31) MERCEDES TOURISMO O 350 (EURO 3)																											year: **2003=>**									program № **11148**																															from **2020-10-15**																		

[en]=> (ALL-CAN300)

Buses

	Ignition	Key inserted	Webasto	Engine working	Vehicle working mode	Handbrake	Footbrake	Clutch	Front left door	Front right door	Rear left door	Rear right door	Status of the car locked with the factory remote control	Alarm	Original remote - CLOSE	Original remote - OPEN	Original remote - 3x arm	Parking	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Rear fog lights	Front fog lights	Cruise	Automatic retarder	Manual retarder	Driver's seat belt	CHECK ENGINE (MIL)	Oil pressure / level	Coolant temperature / level	Battery charging	Handbrake system	Low fuel	Glow plug indicator	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	Axle 1 load	Axle 2 load	Axle 3 load	Axle 4 load	Axle 5 load	Fuel rate	AdBlue level (in percent)	AdBlue level (in liters)	Acceleration pedal position	Engine torque	Retarder torque	Outside temperature	Cargo weight	Gross comb. vehicle weight	Brake pedal position	Tacho Level 1
															REMOTE	REMOTE	REMOTE 3x	P	R	N	D							AUTO	MANUAL								•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
46) SETRA S417 GT-HD (EURO 5)																											year: **2009=>**									program № **11467**																															from **2020-10-15**																		

[en]=> (ALL-CAN300)

Buses

	Ignition	Key inserted	Webasto	Engine working	Vehicle working mode	Handbrake	Footbrake	Clutch	Front left door	Front right door	Rear left door	Rear right door	Status of the car locked with the factory remote control	Alarm	Original remote - CLOSE	Original remote - OPEN	Original remote - 3x arm	Parking	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Rear fog lights	Front fog lights	Cruise	Automatic retarder	Manual retarder	Driver's seat belt	CHECK ENGINE (MIL)	Oil pressure / level	Coolant temperature / level	Battery charging	Handbrake system	Low fuel	Glow plug indicator	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	Axle 1 load	Axle 2 load	Axle 3 load	Axle 4 load	Axle 5 load	Fuel rate	AdBlue level (in percent)	AdBlue level (in liters)	Acceleration pedal position	Engine torque	Retarder torque	Outside temperature	Cargo weight	Gross comb. vehicle weight	Brake pedal position	Tacho Level 1
	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
61) VDL FUTURA FHD (EURO 4)	year: **2007=>**																																			program № **11551**									from **2019-03-18**																			
	+	+		+		+	+			+									+			+	+	+			+											+	+	+	+	+	+	+	+	+	+						+		+	+				+	+	+
62) VOLVO 9700 (EURO 5)	year: **2009=>**																																			program № **11494**									from **2017-09-01**																			
	+			+		+	+											+	+			+		+			+											+	+	+	+	+		+	+	+	+								+	+						
63) VOLVO 9700 (EURO 5) (TACHO SIMPLE)	year: **2009=>**																																			program № **11494**									from **2019-03-18**																			
	+			+																							+											+	+	+		+		+	+											+						+
64) VOLVO B12B	year: **2003=>**																																			program № **12248**									from **2018-03-06**																			
	+			+		+	+												+																				+		+			+	+		+									+	+						
65) VOLVO UNVI URBIS 2.5DD B9 TL	year: **2013=>**																																			program № **11617**									from **2017-09-01**																			
	+			+	+	+	+											+	+					+			+												+	+	+				+	+	+	+	+					+		+	+					+	
66) YUTONG ZK6122H9	year: **2016=>**																																			program № **12469**									from **2018-09-19**																			
	+			+	+	+	+	+												+				+	+		+	+											+	+	+	+	+		+	+	+							+		+	+			+			
67) ZAZ A10C	year: **2018=>**																																			program № **12443**									from **2018-08-27**																			
	+			+	+																																	+		+		+		+	+	+							+		+	+			+			
68) ZAZ A10C	year: **2013=>**																																			program № **12444**									from **2018-09-04**																			
	+			+	+																																+	+	+	+	+	+		+	+	+						+			+	+		+				

+	This parameter is available depending on vehicle's equipment
+	This parameter is available on the client's request
+	This parameter is available depending on vehicle's VIN number
[+]	This parameter may be unavailable using P400 or U400 contactless reader

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery - Grain harvester

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | AC turned on | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Low fuel | Maintenance required | Oil filter of engine is plugged | Alarm oil pressure in engine | Engine oil temperature too high | Alarm coolant level | Drain filter in is plugged | Low hydraulic system pressure | Low hydraulic oil level | Too high hydraulic system oil temp. | Overflow chamber of hydraulic unit | Air filter is plugged | Fuel filter is plugged | Water in fuel | Filter of brakes system is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Cleaning fan control turned off | Threshing drum control turned off | Straw walker is plugged | Excessive clearance under the threshing drum | Feeder belt turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Grain mown volume | Grain moisture | Acceleration pedal position | Engine torque | Threshing drum RPM | Gap under threshing drum | Outside temperature | Battery voltage |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery - Grain harvester

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | AC turned on | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Low fuel | Maintenance required | Oil filter of engine is plugged | Alarm oil pressure in engine | Engine oil temperature too high | Alarm coolant level | Drain filter in is plugged | Low hydraulic system pressure | Low hydraulic oil level | Too high hydraulic system oil temp. | Overflow chamber of hydraulic unit | Air filter is plugged | Fuel filter is plugged | Water in fuel | Filter of brakes system is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Cleaning fan control turned off | Threshing drum control turned off | Straw walker is plugged | Excessive clearance under the threshing drum | Feeder belt turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Grain mown volume | Grain moisture | Acceleration pedal position | Engine torque | Threshing drum RPM | Gap under threshing drum | Outside temperature | Battery voltage |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery - Grain harvester

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | AC turned on | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Low fuel | Maintenance required | Oil filter of engine is plugged | Alarm oil pressure in engine | Engine oil temperature too high | Alarm coolant level | Drain filter in is plugged | Low hydraulic system pressure | Low hydraulic oil level | Too high hydraulic system oil temp. | Overflow chamber of hydraulic unit | Air filter is plugged | Fuel filter is plugged | Water in fuel | Filter of brakes system is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Cleaning fan control turned off | Threshing drum control turned off | Straw walker is plugged | Excessive clearance under the threshing drum | Feeder belt turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Grain mown volume | Grain moisture | Acceleration pedal position | Engine torque | Threshing drum RPM | Gap under threshing drum | Outside temperature | Battery voltage |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery - Grain harvester

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | AC turned on | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Handbrake system | Low fuel | Maintenance required | Oil filter of engine is plugged | Alarm oil pressure in engine | Engine oil temperature too high | Alarm coolant level | Drain filter in is plugged | Low hydraulic system pressure | Low hydraulic oil level | Too high hydraulic system oil temp. | Overflow chamber of hydraulic unit | Air filter is plugged | Fuel filter is plugged | Water in fuel | Filter of brakes system is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Cleaning fan control turned off | Threshing drum control turned off | Straw walker is plugged | Excessive clearance under the threshing drum | Feeder belt turned on | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Grain mown volume | Grain moisture | Acceleration pedal position | Engine torque | Threshing drum RPM | Gap under threshing drum | Outside temperature | Battery voltage |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 70% full | Grain tank is 100% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 70% full | Grain tank is 100% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in liters) | Fuel level (in percent) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 70% full | Grain tank is 100% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | Number of bale pieces | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

[en]=> (ALL-CAN300)

Agricultural machinery

| | Ignition | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | CHECK ENGINE (MIL) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Lights failure | Low fuel | Maintenance required | Engine oil temperature too high | Alarm coolant level | Low hydraulic system pressure | Low hydraulic oil level | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Front TPL turned on | Rear TPH turned on | Front PTO turned on | Rear PTO turned on | Mowing | Threshing | Grain release from hopper | Grain tank is 100% full | Grain tank is 70% full | Grain tank is open | Unloading tube pivot is in idle position | Spreading turned on | Liquid pump turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | AdBlue level (in percent) | Harvesting time | Harvested area | Mowing efficiency | Acceleration pedal position | Engine torque | Threshing drum RPM | Time to service | Outside temperature | Battery voltage | Gross comb. vehicle weight | The total amount of bales | Number of bales | Number of cut bales | The number of bale pieces | Total treated area | Level of liquid in tank | Spray pressure | Actual dose | Area that can be treated until tank is empty | Distance remaining until tank is empty | Rear PTO rotational speed | Front PTO rotational speed |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Construction machinery

| | Ignition | Webasto | Engine working | Vehicle working mode | No operator! | Handbrake | Footbrake | Clutch | Status of the hazard warning lights switch | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Rear fog lights | Front fog lights | Front light ON | Rear light ON | Light signal turned on | AC turned on | Cruise | Driver's seat belt | CHECK ENGINE (MIL) | Electronic stability program off (ESP OFF) | STOP | Oil pressure / level | Coolant temperature / level | Battery charging | Warning | Low fuel | Maintenance required | Glow plug indicator | Alarm oil pressure in engine | Engine oil temperature too high | Drain filter in is plugged | Low hydraulic oil level | Too high hydraulic system oil temp. | Air filter is plugged | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Fuel level (in liters) | Engine speed (RPM) | Engine temperature | Vehicle speed | Fuel rate | AdBlue level (in percent) | Acceleration pedal position | Engine torque | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Outside temperature | Drill RPM | Battery voltage | Cargo weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Forest machinery

	Ignition	Engine working	Vehicle working mode	Handbrake	Footbrake	Front left door	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Front light ON	Right joystick moved right	Right joystick moved left	Right joystick moved front	Right joystick moved back	Left joystick moved right	Left joystick moved left	Left joystick moved front	Left joystick moved back	First front hydraulic	Second front hydraulic	Third front hydraulic	Fourth front hydraulic	Permission to work hydraulics	Total engine work time (dashboard)	Engine lifetime - (counted)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	AdBlue level (in percent)	Acceleration pedal position	Engine torque	Outside temperature
	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
1) JOHN DEERE 1010D (Forwarder)																								year: **2008=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
2) JOHN DEERE 1010D (Forwarder)																								year: **2003=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
3) JOHN DEERE 1010E (Forwarder)																								year: **2009=>**									program № **11441**					from **2017-09-01**
	+	+		+	+																						+	+	+	+	+	+	+	+	+		+	+	
4) JOHN DEERE 1070D (Harvester)																								year: **2007=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
5) JOHN DEERE 1070E (Harvester)																								year: **2009=>**									program № **11441**					from **2017-09-01**
	+	+		+	+																						+	+	+	+	+	+	+	+	+		+	+	
6) JOHN DEERE 1210E (Forwarder)																								year: **2009=>**									program № **11441**					from **2017-09-01**
	+	+		+	+																						+	+	+	+	+	+	+	+	+		+	+	
7) JOHN DEERE 1270D (Harvester)																								year: **2006=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
8) JOHN DEERE 1270G (Harvester)																								year: **2016=>**									program № **12912**					from **2020-02-06**
	+	+	+	+			+	+	+	+	+	+	+	+	+	+	+	+	+	+	+						+	+		+	+	+	+	+			+	+	
9) JOHN DEERE 1490D (Harvester)																								year: **2008=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
10) JOHN DEERE 1510G (Forwarder)																								year: **2018=>**									program № **12913**					from **2020-02-06**
	+	+	+	+			+	+	+	+	+	+	+	+	+	+	+	+	+	+	+						+	+		+	+	+	+	+			+	+	
11) JOHN DEERE 770D (Harvester)																								year: **2006=>**									program № **11329**					from **2017-09-01**
	+	+		+																							+	+	+	+	+	+	+	+	+				
12) KOMATSU 845 (Forwarder)																								year: **2016=>**									program № **12466**					from **2018-09-19**
	+	+	+	+		+	+	+	+					+	+	+	+	+	+	+	+	+	+	+	+		+	+	+	+	+		+	+	+	+	+	+	+
13) KOMATSU 855 (Forwarder)																								year: **2017=>**									program № **12467**					from **2018-09-19**
	+	+	+	+		+	+	+	+					+	+	+	+	+	+	+	+				+	+	+	+	+	+	+		+	+	+	+	+	+	+
14) KOMATSU 860.4 (Forwarder)																								year: **2008=>**									program № **11839**					from **2017-09-01**
	+	+		+																							+	+		+	+		+	+				+	
15) KOMATSU 865 (Forwarder)																								year: **2012=>**									program № **12468**					from **2018-09-19**
	+	+	+	+		+	+	+	+					+	+	+	+	+	+	+	+	+	+	+	+		+	+	+	+	+		+	+	+	+	+	+	+
16) KOMATSU 890.3 (Forwarder)																								year: **2006=>**									program № **11839**					from **2017-09-01**
	+	+																									+	+		+	+		+	+				+	
17) KOMATSU 911.5 (Harvester)																								year: **2011=>**									program № **11839**					from **2017-09-01**
	+	+		+			+	+																			+	+		+	+	+	+	+			+		

[en]=> (ALL-CAN300)

Forest machinery

	Ignition	Engine working	Vehicle working mode	Handbrake	Footbrake	Front left door	Reverse	Neutral	Drive	Parking lights	Dipped headlights	Full beam headlights	Front light ON	Right joystick moved right	Right joystick moved left	Right joystick moved front	Right joystick moved back	Left joystick moved right	Left joystick moved left	Left joystick moved front	Left joystick moved back	First front hydraulic	Second front hydraulic	Third front hydraulic	Fourth front hydraulic	Permission to work hydraulics	Total engine work time (dashboard)	Engine lifetime - (counted)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	AdBlue level (in percent)	Acceleration pedal position	Engine torque	Outside temperature
				P			R	N	D					R	R	R	R	L	L	L	L	F1	F2	F3	F4		•	•	•	•	•	•	•	•	•	•	•	•	•
18) KOMATSU 931.1 (Harvester)																								year: **2011=>**									program № **11839**						from **2017-09-01**
	+	+		+			+	+																			+	+		+	+	+	+	+			+		
19) PRIME TECH PT 300 (Mulcher)																								year: **2012=>**									program № **11442**						from **2017-09-01**
	+	+																									+	+		+	+		+	+			+		
20) SAMPO ROSENLEW SR 1046X (Harvester)																								year: **2006=>**									program № **11442**						from **2017-09-01**
	+	+																									+	+		+	+		+	+					
21) VALMET 840.3 (Forwarder)																								year: **2006=>**									program № **11442**						from **2017-09-01**
	+	+																									+	+		+	+		+	+					

+	This parameter is available depending on vehicle's equipment
+	This parameter is available on the client's request
+	This parameter is available depending on vehicle's VIN number
+	This parameter may be unavailable using P400 or U400 contactless reader

[en]=> (ALL-CAN300)

Utility machinery

	Ignition	Key inserted	Engine working	Standalone engine working	Vehicle working mode	Handbrake	Footbrake	Parking	Reverse	Drive	Rear fog lights	Light signal turned on	Automatic retarder	Oil pressure / level	Battery charging	Right joystick moved right	Right joystick moved left	Right joystick moved front	Right joystick moved back	Left joystick moved right	Left joystick moved left	Left joystick moved front	Left joystick moved back	First rear hydraulic	First front hydraulic	Spreading turned on	Chemistry supply turned on	Feeder belt turned on	Driving wheel lifted	Brushes turned on	Vacuum cleaner	Water supply turned on	High pressure washer (Karcher)	Unloading from the hopper	Low salt (sand) level	Low water level	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	AdBlue level (in percent)	Acceleration pedal position	Engine torque	The amount of spread salt per square meter	The amount of spread fine-grained salt	The amount of spread coarse-grained salt	The amount of spread DiMix	The amount of spread coarse-grained calcium	The amount of spread calcium chloride	The amount of spread sodium chloride	The amount of spread magnesium chloride	The amount of spread gravel	The amount of spread sand	Spread width to the left	Spread width to the right	Salt spreader work hours	Distance covered during salting
1) BUCHER CityCat 1000 (Sweeper) year: **2008=>** program № **11471** from **2017-09-01**	+		+		+			+	+	+																				+	+			+				+																										
2) BUCHER CityCat 2020 (Sweeper) year: **2008=>** program № **11469** from **2017-09-01**	+		+			+	+		+					+	+	+	+	+	+												+		+	+				+		+				+	+	+	+		+															
3) BUCHER CityFant 6 (Sweeper) year: **2011=>** program № **11477** from **2017-09-01**	+		+		+											+	+	+	+											+	+	+		+				+						+																				
4) BUCHER CityFant 6000 (Sweeper) year: **2011=>** program № **11477** from **2017-09-01**	+		+		+											+	+	+	+											+	+	+		+				+						+																				
5) BUCHER GILETTA UH 5000 EcoSat Controller (Salt sweeper) year: **2016=>** program № **12178** from **2018-01-02**	+		+									+														+												+																											
6) BUCHER OPTIFANT 8000 (Sweeper) year: **2017=>** program № **12127** from **2017-09-07**	+		+									+				+	+	+	+											+	+	+		+				+				+	+	+	+				+															
7) BUCHER SH7042 Ecos Controller (Salt sweeper) year: **2017=>** program № **12179** from **2018-01-02**	+		+									+														+												+																											
8) GILETTA CL 10.45 (A/ID) (Brine Spreader) year: **2010=>** program № **11476** from **2017-09-01**	+																															+				+		+																											
9) GILETTA CL 10.45 (A/D) (Brine Spreader) year: **2010=>** program № **11476** from **2017-09-01**	+			+																												+				+		+																											
10) GILETTA CL 8.37 (A/D) (Brine Spreader) year: **2010=>** program № **11476** from **2017-09-01**	+		+																													+				+		+																											
11) GILETTA KS 4000 (ID) (Brine Spreader) year: **2007=>** program № **11476** from **2017-09-01**	+			+								+														+							+			+	+		+																											
12) GILETTA UH 3000 (A/D) (Salt Spreader) year: **2010=>** program № **11476** from **2017-09-01**	+																									+										+		+																											
13) GILETTA UH 3000 (ID) (Salt Spreader) year: **2007=>** program № **11664** from **2017-09-01**	+											+														+	+																								+									+	+				
14) HOLDER S990 GMEINER HUSKI 1100VFS (Salt Spreader) year: **2010=>** program № **11473** from **2017-09-01**	+				+											+	+	+	+					+	+	+										+																													
15) JOHNSTON CN201 (Sweeper) year: **2012=>** program № **11483** from **2017-09-01**	+		+			+	+	+	+							+	+	+	+											+	+	+		+				+		+					+		+		+															
16) JOHNSTON VT501/VS501 (Sweeper) year: **2013=>** program № **11484** from **2017-09-01**	+		+		+											+	+	+	+											+	+	+		+				+						+																				
17) JOHNSTON VT651/VS651 (Sweeper) year: **2013=>** program № **11484** from **2017-09-01**	+		+		+											+	+	+	+											+	+	+		+				+						+																				

[en]=> (ALL-CAN300)

Utility machinery

	Ignition	Key inserted	Engine working	Standalone engine working	Vehicle working mode	Handbrake	Footbrake	Parking	Reverse	Drive	Rear fog lights	Light signal turned on	Automatic retarder	Oil pressure / level	Battery charging	Right joystick moved right	Right joystick moved left	Right joystick moved front	Right joystick moved back	Left joystick moved right	Left joystick moved left	Left joystick moved front	Left joystick moved back	First rear hydraulic	First front hydraulic	Spreading turned on	Chemistry supply turned on	Feeder belt turned on	Driving wheel lifted	Brushes turned on	Vacuum cleaner	Water supply turned on	High pressure washer (Karcher)	Unloading from the hopper	Low salt (sand) level	Low water level	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	AdBlue level (in percent)	Acceleration pedal position	Engine torque	The amount of spread salt per square meter	The amount of spread fine-grained salt	The amount of spread coarse-grained salt	The amount of spread DiMix	The amount of spread coarse-grained calcium	The amount of spread calcium chloride	The amount of spread sodium chloride	The amount of spread magnesium chloride	The amount of spread gravel	The amount of spread sand	Spread width to the left	Spread width to the right	Salt spreader work hours	Distance covered during salting
18) JOHNSTON VT801/VS801 (Sweeper)																										year: **2013=>**												program № **11484**																		

[en]=> (ALL-CAN300)

Utility machinery

	Ignition	Key inserted	Engine working	Standalone engine working	Vehicle working mode	Handbrake	Footbrake	Parking	Reverse	Drive	Rear fog lights	Light signal turned on	Automatic retarder	Oil pressure / level	Battery charging	Right joystick moved right	Right joystick moved left	Right joystick moved front	Right joystick moved back	Left joystick moved right	Left joystick moved left	Left joystick moved front	Left joystick moved back	First rear hydraulic	First front hydraulic	Spreading turned on	Chemistry supply turned on	Feeder belt turned on	Driving wheel lifted	Brushes turned on	Vacuum cleaner	Water supply turned on	High pressure washer (Karcher)	Unloading from the hopper	Low salt (sand) level	Low water level	Total engine work time (dashboard)	Engine lifetime - (counted)	Total mileage of the vehicle (dashboard)	Vehicle mileage - (counted)	Total fuel consumption	Total fuel consumption - (counted)	Fuel level (in percent)	Engine speed (RPM)	Engine temperature	Vehicle speed	AdBlue level (in percent)	Acceleration pedal position	Engine torque	The amount of spread salt per square meter	The amount of spread fine-grained salt	The amount of spread coarse-grained salt	The amount of spread DiMix	The amount of spread coarse-grained calcium	The amount of spread calcium chloride	The amount of spread sodium chloride	The amount of spread magnesium chloride	The amount of spread gravel	The amount of spread sand	Spread width to the left	Spread width to the right	Salt spreader work hours	Distance covered during salting

TELTONIKA

[en]=> (ALL-CAN300)

Special machinery

| | Ignition | Key inserted | Engine working | Vehicle working mode | No operator! | Interlock system | Handbrake | Footbrake | Status of the hazard warning lights switch | Front left door | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | Oil pressure / level | Coolant temperature / level | Battery charging | Glow plug indicator | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Spreading turned on | Liquid pump turned on | Chemicals | Compressor | Water valve | Cabin up | Cabin down | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Time to service | HV battery level | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Height of the arm above the ground | Level of water for fire fighting | Level of fire fighting foam | Pressure in fire fighting pump | Wind speed | Outside temperature | The amount of spread salt per square meter | Battery voltage | Spread width to the left | Spread width to the right | Cargo weight | Gross comb. vehicle weight | Brake pedal position |
|---|---|---

TELTONIKA

[en]=> (ALL-CAN300)

Special machinery

| | Ignition | Key inserted | Engine working | Vehicle working mode | No operator! | Interlock system | Handbrake | Footbrake | Status of the hazard warning lights switch | Front left door | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | Oil pressure / level | Coolant temperature / level | Battery charging | Glow plug indicator | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Spreading turned on | Liquid pump turned on | Chemicals | Compressor | Water valve | Cabin up | Cabin down | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Time to service | HV battery level | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Height of the arm above the ground | Level of water for fire fighting | Level of fire fighting foam | Pressure in fire fighting pump | Wind speed | Outside temperature | The amount of spread salt per square meter | Battery voltage | Spread width to the left | Spread width to the right | Cargo weight | Gross comb. vehicle weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Special machinery

| | Ignition | Key inserted | Engine working | Vehicle working mode | No operator! | Interlock system | Handbrake | Footbrake | Status of the hazard warning lights switch | Front left door | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | Oil pressure / level | Coolant temperature / level | Battery charging | Glow plug indicator | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Spreading turned on | Liquid pump turned on | Chemicals | Compressor | Water valve | Cabin up | Cabin down | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Time to service | HV battery level | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Height of the arm above the ground | Level of water for fire fighting | Level of fire fighting foam | Pressure in fire fighting pump | Wind speed | Outside temperature | The amount of spread salt per square meter | Battery voltage | Spread width to the left | Spread width to the right | Cargo weight | Gross comb. vehicle weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Special machinery

| | Ignition | Key inserted | Engine working | Vehicle working mode | No operator! | Interlock system | Handbrake | Footbrake | Status of the hazard warning lights switch | Front left door | Parking | Reverse | Neutral | Drive | Parking lights | Dipped headlights | Full beam headlights | Front light ON | Rear light ON | Light signal turned on | Cruise | Automatic retarder | Manual retarder | Driver's seat belt | CHECK ENGINE (MIL) | Oil pressure / level | Coolant temperature / level | Battery charging | Glow plug indicator | Right joystick moved right | Right joystick moved left | Right joystick moved front | Right joystick moved back | Left joystick moved right | Left joystick moved left | Left joystick moved front | Left joystick moved back | First rear hydraulic | Second rear hydraulic | Third rear hydraulic | Fourth rear hydraulic | First front hydraulic | Second front hydraulic | Third front hydraulic | Fourth front hydraulic | Rear PTO turned on | Spreading turned on | Liquid pump turned on | Chemicals | Compressor | Water valve | Cabin up | Cabin down | Permission to work hydraulics | Total engine work time (dashboard) | Engine lifetime - (counted) | Total mileage of the vehicle (dashboard) | Vehicle mileage - (counted) | Total fuel consumption | Total fuel consumption - (counted) | Fuel level (in percent) | Engine speed (RPM) | Engine temperature | Vehicle speed | Axle 1 load | Axle 2 load | Axle 3 load | Axle 4 load | Axle 5 load | AdBlue level (in percent) | AdBlue level (in liters) | Acceleration pedal position | Engine torque | Retarder torque | Time to service | HV battery level | The slope of the arm | Rotation of the arm | Eject of the arm | Distance between arm and vehicle | Height of the arm above the ground | Level of water for fire fighting | Level of fire fighting foam | Pressure in fire fighting pump | Wind speed | Outside temperature | The amount of spread salt per square meter | Battery voltage | Spread width to the left | Spread width to the right | Cargo weight | Gross comb. vehicle weight | Brake pedal position |
|---|---|---

[en]=> (ALL-CAN300)

Tankers

Section 1 - the presence of fluid in the downpipe	Section 1 - full	Section 1 - overfill	Section 2 - the presence of fluid in the downpipe	Section 2 - full	Section 2 - overfill	Section 3 - the presence of fluid in the downpipe	Section 3 - full	Section 3 - overfill	Section 4 - the presence of fluid in the downpipe	Section 4 - full	Section 4 - overfill	Section 5 - the presence of fluid in the downpipe	Section 5 - full	Section 5 - overfill	Section 6 - the presence of fluid in the downpipe	Section 6 - full	Section 6 - overfill
1	1	1	2	2	2	3	3	3	4	4	4	5	5	5	6	6	6
1) OPTOLEVEL GATEWAY (v10)														year: **2009=>**		program № **11863**	from **2017-09-01**
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

+	This parameter is available depending on vehicle's equipment
+	This parameter is available on the client's request
+	This parameter is available depending on vehicle's VIN number
+	This parameter may be unavailable using P400 or U400 contactless reader