

# FMP100 Keyboard

[Main Page](#) > [Fast & Easy Trackers](#) > [FMP100](#) > [FMP100 Manual](#) > [FMP100 Configuration](#) > **FMP100 Keyboard**

FMP100 have one physical button integrated and it can be configured to be used for different purposes.

## Button



Button can be pressed in three different ways:

- 1 Click - button is pressed no longer than 2 seconds.
- 2 Clicks - button is pressed no more than two times. Between clicks there needs to be less than 1 second pause.
- Long Click - button is pressed and hold more than 2 seconds.

For each click method you can choose from 4 different modes:

- None
- Alarm
- Change Trip Mode
- Check Trip Mode