

TFT100 RS232 settings

[Main Page](#) > [E-Mobility Trackers](#) > [TFT100](#) > [TFT100 Configuration](#) > **TFT100 RS232 settings**



Contents

- [1 Mode](#)
- [2 RS232 Mode](#)
- [3 RS232 Baudrate](#)
- [4 RS232 Parity](#)
- [5 TCP Binary Mode settings](#)
- [6 Message Timestamp](#)

Mode



RS232 supports full-duplex communication which means the data can be both sent and received at the same time as they use separate transmission lines.

RS232 Mode



- Log Mode - RS232 prints TFT100 device log and does not respond to commands (Transmit mode).
- NMEA - RS232 prints GNSS NMEA log and does not respond to commands (Transmit mode).
- TCP ASCII/Binary - In TCP ASCII/Binary mode all data received from external device is sent directly to server. Data is encapsulated in codec 12 format. TCP Binary Mode has a delay of 30 ms, if no data is received for 30 ms, data is sent to the server. TCP ASCII mode waits for the End of Line (EOL) character (0x0D0A, \r\n) to pack data and send it to the server.
- TCP ASCII/Binary Buffered - TCP ASCII Buffered and TCP Binary Buffered modes are used to collect data from RS232 and save it in buffer if there is no link with server and data cannot be sent immediately. When link is established and there is data to transmit, then RS232 data from buffer is transmitted after all records are sent. Data is sent in codec 13 protocol.

Note! That in TCP ASCII and TCP Binary modes device sends data from external device only to main server. In Buffered modes - to both main and backup/duplicate servers.

RS232 Baudrate



RS232 Baudrate selection.
Not available in the Log Mode.

RS232 Parity



Parity selection.

TCP Binary Mode settings



TCP Binary has a setting Prefix. It is possible to set **Prefix 1**, **Prefix 2** or **Prefix 3**. These prefixes can be used separately or in unison. To configure this setting a value from 0 to 255 in decimal has to be entered. Device will convert this value to HEX and compare the 1st, 2nd or 3rd byte from incoming data. If the values do not match, device will not accept incoming data. Example:

Incoming packet through RS232 using TCP Binary/Binary Buffered mode - 50 72 65 66 69 78 20 57 6f 72 6b 69 6e 67

- If Prefix 1 is set to 80 in decimal, it is equal to 50 in HEX. TFT100 device will then check the 1st byte of incoming data and compare to the set Prefix 1.
- If Prefix 2 is set to 114 in decimal, it is equal to 72 in HEX. TFT100 device will then check the 2nd byte of incoming data and compare to the set Prefix 2.
- If Prefix 3 is set to 101 in decimal, it is equal to 65 in HEX. TFT100 device will then check the 3rd byte of incoming data and compare to the set Prefix 3.

When values match, data will be accepted and saved to Buffer (using TCP Binary Buffered mode) or sent to server (using TCP Binary mode).

Incoming packet through RS232 using TCP Binary/Binary Buffered mode - 50 0 65 66 69 78 20 57 6f 72 6b 69 6e 67

- If Prefix 1 is set to 80 in decimal, it is equal to 50 in HEX. TFT100 device will then check the 1st byte of incoming data and compare to the set Prefix 1.
- If Prefix 2 is set to 114 in decimal, it is equal to 72 in HEX. TFT100 device will then check the 2nd byte 0 of incoming data and compare to the set Prefix 2.

Since Prefix 2 does not match incoming 2nd byte, data will not be accepted.

Message Timestamp



Message Timestamp parameter is used to determine if it is necessary to include timestamp in RS232 TCP packet when sending to server. If parameter is enabled, then Codec 13 is used for data sending. Otherwise, Codec 12 is used.

NOTE!

Description how to test **TCP link mode** (transparent mode) with RS232 and RS485 can be found [here](#).