

FMB641 Carrier

[Main Page](#) > [EOL Products](#) > [FMB641](#) > [FMB641 Manual](#) > **FMB641 Carrier**

□

Contents

- [1 Introduction](#)
- [2 Supported Carrier Refrigerators](#)
- [3 Installation guide](#)
- [4 Configuration](#)

Introduction

Usually, cargo is equally as important as the vehicle itself, with temperature data you can be assured that the goods which you are delivering will maintain high quality, thus Teltonika is offering the ability to monitor real-time information from Carrier Freezers. The Carrier Control box/ECU is connected via the RS232 port of the professional FMB6 trackers. The solution is easy to install and to configure. This allows to monitor the main information of the freezer trailer such as Temperature, Fridge door status, Alarms, etc. and generate events according to your needs. For more information please refer to the installation manual below.

Supported Carrier Refrigerators

SUPPORTED CARRIER REFRIGERATORS:

VECTOR 1800 | VECTOR 1850 | VECTOR 1850 MT | VECTOR 1550

Installation guide

The installation manual for Carrier Vector 1550 can be downloaded here: 

Installation requires "[Carrier reefer cable](#)"

Configuration

Make sure the FMx6 device is configured to receive data from "Carrier Reefer". To do this, enter the configurator window, select the RS232 \ RS485 section displayed in the screenshot below, and configure accordingly (COM1 Settings, Mode "Carrier Reefer", Baudrate: 9600)



The screenshot below displays Reefer I/O parameters section, here you can set up your device to send required parameters

- Security
- System
- GPRS
- Data Acquisition
- SMS \ Call Settings
- SMS Events
- GSM Operators
- Features
- Accelerometer Features
- Auto Geofence
- Manual Geofence Settings
- Manual Geofence Zones
- Trip \ Odometer
- Bluetooth
- iButton List
- I/O
- LVCAN
- FMS IO
- Manual CAN IO
- Tachograph Data
- RS232 \ RS485
- CAN \ Tachograph
- ContiPressureCheck
- Custom scenarios
- Mobileye
- Reefer IO

reefer

Input Name	Priority	Low Level	High Level	Event Only	Operand
Zone1 Return Air Temperature 1	None Low High Panic	0	0	Yes No	Monitoring
Zone1 Return air temperature 2	None Low High Panic	0	0	Yes No	Monitoring
Zone1 Supply Air Temperature 1	None Low High Panic	0	0	Yes No	Monitoring
Zone1 Supply air temperature 2	None Low High Panic	0	0	Yes No	Monitoring
Zone1 Set Temperature	None Low High Panic	0	0	Yes No	Monitoring
Zone2 Supply air temperature 1	None Low High Panic	0	0	Yes No	Monitoring
Zone2 Return air temperature 1	None Low High Panic	0	0	Yes No	Monitoring
Zone2 Set Temperature	None Low High Panic	0	0	Yes No	Monitoring
Ambient Air Temperature	None Low High Panic	0	0	Yes No	Monitoring
Compressor Coolant Temperature	None Low High Panic	0	0	Yes No	Monitoring
Compressor RPM	None Low High Panic	0	0	Yes No	Monitoring
Compressor Config	None Low High Panic	0	0	Yes No	Monitoring
Battery Voltage (V * 10)	None Low High Panic	0	0	Yes No	Monitoring
Compressor Motor Work Minutes (HM)	None Low High Panic	0	0	Yes No	Monitoring
Work Minutes (HMT)	None Low High Panic	0	0	Yes No	Monitoring
Electric Minutes (HME)	None Low High Panic	0	0	Yes No	Monitoring
Door State	None Low High Panic	0	0	Yes No	Monitoring
Installation Serial	None Low High Panic	0	0	Yes No	Monitoring
Trailer Registration Number	None Low High Panic	0	0	Yes No	Monitoring
Error Count	None Low High Panic	0	0	Yes No	Monitoring
Alarm 1	None Low High Panic	0	0	Yes No	Monitoring
Alarm 2	None Low High Panic	0	0	Yes No	Monitoring
Alarm 3	None Low High Panic	0	0	Yes No	Monitoring

[Codec 8 Extended](#) should be selected as the main data protocol in the “Protocol Settings” tab, which is located in the “System” section.

- Security
- System
- GPRS
- Data Acquisition
- SMS \ Call Settings
- SMS Events
- GSM Operators
- Features
- Accelerometer Features
- Auto Geofence
- Manual Geofence Settings
- Manual Geofence Zones
- Trip \ Odometer
- Bluetooth
- iButton List
- I/O
- LVCAN
- FMS IO
- Manual CAN IO
- Tachograph Data
- RS232 \ RS485
- CAN \ Tachograph
- ContiPressureCheck

Sleep Mode

Sleep Settings

Disable GPS Sleep

Deep Sleep Online Deep Sleep

Timeout (min) 10

System Settings

GNSS Source

GPS GLONASS

Analog Input Value Range

Range 10V Range 30V

AIN4/DOUT4 Mode

Ain4 DOUT4

Analog Input Value Range 3-4

Range 10V Range 30V

Odometer Source settings

GPS LVCAN

FMS KLINE

Speed Source settings

GPS LVCAN

FMS KLINE

Protocol Settings

Data Protocol

Codec 8 **Codec 8 Extended**

Records Settings

Records Saving/Sending Without TS

After Position Fix Always

After Time Sync

Open Link Timeout (s) 30

Response Timeout (s) 30

Sort By

Newest Oldest

Save records to

Internal memory SD card

Ping mode

Disabled Empty Codec.12

0xFF

Network Ping Timeout (min.) 60

Static Navigation Settings

Static Navigation

Disable **Enable**

Static Navigation Deactivation Source

Movement OR Ignition Movement

Ignition Movement AND Ignition

Ignition Source

Ignition Settings

Digital input 1 Digital input 2

Digital input 3 Digital input 4

Movement **Power Voltage**

High Voltage (mV) 30000

Low Voltage (mV) 13200

Movement Start Delay (s) 1

Movement Stop Delay (s) 60