

# FMB641 Carrier

[Main Page](#) > [Professional Trackers](#) > [FMB641](#) > [FMB641 Manual](#) > **FMB641 Carrier**



## Contents

- [1 Introduction](#)
- [2 Supported Carrier Refrigerators](#)
- [3 Installation guide](#)
- [4 Configuration](#)

## Introduction

Usually, cargo is equally as important as the vehicle itself, with temperature data you can be assured that the goods which you are delivering will maintain high quality, thus Teltonika is offering the ability to monitor real-time information from Carrier Freezers. The Carrier Control box/ECU is connected via the RS232 port of the professional FMB6 trackers. The solution is easy to install and to configure. This allows to monitor the main information of the freezer trailer such as Temperature, Fridge door status, Alarms, etc. and generate events according to your needs. For more information please refer to the installation manual below.

## Supported Carrier Refrigerators

SUPPORTED CARRIER REFRIGERATORS:

VECTOR 1800 | VECTOR 1850 | VECTOR 1850 MT | VECTOR 1550

## Installation guide

The installation manual for Carrier Vector 1550 can be downloaded here: 

Installation requires "[Carrier reefer cable](#)"

## Configuration

Make sure the FMx6 device is configured to receive data from "Carrier Reefer". To do this, enter the configurator window, select the RS232 \ RS485 section displayed in the screenshot below, and configure accordingly (COM1 Settings, Mode "Carrier Reefer", Baudrate: 9600)



The screenshot below displays Reefer I/O parameters section, here you can set up your device to send required parameters

Security
System
GPRS
Data Acquisition
SMS \ Call Settings
SMS Events
GSM Operators
Features
Accelerometer Features
Auto Geofence
Manual Geofence Settings
Manual Geofence Zones
Trip \ Odometer
Bluetooth
iButton List
I/O
LVCAN
FMS IO
Manual CAN IO
Tachograph Data
RS232 \ RS485
CAN \ Tachograph
ContiPressureCheck
Custom scenarios
Mobileye
Reefer IO

reefer

Input Name	Priority				Low Level	High Level	Event Only		Operand	
Zone1 Return Air Temperature 1	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone1 Return air temperature 2	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone1 Supply Air Temperature 1	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone1 Supply air temperature 2	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone1 Set Temperature	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone2 Supply air temperature 1	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone2 Return air temperature 1	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Zone2 Set Temperature	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Ambient Air Temperature	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Compressor Coolant Temperature	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Compressor RPM	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Compressor Config	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Battery Voltage (V * 10)	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Compressor Motor Work Minutes (HM)	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Work Minutes (HMT)	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Electric Minutes (HME)	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Door State	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Installation Serial	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Trailer Registration Number	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Error Count	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Alarm 1	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Alarm 2	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼
Alarm 3	None	Low	High	Panic	0	0	Yes	No	Monitoring	▼

[Codec 8 Extended](#) should be selected as the main data protocol in the “Protocol Settings” tab, which is located in the “System” section.

Security
System
GPRS
Data Acquisition
SMS \ Call Settings
SMS Events
GSM Operators
Features
Accelerometer Features
Auto Geofence
Manual Geofence Settings
Manual Geofence Zones
Trip \ Odometer
Bluetooth
iButton List
I/O
LVCAN
FMS IO
Manual CAN IO
Tachograph Data
RS232 \ RS485
CAN \ Tachograph
ContiPressureCheck

#### Sleep Mode

##### Sleep Settings

Disable	GPS Sleep
Deep Sleep	Online Deep Sleep
Timeout (min)	10

##### System Settings

GNSS Source	
GPS	GLONASS
Analog Input Value Range	
Range 10V	Range 30V
AIN4/DOUT4 Mode	
Ain4	DOUT4
Analog Input Value Range 3-4	
Range 10V	Range 30V
Odometer Source settings	
GPS	LVCAN
FMS	KLINE
Speed Source settings	
GPS	LVCAN
FMS	KLINE

#### Protocol Settings

##### Data Protocol

Codec 8	Codec 8 Extended
---------	------------------

##### Records Settings

##### Records Saving/Sending Without TS

After Position Fix	Always
After Time Sync	
Open Link Timeout (s)	30
Response Timeout (s)	30
Sort By	
Newest	Oldest
Save records to	
Internal memory	SD card
Ping mode	
Disabled	Empty Codec.12
0xFF	
Network Ping Timeout (min.)	60

#### Static Navigation Settings

##### Static Navigation

Disable	Enable
Static Navigation Deactivation Source	
Movement OR Ignition	Movement
Ignition	Movement AND Ignition

##### Ignition Source

##### Ignition Settings

Digital input 1	Digital input 2
Digital input 3	Digital input 4
Movement	Power Voltage
High Voltage (mV)	30000
Low Voltage (mV)	13200
Movement Start Delay (s)	1
Movement Stop Delay (s)	60