

# FMC125 SMS events

[Main Page](#) > [Professional Trackers](#) > [FMM125](#) > [FMC125 Configuration](#) > **FMC125 SMS events**

SMS events functionality allows FMC125 to send a configured SMS when an event is triggered. This event can be triggered by every I/O element.

When any of the I/O elements is triggered, FMC125 sends a configured SMS message to a defined phone number. If SMS events are activated but there are no numbers defined in *GSM Predefined Numbers* list (similarly as in the picture below), then the device will not send any messages.



The sent SMS messages format is following:

*"Date Time Current Coordinate Event Text"*

For example, if FMC125 is configured to send an SMS, when Ignition reaches high level while configured with *High priority* and event generation on both range entrance and exit (as shown on the figure below), then the sent SMS is:

*"2017/06/13 13:52:18 Lon:25.255537 Lat:54.667193 Ignition 1"*

The screenshot displays the FMC125 configuration interface. At the top, there are buttons for 'Load from device', 'Save to device', 'Update firmware', 'Reset configuration', 'Load from file', 'Save to file', 'Read records', and 'Reboot device'. Below these is a sidebar with various configuration categories like Status, Security, System, GPRS, Data Acquisition, SMS \ Call Settings, GSM Operators, Features, Accelerometer Features, Auto Geofence, Manual Geofence, Trip \ Odometer, Bluetooth, Bluetooth 4.0, 1-Wire, I/O, OBD II, CAN Adapter, and RS232 \ RS485. The main area shows a table for I/O settings with columns for Input Name, Units, Priority, Low Level, High Level, Event Only, Operand, Avg Const, Send SMS To, and SMS Text. The table lists various inputs like Ignition, Movement, Data Mode, GSM Signal, Sleep Mode, GNSS Status, GNSS PDOP, GNSS HDOP, External Voltage, Speed, GSM Cell ID, GSM Area Code, Battery Voltage, Battery Current, Active GSM Operator, Trip Odometer, Total Odometer, Digital Input 1, Analog Input 1, Digital Output 1, Fuel Used GPS, Fuel Rate GPS, Axis X, Axis Y, Axis Z, ICCID, Digital Input 2, Dallas Temperature 1, and Dallas Temperature 2. Each input has a priority level (None, Low, High, Panic) and a status (On Change, Monitoring, etc.).

The SMS Text field can be altered and any text can be entered. Maximum message length is 160 symbols (numbers, letters and symbols in ASCII, except for comma symbol ",").

If FMC125 is in *Deep Sleep* mode and an SMS event occurs with *Low priority* (which does not wake up FMC125), then the device does not send the message. It is saved to device memory until it wakes up from *Deep Sleep* mode and GSM modem starts working normally. After it wakes up, all the messages that are saved to memory will be sent, but keep in mind that only 10 messages can be saved to memory - all other messages will not be saved, until there is free memory space.