

# TMT250 SMS/Call settings

[Main Page](#) > [Autonomous Trackers](#) > [TMT250](#) > [TMT250 Configuration](#) > **TMT250 SMS/Call settings**

□

## Contents

- [1 SMS Data sending](#)
- [2 SMS Commands](#)
- [3 Incoming Call Settings](#)
- [4 Authorized Numbers](#)
- [5 GSM Predefined Numbers](#)

## SMS Data sending

The screenshot shows a configuration box titled "SMS Data Sending". Inside, there is a label "Allow SMS Data Sending" above two buttons: "Disable" (highlighted in blue) and "Enable" (grey). Below the buttons is a text input field labeled "Data Send Number".

These settings allow sending AVL data using binary SMS. AVL data will be sent by SMS only when there is no GPRS connection. This setting does not affect replies to SMS request messages - answers are always sent back to the sender's telephone number.

## SMS Commands

The screenshot shows a configuration box titled "SMS Commands". It contains three input fields: "Login" (empty), "Password" (empty), and "SMS Event Time Zone" (a dropdown menu currently showing "UTC+00:00").

Essential fields in SMS/Call settings are Login and Password. The login and password are used with every SMS sent to the device. If login and password are not set, in every SMS sent to the device, two spaces before command have to be used: <space><space><command>.

Command structure with set login and password:<login><space><password><space><command>.

For example: "asd 123 getgps"

## Incoming Call Settings

Incoming Call Action parameter defines device action during incoming call:

- Do Nothing
- Hang-up - Automatically hang up an incoming call.
- Report Position - Report position to calling number via SMS.
- Auto Answer (HF)- Auto answer an incoming call if device is paired with a hands-free kit.
- Man-Down -
- Info SMS - Send info SMS to incoming call number and hang up the incoming call.  
*Info SMS format:* Date: <date> Time: ; IMEI: <imei>; Version: <version>; BatLvl: <batlvl>; OpId: <operator\_id>; GSMSignLvl: <gsm\_signal\_level>
- Power Off - Hang up incoming call and turn device off.
- Send GPRS Data - Hang up incoming call and start sending records to server.
- Auto Geofencing Off - Turn off Auto Geofence scenario.

**Incoming Call Settings**

Incoming Call Action

Do Nothing (BT HF)	Hangup
Report Position	Auto Answer (HF)
Man-Down	Info SMS
Power Off	Send GPRS Data
Auto Geofencing Off	

## Authorized Numbers

**Authorized Numbers**

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20

Import CSV  
Export CSV

List of Authorized numbers to receive SMS and Calls from.

Phone numbers have to be written in international standard, using "+" is optional but not necessary (in both cases number will be recognized, but when number is without "+" symbol, IDD Prefix will not be generated, which depends on location of the phone).

**✘ If no numbers are entered, configuration and sending commands over SMS are allowed from all GSM numbers.**

# GSM Predefined Numbers

GSM Predefined Numbers

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	

Import CSV

Export CSV

List of predefined numbers for SMS events sending and making Calls.



TMT250 works in synchronized GPS time which is UTC+0, with this option customer can configure the time zone and get SMS messages with correct time.



Please do not set *Data Send Number* to some cell phone number, because it will not understand binary SMS. When sending a binary SMS to a phone number, which is a server phone number, the server can interpret and understand binary code, so the data can be read and you can view it on the server.



SMS login and password and authorized numbers list are used to protect TMT250 device from unauthorized access. Module accepts messages only from a list of authorized numbers and with proper module login and password. Phone numbers have to be written in international standard using "+" or without using it (in both cases the number will be recognized). If no authorized numbers are entered, module accepts messages from all numbers.