# Template:FMB209 First start card



Teltonika FMB209 is a SPECIAL waterproof tracker with Bluetooth connectivity and integrated backup battery. Device was designed to meet Indian government regulation AIS 140



#### **Contents**

- 1 How to insert Micro-SIM card and connect the battery
- 2 Cable colors

## How to insert Micro-SIM card and connect the battery

- 1. Unscrew 6 screws counterclockwise that are located on the bottom of the FMB209 device.
- 2. Remove the **cover**.
- 3. Insert **Micro-SIM** card as shown with **PIN request disabled** or read **Security info** how to enter it later in <u>Teltonika Configurator</u>. Make sure that Micro-SIM card **cut-off corner** is pointing forward to slot.
- 4. Connect **battery** as shown to device.
- 5. After **configuration**, see "<u>PC Connection (Windows)</u>", attach device **cover** back and **screw** in all screws.

Device is ready to be mounted.

## 

Micro-SIM card insertion/removal must be performed when device is powered off 
external voltage and internal battery disconnected. Otherwise Micro-SIM card might be damaged or device will not detect it.

### Cable colors

PIN NUMBER	PIN NAME	DESCRIPTION	+1030 V DC	•
Red	VCC (10-30)V DC (+)	Power supply (+1030 V DC)	GND	6
Black	GND (-)	Ground	DIN1	
Yellow	DIN 1	Digital input, channel 1	DINI	<u> </u>
White/Green	DIN 2	Digital input, channel 2	DIN2	•
White	DOUT 1	Digital Output Channel 1	DOUT1	
Grey	AIN 1/DIN 3	Analog input, channel 1. Input range: 0-30 V DC/Digital input channel 3	AIN1/DIN3	
White/Orange	RS232-TX	Output for data transmission through RS-232	RS232-TX	
Violet	RS232-RX	Input for data reception through RS-232	RS232-RX	
Green	AIN 2/DIN 4	Analog input, channel 2. Input range:	AIN2/DIN4	
Blue	DOUT 2	0-30 V DC/Digital input channel 4 Digital output 2	DOUT2	<u> </u>