

DashCam Data Sending Parameters ID

[Main Page](#) > [Video Solutions](#) > [Teltonika DashCam](#) > **DashCam Data Sending Parameters ID**



Contents

- [1 DashCam/DualCam RS232 camera support](#)
- [2 Camera Feature Settings Parameters ID](#)
- [3 Camera Feature Settings Parameters ID \(for FMx650 devices\)](#)
- [4 Camera Scenario Settings Parameters ID](#)
- [5 Camera Scenario Settings Parameters ID \(for FMx650 devices\)](#)
- [6 Video sending by trigger parameters ID](#)
- [7 Image sending trigger parameters ID](#)
- [8 Camera ping transmission and TF status checking parameters ID](#)

DashCam/DualCam RS232 camera support

DashCam camera support was introduced from firmware version 03.27.13.Rev.662. A new RS232 mode "DashCam" was added with parameters for setting control. The details of the RS232 mode parameter are provided in the table below.

Parameter name	Parameter ID	Parameter value	Parameter description
RS232 Mode	151	18	DualCam
RS232 Mode	151	26	DashCam



Configuration version 8.19.5.0 has to be used if the configuration is being made in offline mode.

Camera Feature Settings Parameters ID



Once this mode is enabled, new tab "Camera Settings" appears on the left sidebar. This will contain the main parameters for configuring the camera settings. The parameter IDs and values are provided in the table below. Once configuration is saved to device, these parameters are updated.

Parameter name	Parameter ID	Parameter values	Default values
Camera Picture Resolution	66000	0 - 160 x 120	3
		1 - 320 x 240	
		2 - 640 x 480	
		3 - 1280 x 720	
Camera Picture Compression	66001	4 - 1920 x 1080	50
		[0 - 100] (%)	
		0 - Disabled	
		1 - Enabled	
OSD Display	66002	0 - Disabled 1 - Enabled	0
Video Frame Rate	66003	20, 25 and 30 (frames per second)	30
File transfer priority	66025	0 - Picture	2
		1 - Video 2 - Alternating	

Camera Time Zone	66024	-720 - UTC-12:00 -690 - UTC-11:30 -660 - UTC-11:00 -630 - UTC-10:30 -600 - UTC-10:00 -570 - UTC-09:30 -540 - UTC-09:00 -510 - UTC-08:30 -480 - UTC-08:00 -450 - UTC-07:30 -420 - UTC-07:00 -390 - UTC-06:30 -360 - UTC-06:00 -330 - UTC-05:30 -300 - UTC-05:00 -270 - UTC-04:30 -240 - UTC-04:00 -210 - UTC-03:30 -180 - UTC-03:00 -150 - UTC-02:30 -120 - UTC-02:00 -90 - UTC-01:30 -60 - UTC-01:00 -30 - UTC-00:30 0 - UTC+00:00 30 - UTC+00:30 60 - UTC+01:00 90 - UTC+01:30 120 - UTC+02:00 150 - UTC+02:30 180 - UTC+03:00 210 - UTC+03:30 240 - UTC+04:00 270 - UTC+04:30 300 - UTC+05:00 330 - UTC+05:30 360 - UTC+06:00 390 - UTC+06:30 420 - UTC+07:00 450 - UTC+07:30 480 - UTC+08:00 510 - UTC+08:30 540 - UTC+09:00 570 - UTC+09:30 600 - UTC+10:00 630 - UTC+10:30 660 - UTC+11:00 690 - UTC+11:30 720 - UTC+12:00 750 - UTC+12:30 780 - UTC+13:00 810 - UTC+13:30 840 - UTC+14:00	UTC+00:00
------------------	-------	---	-----------

OSD display - On Screen Display feature displays date and time in the upper left corner of the photo. This feature can be enabled or disabled.

Camera Feature Settings Parameters ID (for FMx650 devices)

	Parameter ID for FMX650 device	Parameter values for FMX650 device
Camera Resolution Picture	COM1 DashCam - 1011000	0 - 160 x 120
	COM2 DashCam - 1012000	1 - 320 x 240 2 - 640 x 480 3 - 1280 x 720 4 - 1920 x 1080
Camera Picture Compression	COM1 DashCam - 1011001	[0 - 100] (%)
	COM2 DashCam - 1012001	
OSD Display	COM1 DashCam - 1011002	0 - Disabled
	COM2 DashCam - 1012002	1 - Enabled
Video Frame Rate	COM1 DashCam - 1011003	20 - 20 FPS
	COM2 DashCam - 1012003	25 - 25 FPS
		30 - 30 FPS
File Transfer Priority	COM1 DashCam - 1011025	0 - Picture
	COM2 DashCam - 1012025	1 - Video
		2 - Alternating

Camera Time Zone

COM1 DashCam - 1011024
COM2 DashCam - 1012024

- 720 - UTC-12:00
- 690 - UTC-11:30
- 660 - UTC-11:00
- 630 - UTC-10:30
- 600 - UTC-10:00
- 570 - UTC-09:30
- 540 - UTC-09:00
- 510 - UTC-08:30
- 480 - UTC-08:00
- 450 - UTC-07:30
- 420 - UTC-07:00
- 390 - UTC-06:30
- 360 - UTC-06:00
- 330 - UTC-05:30
- 300 - UTC-05:00
- 270 - UTC-04:30
- 240 - UTC-04:00
- 210 - UTC-03:30
- 180 - UTC-03:00
- 150 - UTC-02:30
- 120 - UTC-02:00
- 90 - UTC-01:30
- 60 - UTC-01:00
- 30 - UTC-00:30
- 0 - UTC+00:00
- 30 - UTC+00:30
- 60 - UTC+01:00
- 90 - UTC+01:30
- 120 - UTC+02:00
- 150 - UTC+02:30
- 180 - UTC+03:00
- 210 - UTC+03:30
- 240 - UTC+04:00
- 270 - UTC+04:30
- 300 - UTC+05:00
- 330 - UTC+05:30
- 360 - UTC+06:00
- 390 - UTC+06:30
- 420 - UTC+07:00
- 450 - UTC+07:30
- 480 - UTC+08:00
- 510 - UTC+08:30
- 540 - UTC+09:00
- 570 - UTC+09:30
- 600 - UTC+10:00
- 630 - UTC+10:30
- 660 - UTC+11:00
- 690 - UTC+11:30
- 720 - UTC+12:00
- 750 - UTC+12:30
- 780 - UTC+13:00
- 810 - UTC+13:30
- 840 - UTC+14:00

Camera Scenario Settings Parameters ID



"Camera settings" tab also contains scenario settings that trigger camera video/photo capture when specific condition is met.

Parameter name	Parameter ID	Parameter values	Default values
Periodic Image sending	66006	0 - Disabled 1 - Front Camera	0
Sending interval	66007	[10-1800] (seconds)	600
Image Sending Trigger	66022	0 - None 2 - DIN1 4 - DIN2 8 - Crash 16 - Towing 32 - Idling 64 - Geofence 128 - Unplug 256 - Green Driving	0
Video sending trigger	66023	0 - None 2 - DIN1 4 - DIN2 8 - Crash	0
Video duration before trigger	66009	[1-10] (seconds)	5
Video duration after trigger	66010	[1-10] (seconds)	5
Camera Scenario Mode	66020	0 - On Ignition 1 - Always	0

Video source for trigger DIN1	66040	0 - None 1 - Front	0
Video source for trigger DIN2	66041	0 - None 1 - Front	0
Video source for trigger Crash	66042	0 - None 1 - Front	0

Camera Scenario Settings Parameters ID (for FMx650 devices)

	Parameter ID for FMX650 device	Parameter Values for FMX650 device
Periodic Image Sending	COM1 DashCam - 1011006 COM2 DashCam - 1012006	0 - Disabled 1 - Front Camera 2 - Rear Camera 3 - Both Cameras
Sending Interval	COM1 DashCam - 1011007 COM2 DashCam - 1012007	[10 - 1800] (seconds) 2 - DIN1 4 - DIN2 8 - DIN3 16 - DIN4 32 - Crash 64 - Towing 128 - Idling 256 - Geofence 512 - Unplug 1024 - Green Driving
Image Sending Trigger	COM1 DashCam - 1011022 COM2 DashCam - 1012022	0 - None 1 - DIN1 2 - DIN2 3 - Crash
Video Sending Trigger	COM1 DashCam - 1011023 COM2 DashCam - 1012023	0 - None 1 - DIN1 2 - DIN2 3 - Crash
Video duration before Trigger	COM1 DashCam - 1011009 COM2 DashCam - 1012009	[0 - 15] (seconds)
Video duration after Trigger	COM1 DashCam - 1011010 COM2 DashCam - 1012010	[0 - 15] (seconds)
Camera Scenario Mode	COM1 DashCam - 1011020 COM2 DashCam - 1012020	0 - On Ignition 1 - Always
Video Source for Trigger DIN1	COM1 DashCam - 1011040 COM2 DashCam - 1012040	
Video Source for Trigger DIN2	COM1 DashCam - 1011041 COM2 DashCam - 1012041	0 - None
Video Source for Trigger DIN3	COM1 DashCam - 1011044 COM2 DashCam - 1012044	1 - Front 2 - Rear
Video Source for Trigger DIN4	COM1 DashCam - 1011045 COM2 DashCam - 1012045	3 - Front and Rear
Video Source for Trigger Crash	COM1 DashCam - 1011042 COM2 DashCam - 1012042	

Video sending by trigger parameters ID

Video sending by trigger camera scenario monitors the selected trigger (video sending trigger parameter) and captures video from the camera before and after the event (video duration before trigger and video duration after trigger parameters). If the previously captured video has not finished downloading, then a new video capture is skipped until the old one has been sent. When this scenario is triggered, high priority eventual record is generated with the value corresponding to what triggered the scenario. See the table below.

Parameter name	Parameter AVL ID	Parameter value
SOS trigger	499	0 - Server request 1 - DIN1 2 - DIN2 3 - Crash

Image sending trigger parameters ID

Added Image sending trigger option (works the same way as Video sending trigger just triggers

image sending).

For selecting multiple options using SMS/GPRS commands, add values of every option and set that value for this parameter.

For example, to set DIN1 (2), Crash (8), and Unplug (128) scenarios as triggers, add their values (2 + 4 + 128 = 138) and set the sum as the parameter value

Parameter name	Parameter AVL ID	Parameter value
SOS trigger	499	0 - Server request
		1 - DIN1
		2 - DIN2
		3 - Crash
		4 - Towing
		5 - Idling
		6 - Geofence
		7 - Unplug
		8 - Green Driving

Camera ping transmission and TF status checking parameters ID

Camera pinging was implemented to periodically check if a camera is connected to a device. This is done via "Get TF status" command for camera every 20 seconds when ignition is on. The received result from this command is stored in the corresponding AVL element "Front camera state". The following do not only store TF status, but also if response from the camera was received or not.

Parameter name	Parameter AVL ID for FMx125, FMx225 devices	Parameter AVL ID for FMx650 devices	Parameter Values
Front Camera State:	498	COM1 DashCam - 12303 COM2 DashCam - 12306	0 - Camera not detected
			1 - No Card
			2 - Card mount failed
			3 - Card mounted
			4 - Card faulty