

# FMM640 Device Family Parameter list

[Main Page](#) > [EOL Products](#) > [FMM640](#) > [FMM640 Manual](#) > **FMM640 Device Family Parameter list**



## Contents

- [1 System parameters](#)
- [2 GPRS parameters](#)
- [3 SMS/Call settings](#)
- [4 SMS Events](#)
- [5 GSM Operators](#)
- [6 Data Acquisition](#)
- [7 Tracking on Demand](#)
- [8 Features](#)
- [9 Auto Geofence](#)
- [10 Manual Geofence](#)
- [11 Accelerometer features](#)
- [12 Bluetooth](#)
- [13 iButton List](#)
- [14 I/O parameters](#)
- [15 LVCAN](#)
- [16 FMS](#)
- [17 Manual CAN](#)
- [18 Tachograph data](#)
- [19 RS232/RS485](#)
- [20 CAN \ Tachograph](#)
- [21 Continental TPMS](#)
- [22 Mobileye](#)
- [23 Reefer](#)
- [24 Custom scenario](#)
- [25 FMS ECO driving](#)

## System parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
100	Unit8	0	0	3	0 - Ignition 1 - Movement Sensor 2 - GNSS 3 - CAN Speed	Movement Source
102	Uint8	2	0	3	0 - Disabled 1 - GPS Sleep 2 - Deep Sleep 3 - Online Deep Sleep	Sleep Mode
103	Uint8	10	1	3000	Minutes	Sleep timeout

<b>106</b>	Uint8	1	0	1	0 - Disabled 1 - Enabled	Static Navigation
<b>123</b>	Uint8	0	0	3	0 - Movement OR Ignition 1 - Movement 2 - Ignition 3 - Movement AND Ignition	Static Navigation Deactivation Source
<b>111</b>	Uint8	1	0	1	0 - Range 10 V 1 - Range 30 V	Analog input value range
<b>122</b>	Uint8	1	0	1	0 - Range 10 V 1 - Range 30 V	Analog Input Value Range 3-4
<b>115</b>	Uint8	0	0	1	0 - Ain4 1 - DOUT4	AIN4/DOUT4
<b>117</b>	Uint8	0	0	3	0 - GPS 1 - LVCAN 2 - FMS 3 - KLINE	Odometer Source Settings
<b>118</b>	Uint8	0	0	3	0 - GPS 1 - LVCAN 2 - FMS 3 - KLINE	Speed Source settings
<b>221</b>	Uint8	0	0	3	0 - Dont Send 1 - Send Zero 2 - Send Last Known Value 3 - Send 0xFF	IO Send Mode
<b>113</b>	Uint8	0	0	1	0 - Codec 8 1 - Codec 8 Extended	Data Protocol
<b>107</b>	Uint8	0	0	1	0 - After Position Fix 1 - Always 2 - After Time Sync	Saving/Sending without (TS) time synchronization
<b>1000</b>	Uint8	30	30	259200	Seconds	Open Link timeout
<b>1001</b>	Uint8	30	5	300	Seconds	Response Timeout
<b>1002</b>	Uint8	0	0	1	0 - Newest 1 - Oldest	Sort By
<b>1006</b>	Uint8	0	0	1	0 - Internal memory 1 - SD card	Save records to
<b>1007</b>	Uint8	0	0	2	0 - Disabled 1 - Empty Codec 12 2 - 0xFF	Ping mode
<b>1003</b>	Uint8	60	1	259200	Minutes	Ping timeout (min.)
<b>109</b>	Uint8	3	1	3	0 - Disable 1 - GPS only 3 - GPS + GLONASS 7 - GPS + Galileo + Glonass 9 - GPS + Beidou	GNSS Source
<b>110</b>	Unit8	0	0	1	0 - On Need 1 - After ignition ON	Battery Charge Mode
<b>101</b>	Uint8	32	1	63	1 - DIN1 2 - DIN2 4 - DIN3 8 - DIN4 16 - Movement 32 - Power Voltage If multiple - sum values of desired Ignition sources. E.g. DIN3+DIN4 = 12	<a href="#">Ignition settings</a>

<b>104</b>	Uint16	30000	0	30000	Millivolts	Sets High voltage level
<b>105</b>	Uint16	13200	0	29999	Millivolts	Low voltage level
<b>19001</b>	Uint8	1	1	60	Seconds	Movement Start Delay(s)
<b>19002</b>	Uint16	60	5	60	Seconds	Movement Stop Delay(s)
<b>900</b>	Uint8	1	0	3	GPS only 1 - NITZ and NTP 2 - NTP 3 - NITZ	Synchronization settings
<b>910</b>	Uint8	0	0	24	Hours	NTP Resync
<b>902</b>	S8[55]	avl1.teltonika.lt	0	55 char string	Char string	NTP server 1
<b>903</b>	S8[55]	pool.ntp.org	0	55 char string	Server address	NTP server 2

## GPRS parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>2022</b>	Uint8	0	0	1	Boolean	GPRS activation
<b>2023</b>	Uint8	100	0	1000	Megabytes	Home Limit (MB)
<b>2024</b>	Uint8	10	0	100	Megabytes	Roaming Limit (MB)
<b>2001</b>	S8[32]	Empty	0	32 char string	Text	SIM1 APN Name
<b>2002</b>	S8[30]	Empty	0	30 char string	Text	SIM1 APN username
<b>2003</b>	S8[30]	Empty	0	30 char string	Text	SIM1 APN Password
<b>2011</b>	Uint8	1	0	1	Boolean	SIM2 GPRS content activation
<b>2012</b>	S8[32]	Empty	0	32 char string	Text	SIM2 APN Name
<b>2013</b>	S8[30]	Empty	0	30 char string	Text	SIM2 APN username
<b>2014</b>	S8[30]	Empty	0	30 char string	Text	SIM2 APN Password
<b>2004</b>	S8[55]	Empty	0	55 char string	Internet address	Server #1 Domain
<b>2005</b>	Uint16	0	0	65535	Port number	Target Server #1 Port
<b>2006</b>	Uint8	0	0	1	Boolean	Server #1 Protocol
<b>2007</b>	S8[55]	Empty	0	55 char string	Internet address	Server #2 Server Domain
<b>2008</b>	Uint8	0	0	65535	Port number	Server #2 Server Port
<b>2009</b>	Uint8	0	0	1	Boolean	2nd Server Protocol
<b>13003</b>	Uint8	1	0	1	Boolean	FOTA WEB status
<b>13000</b>	S8[55]	fm.teltonika.lt	0	55 char string	Internet address	FOTA WEB Domain
<b>13001</b>	Uint8	5000	0	65535	Port number	FOTA WEB port
<b>13002</b>	Uint16	720	30	65535	Minutes	FOTA WEB Period (min)

## SMS/Call settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		

<b>3000</b>	Uint8	0	0	1	Boolean	SMS data sending settings
<b>3001</b>	S8[16]	Empty	Empty	16 digits	Phone number	Data send number
<b>4000-4009</b>	S8[16]	Empty	Empty	16 digits	Phone number(s)	Authorized phone numbers
<b>9000-9009</b>	Uint8	0	0	255	AVL ID(s)	SMS Events AVL ID list
<b>7000-7009</b>	S8[16]	Empty	Empty	16 digits	GSM Number(s)	GSM Predefined Numbers [1-10]
<b>3003</b>	S8[5]	Empty	Empty	5 char	Text	SMS Login
<b>3004</b>	S8[5]	Empty	Empty	5 char	Text	SMS Password
<b>3005</b>	Uint8	0	0	4	Mode	Incoming call action
<b>3006</b>	Uint16	0	-720	840	Number	SMS Event Time Zone
<b>3009</b>	Uint8	0	0	10	Phone number	DIN 1 GSM Number
<b>3011</b>	Uint8	0	0	1	Boolean	DIN 2 Call Trigger
<b>3012</b>	Uint8	0	0	10	Phone number	DIN 2 GSM Number
<b>3013</b>	Uint8	0	0	1	Boolean	DIN 3 Call Trigger
<b>3014</b>	Uint8	0	0	10	Phone number	DIN 3 GSM Number
<b>3015</b>	Uint8	0	0	1	Boolean	DIN 4 Call Trigger
<b>3016</b>	Uint8	0	0	10	Phone number	DIN 4 GSM Number

## SMS Events

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>9000-9009</b>	Uint8	0	0	255	AVL ID(s)	SMS Events AVL ID list [1-10]
<b>7000-7009</b>	S8[16]	Empty	Empty	16 digits	GSM Number(s)	GSM Event Number list [1-10]
<b>8000-8009</b>	String	Empty	Empty	160 char	Text	SMS Event Text [1-10]

## GSM Operators

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>5000-5049</b>	Uint32	0	0	999999	MCC+MNC number(s)	SIM1 Roaming Operator List
<b>9500-9549</b>	Uint32	0	0	999999	MCC+MNC number(s)	SIM2 Roaming/ Home Operator List
<b>5500-5549</b>	Uint32	0	0	999999	MCC+MNC number(s)	Black List

## Data Acquisition

- Home Network GSM operator code “Vehicle on STOP” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>10000</b>	Uint32	3600	0	2592000	Seconds	Min Period
<b>10005</b>	Uint32	120	0	2592000	Seconds	Send Period
<b>10004</b>	Uint8	1	1	255	Amount	Min Saved Records

- Home Network GSM operator code “Vehicle MOVING” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
10050	Uint32	3600	0	2592000	Seconds	Min Period
10051	Uint16	100	0	65535	Amount	Min Distance
10053	Uint8	10	0	180	Number	Min Angle
10053	Uint32	10	0	255	Seconds	Min Speed Delta
10055	Uint32	120	0	2592000	Seconds	Send Period
10054	Uint8	1	1	255	Amount	Min Saved Records

- Roaming Network GSM operator code “Vehicle on STOP” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
10100	Uint32	3600	0	2592000	Seconds	Min Period
10105	Uint32	120	0	2592000	Seconds	Send Period
10104	Uint8	1	1	255	Amount	Min Saved Records

- Roaming Network GSM operator code “Vehicle MOVING” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
10150	Uint32	300	0	2592000	Seconds	Min Period
10151	Uint16	100	0	65535	Amount	Min Distance
10152	Uint8	10	0	180	Number	Min Angle
10153	Uint32	10	0	255	Seconds	Min Speed Delta
10155	Uint32	120	0	2592000	Seconds	Send Period
10154	Uint8	1	1	255	Amount	Min Saved Records

- Unknown Network GSM operator code “Vehicle on STOP” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
10200	Uint32	3600	0	2592000	Seconds	Min Period
10205	Uint32	120	0	2592000	Seconds	Send Period
10204	Uint8	1	1	255	Amount	Min Saved Records

- Unknown Network GSM operator code “Vehicle MOVING” parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
10250	Uint32	300	0	2592000	Seconds	Min Period
10251	Uint16	100	0	65535	Amount	Min Distance
10252	Uint8	10	0	180	Number	Min Angle
10253	Uint32	10	0	255	Seconds	Min Speed Delta
10255	Uint32	120	0	2592000	Seconds	Send Period
10254	Uint8	1	1	255	Amount	Min Saved Records

## Tracking on Demand

Parameter ID	Parameter Type	Default value	Value range		Parameter name
			Min	Max	
10990	Uint8	10	5	60	Tracking period
10991	Uint16	600	300	3600	Tracking duration

## Features

- Green driving parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11004	Uint8	25	25	85	mG	Max acceleration
11005	Uint8	35	25	85	mG	Max braking
11006	Uint8	30	10	100	mG	Max cornering
11007	Uint8	0	0	1	0 - GPS	Source
					1 - Accelerometer	
11003	Uint8	0	0	5	0 - None	Green driving digital output control settings
					1 - No DOUT control	
					2 - DOUT 1	
					3 - DOUT 2	
					4 - DOUT 3	
					5 - <a href="#">DOUT4 (Mode must be selected)</a>	
11009	float	0.1	0.1	10	Milliseconds	Acceleration Digital output on duration
11010	float	0.1	0.1	10	Milliseconds	Braking Digital output on duration
11011	float	0.1	0.1	10	Milliseconds	Cornering Digital output on duration

• Overspeeding parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11103	Uint8	0	0	5	0 - Disable	Overspeeding output control
					1 - No DOUT control	
					2 - DOUT1	
					3 - DOUT2	
					4 - DOUT3	
					5 - <a href="#">DOUT4 (Mode must be selected)</a>	
11104	Uint16	90	0	260	Speed	Max allowed Speed

• Jamming parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11304	Uint8	0	0	5	0 - Disable	Overspeeding output control
					1 - No DOUT control	
					2 - DOUT1	
					3 - DOUT2	
					4 - DOUT3	
					5 - <a href="#">DOUT4 (Mode must be selected)</a>	
11303	Uint8	1	0	1	Boolean	Jamming Eventual records
11305	Uint16	60	0	65535	Seconds	Time Until Jamming Event Detection
11305	Uint16	60	0	65535	Seconds	Time Until Jamming Event Detection
11301	Int32	60	0	65530	Milliseconds	Jamming DOUT on duration [ms]
11306	Uint8	0	0	2	Mode	Jamming Sensitivity Control

• Immobilizer parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		

11702	UInt8	0	0	5	0 - Disable 1 - No DOUT control 2 - DOUT1 3 - DOUT2 4 - DOUT3 5 - <a href="#">DOUT4 (Mode must be selected)</a>	Immobilizer output control
11701	UInt8	1	0	1	Boolean	Eventual records
11703	UInt8	0	0	1	Boolean	iButton list check

- iButton read notification parameters

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11704	UInt8	0	0	5	0 - Disable 1 - No DOUT control 2 - DOUT1 3 - DOUT2 4 - DOUT3 5 - <a href="#">DOUT4 (Mode must be selected)</a>	iButton read notification output control
11705	UInt8	200	100	5000	Milliseconds	Duration timeout [ms]

## Auto Geofence

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
20000	UInt8	0	0	3	0 - Disable 1 - Low priority 2 - High priority 3 - Panic priority	Priority
20002	UInt8	1	0	1	Boolean	Eventual records
20001	UInt8	0	0	2	0 - On exiting zone 1 - On entering zone 2 - On both	AutoGeofence event generating
20003	UInt16	60	0	65535	Minutes	Activation timeout
20004	UInt32	100	0	1000000	Metres	Radius
20005	UInt8	0	0	5	0 - Ignition 1 - iButton	Deactivate by

## Manual Geofence

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
20100	UInt8	0	0	3	0 - Disabled 1 - Low 2 - High 3 - Panic	Priority
20101	UInt8	0	0	2	0 - On exiting zone 1 - On entering zone 2 - On both	Operand
20102	UInt8	1	0	1	Boolean	Eventual records
20103	UInt32	1	0	1000000	Border value	Frame border
20104	UInt8	0	0	1	0 - Circle 1 - Rectangle	Shape type

<b>20105</b>	Uint32	5	0	1000000	Metres	Radius
<b>20106</b>	Double	0	-180	180	Coordinate	X1
<b>20107</b>	Double	0	-90	90	Coordinate	Y1
<b>20108</b>	Double	0	-180	180	Coordinate	X2
<b>20109</b>	Double	0	-90	90	Coordinate	Y2
<b>20110</b>	Uint8	0	0	5	0 - Disable	Geozone
					1 - No DOUT control	Overspeeding #1
					2 - DOUT1	DOUT control
					3 - DOUT2	
					4 - DOUT3	
					5 - <u>DOUT4 (Mode must be selected)</u>	
<b>20111</b>	Uint16	90	0	1000	km/h	Max allowed speed

Similarly to a group defined in the upper table:

Zone number	Parameter											
	Priority	Event generating	Eventual records	Frame border	Shape type	Radius	X1	Y1	X2	Y2	Overspeeding	Max allowed speed
1	20100	20101	20102	20103	20104	20105	20106	20107	20108	20109	20110	20111
2	20120	20121	20122	20123	20124	20125	20126	20127	20128	20129	20130	20131
3	20140	20141	20142	20143	20144	20145	20146	20147	20148	20149	20150	20151
4	20160	20161	20162	20163	20164	20165	20166	20167	20168	20169	20170	20171
5	20180	20181	20182	20183	20184	20185	20186	20187	20188	20189	20190	20191
6	20200	20201	20202	20203	20204	20205	20206	20207	20208	20209	20210	20211
7	20220	20221	20222	20223	20224	20225	20226	20227	20228	20229	20230	20231
8	20240	20241	20242	20243	20244	20245	20246	20247	20248	20249	20250	20251
9	20260	20261	20262	20263	20264	20265	20266	20267	20268	20269	20270	20271
10	20280	20281	20282	20283	20284	20285	20286	20287	20288	20289	20290	20291
11	20300	20301	20302	20303	20304	20305	20306	20307	20308	20309	20310	20311
12	20320	20321	20322	20323	20324	20325	20326	20327	20328	20329	20330	20331
13	20340	20341	20342	20343	20344	20345	20346	20347	20348	20349	20350	20351
14	20360	20361	20362	20363	20364	20365	20366	20367	20368	20369	20370	20371
15	20380	20381	20382	20383	20384	20385	20386	20387	20388	20389	20390	20391
16	20400	20401	20402	20403	20404	20405	20406	20407	20408	20409	20410	20411
17	20420	20421	20422	20423	20424	20425	20426	20427	20428	20429	20430	20431
18	20440	20441	20442	20443	20444	20445	20446	20447	20448	20449	20450	20451
19	20460	20461	20462	20463	20464	20465	20466	20467	20468	20469	20470	20471
20	20480	20481	20482	20483	20484	20485	20486	20487	20488	20489	20490	20491
21	20500	20501	20502	20503	20504	20505	20506	20507	20508	20509	20510	20511
22	20520	20521	20522	20523	20524	20525	20526	20527	20528	20529	20530	20531
23	20540	20541	20542	20543	20544	20545	20546	20547	20548	20549	20550	20551
24	20560	20561	20562	20563	20564	20565	20566	20567	20568	20569	20570	20571
25	20580	20581	20582	20583	20584	20585	20586	20587	20588	20589	20590	20591
26	20600	20601	20602	20603	20604	20605	20606	20607	20608	20609	20610	20611
27	20620	20621	20622	20623	20624	20625	20626	20627	20628	20629	20630	20631
28	20640	20641	20642	20643	20644	20645	20646	20647	20648	20649	20650	20651
29	20660	20661	20662	20663	20664	20665	20666	20667	20668	20669	20670	20671
30	20680	20681	20682	20683	20684	20685	20686	20687	20688	20689	20690	20691
31	20700	20701	20702	20703	20704	20705	20706	20707	20708	20709	20710	20711
32	20720	20721	20722	20723	20724	20725	20726	20727	20728	20729	20730	20731
33	20740	20741	20742	20743	20744	20745	20746	20747	20748	20749	20750	20751
34	20760	20761	20762	20763	20764	20765	20766	20767	20768	20769	20770	20771
35	20780	20781	20782	20783	20784	20785	20786	20787	20788	20789	20790	20791
36	20800	20801	20802	20803	20804	20805	20806	20807	20808	20809	20810	20811
37	20820	20821	20822	20823	20824	20825	20826	20827	20828	20829	20830	20831
38	20840	20841	20842	20843	20844	20845	20846	20847	20848	20849	20850	20851
39	20860	20861	20862	20863	20864	20865	20866	20867	20868	20869	20870	20871
40	20880	20881	20882	20883	20884	20885	20886	20887	20888	20889	20890	20891
41	20900	20901	20902	20903	20904	20905	20906	20907	20908	20909	20910	20911
42	20920	20921	20922	20923	20924	20925	20926	20927	20928	20929	20930	20931
43	20940	20941	20942	20943	20944	20945	20946	20947	20948	20949	20950	20951
44	20960	20961	20962	20963	20964	20965	20966	20967	20968	20969	20970	20971
45	20980	20981	20982	20983	20984	20985	20986	20987	20988	20989	20990	20991
46	21000	21001	21002	21003	21004	21005	21006	21007	21008	21009	21010	21011
47	21020	21021	21022	21023	21024	21025	21026	21027	21028	21029	21030	21031
48	21040	21041	21042	21043	21044	21045	21046	21047	21048	21049	21050	21051
49	21060	21061	21062	21063	21064	21065	21066	21067	21068	21069	21070	21071
50	21080	21081	21082	21083	21084	21085	21086	21087	21088	21089	21090	21091
51	21100	21101	21102	21103	21104	21105	21106	21107	21108	21109	21110	21111
52	21120	21121	21122	21123	21124	21125	21126	21127	21128	21129	21130	21131
53	21140	21141	21142	21143	21144	21145	21146	21147	21148	21149	21150	21151
54	21160	21161	21162	21163	21164	21165	21166	21167	21168	21169	21170	21171
55	21180	21181	21182	21183	21184	21185	21186	21187	21188	21189	21190	21191
56	21200	21201	21202	21203	21204	21205	21206	21207	21208	21209	21210	21211
57	21220	21221	21222	21223	21224	21225	21226	21227	21228	21229	21230	21231
58	21240	21241	21242	21243	21244	21245	21246	21247	21248	21249	21250	21251
59	21260	21261	21262	21263	21264	21265	21266	21267	21268	21269	21270	21271
60	21280	21281	21282	21283	21284	21285	21286	21287	21288	21289	21290	21291
61	21300	21301	21302	21303	21304	21305	21306	21307	21308	21309	21310	21311
62	21320	21321	21322	21323	21324	21325	21326	21327	21328	21329	21330	21331
63	21340	21341	21342	21343	21344	21345	21346	21347	21348	21349	21350	21351
64	21360	21361	21362	21363	21364	21365	21366	21367	21368	21369	21370	21371
65	21380	21381	21382	21383	21384	21385	21386	21387	21388	21389	21390	21391
66	21400	21401	21402	21403	21404	21405	21406	21407	21408	21409	21410	21411
67	21420	21421	21422	21423	21424	21425	21426	21427	21428	21429	21430	21431
68	21440	21441	21442	21443	21444	21445	21446	21447	21448	21449	21450	21451
69	21460	21461	21462	21463	21464	21465	21466	21467	21468	21469	21470	21471



70	21480	21481	21482	21483	21484	21485	21486	21487	21488	21489	21490	21491
71	21500	21501	21502	21503	21504	21505	21506	21507	21508	21509	21510	21511
72	21520	21521	21522	21523	21524	21525	21526	21527	21528	21529	21530	21531
73	21540	21541	21542	21543	21544	21545	21546	21547	21548	21549	21550	21551
74	21560	21561	21562	21563	21564	21565	21566	21567	21568	21569	21570	21571
75	21580	21581	21582	21583	21584	21585	21586	21587	21588	21589	21590	21591
76	21600	21601	21602	21603	21604	21605	21606	21607	21608	21609	21610	21611
77	21620	21621	21622	21623	21624	21625	21626	21627	21628	21629	21630	21631
78	21640	21641	21642	21643	21644	21645	21646	21647	21648	21649	21650	21651
79	21660	21661	21662	21663	21664	21665	21666	21667	21668	21669	21670	21671
80	21680	21681	21682	21683	21684	21685	21686	21687	21688	21689	21690	21691
81	21700	21701	21702	21703	21704	21705	21706	21707	21708	21709	21710	21711
82	21720	21721	21722	21723	21724	21725	21726	21727	21728	21729	21730	21731
83	21740	21741	21742	21743	21744	21745	21746	21747	21748	21749	21750	21751
84	21760	21761	21762	21763	21764	21765	21766	21767	21768	21769	21770	21771
85	21780	21781	21782	21783	21784	21785	21786	21787	21788	21789	21790	21791
86	21800	21801	21802	21803	21804	21805	21806	21807	21808	21809	21810	21811
87	21820	21821	21822	21823	21824	21825	21826	21827	21828	21829	21830	21831
88	21840	21841	21842	21843	21844	21845	21846	21847	21848	21849	21850	21851
89	21860	21861	21862	21863	21864	21865	21866	21867	21868	21869	21870	21871
90	21880	21881	21882	21883	21884	21885	21886	21887	21888	21889	21890	21891
91	21900	21901	21902	21903	21904	21905	21906	21907	21908	21909	21910	21911
92	21920	21921	21922	21923	21924	21925	21926	21927	21928	21929	21930	21931
93	21940	21941	21942	21943	21944	21945	21946	21947	21948	21949	21950	21951
94	21960	21961	21962	21963	21964	21965	21966	21967	21968	21969	21970	21971
95	21980	21981	21982	21983	21984	21985	21986	21987	21988	21989	21990	21991
96	22000	22001	22002	22003	22004	22005	22006	22007	22008	22009	22010	22011
97	22020	22021	22022	22023	22024	22025	22026	22027	22028	22029	22030	22031
98	22040	22041	22042	22043	22044	22045	22046	22047	22048	22049	22050	22051
99	22060	22061	22062	22063	22064	22065	22066	22067	22068	22069	22070	22071
100	22080	22081	22082	22083	22084	22085	22086	22087	22088	22089	22090	22091

## Accelerometer features

- Towing detection

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11600	UInt8	0	0	3	0 - Disable 1 - Low priority 2 - High priority 3 - Panic priority	Priority
11601	UInt8	1	0	1	Boolean	Eventual records
11602	UInt16	5	0	65535	Minutes	Activation timeout
11603	UInt8	0	0	60	Seconds	Event timeout
11604	UInt8	0	0	10	Phone number	Make call to
11605	Double	0.22	0.1	5	mG	Threshold
11606	Double	1	0.1	5	Degrees	Angle
11607	UInt16	1000	1	5000	Milliseconds	Duration

- Crash detection

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11400	UInt8	0	0	3	0 - Disable 1 - Low priority 2 - High priority 3 - Panic priority	Scenario setting
11401	UInt8	5	0	1000	Milliseconds	Duration
11402	UInt16	1500	0	7900	mG	Threshold
11406	UInt8	0	0	2	0 - Disable 1 - Trace Changes 2 - Trace Full	Crash Trace

- Excessive idling

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
11200	UInt8	0	0	3	0 - Disable 1 - Low priority 2 - High priority 3 - Panic priority	Scenario settings
11203	UInt8	1	0	1	Boolean	Eventual records
11205	UInt8	300	0	3600	Seconds	Time to stopped
11206	UInt8	5	0	3600	Seconds	Time to moving

- Accelerometer autocalibration

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
169	UInt8	1	0	1	Boolean	Accelerometer auto calibration

## Bluetooth

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
800	UInt8	0	0	2	0 - Disable 1 - Enable hidden 2 - Enable visible	Scenario settings

## iButton List

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
30000-30999	UInt64	0	0	0xFFFFFFFF	ID	iButton ID list

## I/O parameters

Parameter ID	Parameter Type	Default value	Value range		Parameter name
			Min	Max	
50000	UInt8	1	0	3	Ignition <a href="#">Priority</a>
50001	UInt8	5	0	6	Ignition <a href="#">Operand</a>
50002	UInt8	0	0	1	Ignition High level
50003	UInt8	0	0	1	Ignition Low level
50004	UInt8	0	0	1	Ignition <a href="#">Event only</a>
50005	UInt16	10	0	65535	Ignition Average
50010	UInt8	1	0	3	Movement <a href="#">Priority</a>
50011	UInt8	5	0	6	Movement <a href="#">Operand</a>
50012	UInt8	0	0	1	Movement High level
50013	UInt8	0	0	1	Movement Low level
50014	UInt8	0	0	1	Movement <a href="#">Event only</a>
50015	UInt16	1	0	65535	Movement Average
50020	UInt8	1	0	3	Data Mode <a href="#">Priority</a>
50021	UInt8	3	0	6	Data Mode Operand
50022	UInt8	0	0	5	Data Mode High level
50023	UInt8	0	0	5	Data Mode Low level
50024	UInt8	0	0	1	Data Mode <a href="#">Event only</a>
50030	UInt8	1	0	3	GSM Signal <a href="#">Priority</a>
50031	UInt8	3	0	6	GSM Signal <a href="#">Operand</a>
50032	UInt8	0	0	5	GSM Signal High level

50033	Uint8	0	0	5	GSM Signal Low level
50034	Uint8	0	0	1	GSM Signal <a href="#">Event only</a>
50035	Uint16	1	0	65535	GSM Signal Average
50040	Uint8	1	0	3	Sleep Mode <a href="#">Priority</a>
50041	Uint8	3	0	6	Sleep Mode <a href="#">Operand</a>
50042	Uint8	0	0	2	Sleep Mode High level
50043	Uint8	0	0	2	Sleep Mode Low level
50044	Uint8	0	0	1	Sleep Mode <a href="#">Event only</a>
50050	Uint8	1	0	3	GNSS Status <a href="#">Priority</a>
50051	Uint8	3	0	6	GNSS Status <a href="#">Operand</a>
50052	Uint8	0	0	5	GNSS Status High level
50053	Uint8	0	0	5	GNSS Status Low level
50053	Uint8	0	0	1	GNSS Status <a href="#">Event only</a>
50060	Uint8	0	0	3	GNSS PDOP <a href="#">Priority</a>
5061	Uint8	3	0	6	GNSS PDOP <a href="#">Operand</a>
5062	Uint16	0	0	1000	GNSS PDOP High level
5063	Uint16	0	0	1000	GNSS PDOP Low level
5064	Uint8	0	0	1	GNSS PDOP <a href="#">Event only</a>
5065	Uint16	10	0	65535	GNSS PDOP Average
50070	Uint8	1	0	3	GNSS HDOP <a href="#">Priority</a>
50071	Uint8	3	0	6	GNSS HDOP <a href="#">Operand</a>
50072	Uint16	0	0	1000	GNSS HDOP High level
50073	Uint16	0	0	1000	GNSS HDOP Low level
50074	Uint8	0	0	1	GNSS HDOP <a href="#">Event only</a>
50075	Uint16	10	0	65535	GNSS HDOP Average
50080	Uint8	1	0	3	External Voltage <a href="#">Priority</a>
50081	Uint8	6	0	6	External Voltage <a href="#">Operand</a>
50082	Uint16	1000	0	60000	External Voltage High level
50083	Uint16	0	0	60000	External Voltage Low level
50084	Uint8	0	0	1	External Voltage <a href="#">Event only</a>
50085	Uint16	10	0	65535	External Voltage Average
50090	Uint8	1	0	3	Speed <a href="#">Priority</a>
50091	Uint8	3	0	6	Speed <a href="#">Operand</a>
50092	Uint16	0	0	300	Speed High level
50093	Uint16	0	0	300	Speed Low level
50094	Uint8	0	0	1	Speed <a href="#">Event only</a>
50095	Uint16	1	0	65535	Speed Average
50100	Uint8	0	0	3	GSM Cell ID <a href="#">Priority</a>
50101	Uint8	3	0	6	GSM Cell ID <a href="#">Operand</a>
50102	Uint32	0	0	999999	GSM Cell ID High level
50103	Uint32	0	0	999999	GSM Cell ID Low level
50104	Uint8	0	0	1	GSM Cell ID <a href="#">Event only</a>
50110	Uint8	0	0	3	GSM Area Code <a href="#">Priority</a>
50111	Uint8	3	0	6	GSM Area Code <a href="#">Operand</a>
50112	Uint32	0	0	999999	GSM Area Code High level
50113	Uint32	0	0	999999	GSM Area Code Low level
50114	Uint8	0	0	1	GSM Area Code <a href="#">Event only</a>
50120	Uint8	1	0	3	Battery Voltage <a href="#">Priority</a>
50121	Uint8	3	0	6	Battery Voltage <a href="#">Operand</a>
50122	Uint16	0	0	5000	Battery Voltage High level
50123	Uint16	0	0	5000	Battery Voltage Low level
50124	Uint8	0	0	1	Battery Voltage <a href="#">Event only</a>
50125	Uint8	0	0	10	Battery Voltage Average
50130	Uint8	1	0	3	Battery Current <a href="#">Priority</a>
50131	Uint8	3	0	6	Battery Current <a href="#">Operand</a>
50132	Uint16	0	0	5000	Battery Current High level
50133	Uint16	0	0	5000	Battery Current Low level
50134	Uint8	0	0	1	Battery Current <a href="#">Event only</a>
50135	Uint8	0	0	10	Battery Current Average

50140	UInt8	0	0	3	Active GSM Operator <a href="#">Priority</a>
50141	UInt8	3	0	6	Active GSM Operator <a href="#">Operand</a>
50142	UInt32	0	0	999999	Active GSM Operator High level
50143	UInt32	0	0	999999	Active GSM Operator Low level
50144	UInt8	0	0	1	Active GSM Operator <a href="#">Event only</a>
50150	UInt8	0	0	3	Trip Odometer <a href="#">Priority</a>
50151	UInt8	3	0	6	Trip Odometer <a href="#">Operand</a>
50152	UInt32	0	0	1000000	Trip Odometer High level
50153	UInt32	0	0	1000000	Trip Odometer Low level
50154	UInt8	0	0	1	Trip Odometer <a href="#">Event only</a>
50160	UInt8	0	0	3	Total Odometer <a href="#">Priority</a>
50161	UInt8	3	0	6	Total Odometer <a href="#">Operand</a>
50162	UInt32	0	0	10000000	Total Odometer High level
50163	UInt32	0	0	10000000	Total Odometer Low level
50164	UInt8	0	0	1	Total Odometer <a href="#">Event only</a>
50170	UInt8	0	0	3	Digital Input 1 <a href="#">Priority</a>
50171	UInt8	3	0	6	Digital Input 1 <a href="#">Operand</a>
50172	UInt8	0	0	1	Digital Input 1 High level
50173	UInt8	0	0	1	Digital Input 1 Low level
50174	UInt8	0	0	1	Digital Input 1 <a href="#">Event only</a>
50175	UInt16	1	0	65535	Digital Input 1 Average
50270	UInt8	0	0	3	Digital Input 2 <a href="#">Priority</a>
50271	UInt8	3	0	6	Digital Input 2 <a href="#">Operand</a>
50272	UInt8	0	0	1	Digital Input 2 High level
50273	UInt8	0	0	1	Digital Input 2 Low level
50274	UInt8	0	0	1	Digital Input 2 <a href="#">Event only</a>
50275	UInt16	1	0	65535	Digital Input 2 Average
50280	UInt8	0	0	3	Digital Input 3 <a href="#">Priority</a>
50281	UInt8	3	0	6	Digital Input 3 <a href="#">Operand</a>
50872	UInt8	0	0	1	Digital Input 3 High level
50873	UInt8	0	0	1	Digital Input 3 Low level
50874	UInt8	0	0	1	Digital Input 3 <a href="#">Event only</a>
50875	UInt16	1	0	65535	Digital Input 3 Average
50660	UInt8	0	0	3	Digital Input 4 <a href="#">Priority</a>
50661	UInt8	3	0	6	Digital Input 4 <a href="#">Operand</a>
50662	UInt8	0	0	1	Digital Input 4 High level
50663	UInt8	0	0	1	Digital Input 4 Low level
50664	UInt8	0	0	1	Digital Input 4 <a href="#">Event only</a>
50665	UInt16	1	0	65535	Digital Input 4 Average
50180	UInt8	0	0	3	Analog Input 1 <a href="#">Priority</a>
50181	UInt8	3	0	6	Analog Input 1 <a href="#">Operand</a>
50182	UInt16	0	0	30000	Analog Input 1 High level
50183	UInt16	0	0	30000	Analog Input 1 Low level
50184	UInt8	0	0	1	Analog Input 1 <a href="#">Event only</a>
50185	UInt16	10	0	65535	Analog Input 1 Average
50290	UInt8	0	0	3	Analog Input 2 <a href="#">Priority</a>
50291	UInt8	3	0	6	Analog Input 2 <a href="#">Operand</a>
50292	UInt16	0	0	30000	Analog Input 2 High level
50293	UInt16	0	0	30000	Analog Input 2 Low level
50294	UInt8	0	0	1	Analog Input 2 <a href="#">Event only</a>
50295	UInt16	10	0	65535	Analog Input 2 Average
50670	UInt8	0	0	3	Analog Input 3 <a href="#">Priority</a>
50671	UInt8	3	0	6	Analog Input 3 <a href="#">Operand</a>
50672	UInt16	0	0	30000	Analog Input 3 High level
50673	UInt16	0	0	30000	Analog Input 3 Low level
50674	UInt8	0	0	1	Analog Input 3 <a href="#">Event only</a>
50675	UInt16	10	0	65535	Analog Input 3 Average
50680	UInt8	0	0	3	Analog Input 4 <a href="#">Priority</a>
50681	UInt8	3	0	6	Analog Input 4 <a href="#">Operand</a>

50682	Uint16	0	0	30000	Analog Input 4 High level
50683	Uint16	0	0	30000	Analog Input 4 Low level
50684	Uint8	0	0	1	Analog Input 4 <a href="#">Event only</a>
50685	Uint16	10	0	65535	Analog Input 4 Average
50190	Uint8	0	0	3	Digital Output 1 <a href="#">Priority</a>
50191	Uint8	0	0	6	Digital Output 1 <a href="#">Operand</a>
50192	Uint8	0	0	1	Digital Output 1 High level
50193	Uint8	0	0	1	Digital Output 1 Low level
50194	Uint8	0	0	1	Digital Output 1 <a href="#">Event only</a>
50195	Uint16	1	0	65535	Digital Output 1 Average
50300	Uint8	0	0	3	Digital Output 2 <a href="#">Priority</a>
50301	Uint8	0	0	6	Digital Output 2 <a href="#">Operand</a>
50302	Uint8	0	0	1	Digital Output 2 High level
50303	Uint8	0	0	1	Digital Output 2 Low level
50304	Uint8	0	0	1	Digital Output 2 <a href="#">Event only</a>
50305	Uint16	1	0	65535	Digital Output 2 Average
50690	Uint8	0	0	3	Digital Output 3 <a href="#">Priority</a>
50691	Uint8	0	0	6	Digital Output 3 <a href="#">Operand</a>
50192	Uint8	0	0	1	Digital Output 3 High level
50693	Uint8	0	0	1	Digital Output 3 Low level
50694	Uint8	0	0	1	Digital Output 3 <a href="#">Event only</a>
50695	Uint16	1	0	65535	Digital Output 3 Average
50700	Uint8	0	0	3	Digital Output 4 <a href="#">Priority</a>
50701	Uint8	0	0	6	Digital Output 4 <a href="#">Operand</a>
50702	Uint8	0	0	1	Digital Output 4 High level
50703	Uint8	0	0	1	Digital Output 4 Low level
50704	Uint8	0	0	1	Digital Output 4 <a href="#">Event only</a>
50705	Uint16	1	0	65535	Digital Output 4 Average
50220	Uint8	0	0	3	Axis X <a href="#">Priority</a>
50221	Uint8	3	0	6	Axis X <a href="#">Operand</a>
50222	Uint16	0	-8000	8000	Axis X High level
50223	Uint16	0	-8000	8000	Axis X Low level
50224	Uint8	0	0	1	Axis X <a href="#">Event only</a>
50225	Uint16	1	0	65535	Axis X Average
50230	Uint8	0	0	3	Axis Y <a href="#">Priority</a>
50231	Uint8	3	0	6	Axis Y <a href="#">Operand</a>
50232	Uint16	0	-8000	8000	Axis Y High level
50233	Uint16	0	-8000	8000	Axis Y Low level
50234	Uint8	0	0	1	Axis Y <a href="#">Event only</a>
50235	Uint16	1	0	65535	Axis Y Average
50240	Uint8	0	0	3	Axis Z <a href="#">Priority</a>
50241	Uint8	3	0	6	Axis Z <a href="#">Operand</a>
50242	Uint16	0	-8000	8000	Axis Z High level
50243	Uint16	0	-8000	8000	Axis Z Low level
50244	Uint8	0	0	1	Axis Z <a href="#">Event only</a>
50245	Uint16	1	0	65535	Axis Z Average
50820	Uint8	0	0	3	IMSI <a href="#">Priority</a>
50821	Uint8	0	0	6	IMSI <a href="#">Operand</a>
50822	Uint8	0	0	1	IMSI <a href="#">Event only</a>
50250	Uint8	0	0	3	ICCID <a href="#">Priority</a>
50251	Uint8	3	0	6	ICCID <a href="#">Operand</a>
50254	Uint8	0	0	1	ICCID <a href="#">Event only</a>
50260	Uint8	0	0	3	SD Status <a href="#">Priority</a>
50261	Uint8	3	0	6	SD Status <a href="#">Operand</a>
50262	Uint8	0	0	1	SD Status High level
50263	Uint8	0	0	1	SD Status Low level
50310	Uint8	0	0	3	Dallas Temperature 1 <a href="#">Priority</a>
50311	Uint8	3	0	6	Dallas Temperature 1 <a href="#">Operand</a>
50312	Int8	0	-55	125	Dallas Temperature 1 High level

50313	Int8	0	-55	125	Dallas Temperature 1 Low level
50314	UInt8	0	0	1	Dallas Temperature 1 <a href="#">Event only</a>
50315	UInt16	0	0	65535	Dallas Temperature 1 Average
50320	UInt8	0	0	3	Dallas Temperature 2 <a href="#">Priority</a>
50321	UInt8	3	0	6	Dallas Temperature 2 <a href="#">Operand</a>
50322	Int8	0	-55	125	Dallas Temperature 2 High level
50323	Int8	0	-55	125	Dallas Temperature 2 Low level
50324	UInt8	0	0	1	Dallas Temperature 2 <a href="#">Event only</a>
50325	UInt16	0	0	65535	Dallas Temperature 2 Average
50330	UInt8	0	0	3	Dallas Temperature 3 <a href="#">Priority</a>
50331	UInt8	3	0	6	Dallas Temperature 3 <a href="#">Operand</a>
50332	Int8	0	-55	125	Dallas Temperature 3 High level
50333	Int8	0	-55	125	Dallas Temperature 3 Low level
50334	UInt8	0	0	1	Dallas Temperature 3 <a href="#">Event only</a>
50335	UInt16	0	0	65535	Dallas Temperature 3 Average
50340	UInt8	0	0	3	Dallas Temperature 4 <a href="#">Priority</a>
50341	UInt8	3	0	6	Dallas Temperature 4 <a href="#">Operand</a>
50342	Int8	0	-55	125	Dallas Temperature 4 High level
50343	Int8	0	-55	125	Dallas Temperature 4 Low level
50344	UInt8	0	0	1	Dallas Temperature 4 <a href="#">Event only</a>
50345	UInt16	0	0	65535	Dallas Temperature 4 Average
50720	UInt8	0	0	3	Dallas Temperature 5 <a href="#">Priority</a>
50721	UInt8	3	0	6	Dallas Temperature 5 <a href="#">Operand</a>
50722	Int8	0	-55	125	Dallas Temperature 5 High level
50723	Int8	0	-55	125	Dallas Temperature 5 Low level
50724	UInt8	0	0	1	Dallas Temperature 5 <a href="#">Event only</a>
50725	UInt16	0	0	65535	Dallas Temperature 5 Average
50750	UInt8	0	0	3	Dallas Temperature 6 <a href="#">Priority</a>
50751	UInt8	3	0	6	Dallas Temperature 6 <a href="#">Operand</a>
50752	Int8	0	-55	125	Dallas Temperature 6 High level
50753	Int8	0	-55	125	Dallas Temperature 6 Low level
50754	UInt8	0	0	1	Dallas Temperature 6 <a href="#">Event only</a>
50755	UInt16	0	0	65535	Dallas Temperature 6 Average
50350	UInt8	0	0	3	Dallas Temperature ID 1 <a href="#">Priority</a>
50351	UInt8	3	0	6	Dallas Temperature ID 1 <a href="#">Operand</a>
50352	UInt32	0	0	999999999	Dallas Temperature ID 1 High level
50353	UInt32	0	0	999999999	Dallas Temperature ID 1 Low level
50354	UInt8	0	0	1	Dallas Temperature ID 1 <a href="#">Event only</a>
50355	UInt16	0	0	65535	Dallas Temperature ID 1 Average
50360	UInt8	0	0	3	Dallas Temperature ID 2 <a href="#">Priority</a>
50361	UInt8	3	0	6	Dallas Temperature ID 2 <a href="#">Operand</a>
50362	UInt32	0	0	999999999	Dallas Temperature ID 2 High level
50363	UInt32	0	0	999999999	Dallas Temperature ID 2 Low level
50364	UInt8	0	0	1	Dallas Temperature ID 2 <a href="#">Event only</a>
50365	UInt16	0	0	65535	Dallas Temperature ID 2 Average
50370	UInt8	0	0	3	Dallas Temperature ID 3 <a href="#">Priority</a>
50371	UInt8	3	0	6	Dallas Temperature ID 3 <a href="#">Operand</a>
50372	UInt32	0	0	999999999	Dallas Temperature ID 3 High level
50373	UInt32	0	0	999999999	Dallas Temperature ID 3 Low level
50374	UInt8	0	0	1	Dallas Temperature ID 3 <a href="#">Event only</a>
50375	UInt16	0	0	65535	Dallas Temperature ID 3 Average
50380	UInt8	0	0	3	Dallas Temperature ID 4 <a href="#">Priority</a>
50381	UInt8	3	0	6	Dallas Temperature ID 4 <a href="#">Operand</a>
50382	UInt32	0	0	999999999	Dallas Temperature ID 4 High level
50383	UInt32	0	0	999999999	Dallas Temperature ID 4 Low level
50384	UInt8	0	0	1	Dallas Temperature ID 4 <a href="#">Event only</a>
50385	UInt16	0	0	65535	Dallas Temperature ID 4 Average
50740	UInt8	0	0	3	Dallas Temperature ID 5 <a href="#">Priority</a>
50741	UInt8	3	0	6	Dallas Temperature ID 5 <a href="#">Operand</a>

50742	Uint32	0	0	999999999	Dallas Temperature ID 5 High level
50743	Uint32	0	0	999999999	Dallas Temperature ID 5 Low level
50744	Uint8	0	0	1	Dallas Temperature ID 5 <a href="#">Event only</a>
50745	Uint16	0	0	65535	Dallas Temperature ID 5 Average
50750	Uint8	0	0	3	Dallas Temperature ID 6 <a href="#">Priority</a>
50751	Uint8	3	0	6	Dallas Temperature ID 6 <a href="#">Operand</a>
50752	Uint32	0	0	999999999	Dallas Temperature ID 6 High level
50753	Uint32	0	0	999999999	Dallas Temperature ID 6 Low level
50754	Uint8	0	0	1	Dallas Temperature ID 6 <a href="#">Event only</a>
50755	Uint16	0	0	65535	Dallas Temperature ID 6 Average
50390	Uint8	0	0	3	iButton <a href="#">Priority</a>
50391	Uint8	3	0	6	iButton <a href="#">Operand</a>
50392	Uint32	0	0	999999999	iButton High level
50393	Uint32	0	0	999999999	iButton Low level
50394	Uint8	0	0	1	iButton <a href="#">Event only</a>
50395	Uint16	0	0	65535	iButton Average
50400	Uint8	0	0	3	RFID <a href="#">Priority</a>
50401	Uint8	3	0	6	RFID <a href="#">Operand</a>
50402	Uint8	0	0	999999999	RFID High level
50403	Uint8	0	0	999999999	RFID Low level
50404	Uint8	0	0	1	RFID <a href="#">Event only</a>
50405	Uint16	1	0	65535	RFID Average
50710	Uint8	0	0	3	RFID2 <a href="#">Priority</a>
50711	Uint8	3	0	6	RFID2 <a href="#">Operand</a>
50712	Uint8	0	0	999999999	RFID2 High level
50713	Uint8	0	0	999999999	RFID2 Low level
50714	Uint8	0	0	1	RFID2 <a href="#">Event only</a>
50715	Uint16	1	0	65535	RFID2 Average
50410	Uint8	0	0	3	LLS1 Fuel Level <a href="#">Priority</a>
50411	Uint8	3	0	6	LLS1 Fuel Level <a href="#">Operand</a>
50412	Uint8	0	0	65535	LLS1 Fuel Level High level
50413	Uint8	0	0	65535	LLS1 Fuel Level Low level
50414	Uint8	0	0	1	LLS1 Fuel Level <a href="#">Event only</a>
50415	Uint16	1	0	65535	LLS1 Fuel Level Average
50420	Uint8	0	0	3	LLS2 Fuel Level <a href="#">Priority</a>
50421	Uint8	3	0	6	LLS2 Fuel Level <a href="#">Operand</a>
50422	Uint8	0	0	65535	LLS2 Fuel Level High level
50423	Uint8	0	0	65535	LLS2 Fuel Level Low level
50424	Uint8	0	0	1	LLS2 Fuel Level <a href="#">Event only</a>
50425	Uint16	1	0	65535	LLS2 Fuel Level Average
50430	Uint8	0	0	3	LLS3 Fuel Level <a href="#">Priority</a>
50431	Uint8	3	0	6	LLS3 Fuel Level <a href="#">Operand</a>
50432	Uint8	0	0	65535	LLS3 Fuel Level High level
50433	Uint8	0	0	65535	LLS3 Fuel Level Low level
50434	Uint8	0	0	1	LLS3 Fuel Level <a href="#">Event only</a>
50435	Uint16	1	0	65535	LLS3 Fuel Level Average
50440	Uint8	0	0	3	LLS4 Fuel Level <a href="#">Priority</a>
50441	Uint8	3	0	6	LLS4 Fuel Level <a href="#">Operand</a>
50442	Uint8	0	0	65535	LLS4 Fuel Level High level
50443	Uint8	0	0	65535	LLS4 Fuel Level Low level
50444	Uint8	0	0	1	LLS4 Fuel Level <a href="#">Event only</a>
50445	Uint16	1	0	65535	LLS4 Fuel Level Average
50450	Uint8	0	0	3	LLS5 Fuel Level <a href="#">Priority</a>
50451	Uint8	3	0	6	LLS5 Fuel Level <a href="#">Operand</a>
50452	Uint8	0	0	65535	LLS5 Fuel Level High level
50453	Uint8	0	0	65535	LLS5 Fuel Level Low level
50454	Uint8	0	0	1	LLS5 Fuel Level <a href="#">Event only</a>
50455	Uint16	1	0	65535	LLS5 Fuel Level Average
50460	Uint8	0	0	3	LLS1 Temperature <a href="#">Priority</a>



50461	Uint8	3	0	6	LLS1 Temperature <a href="#">Operand</a>
50462	Uint8	0	-128	127	LLS1 Temperature High level
50463	Uint8	0	-128	127	LLS1 Temperature Low level
50464	Uint8	0	0	1	LLS1 Temperature <a href="#">Event only</a>
50465	Uint16	1	0	65535	LLS1 Temperature Average
50470	Uint8	0	0	3	LLS2 Temperature <a href="#">Priority</a>
50471	Uint8	3	0	6	LLS2 Temperature <a href="#">Operand</a>
50472	Uint8	0	-128	127	LLS2 Temperature High level
50473	Uint8	0	-128	127	LLS2 Temperature Low level
50474	Uint8	0	0	1	LLS2 Temperature <a href="#">Event only</a>
50475	Uint16	1	0	65535	LLS2 Temperature Average
50480	Uint8	0	0	3	LLS3 Temperature <a href="#">Priority</a>
50481	Uint8	3	0	6	LLS3 Temperature <a href="#">Operand</a>
50482	Uint8	0	-128	127	LLS3 Temperature High level
50483	Uint8	0	-128	127	LLS3 Temperature Low level
50484	Uint8	0	0	1	LLS3 Temperature <a href="#">Event only</a>
50485	Uint16	1	0	65535	LLS3 Temperature Average
50490	Uint8	0	0	3	LLS4 Temperature <a href="#">Priority</a>
50491	Uint8	3	0	6	LLS4 Temperature <a href="#">Operand</a>
50492	Uint8	0	-128	127	LLS4 Temperature High level
50493	Uint8	0	-128	127	LLS4 Temperature Low level
50494	Uint8	0	0	1	LLS4 Temperature <a href="#">Event only</a>
50495	Uint16	1	0	65535	LLS4 Temperature Average
50500	Uint8	0	0	3	LLS5 Temperature <a href="#">Priority</a>
50501	Uint8	3	0	6	LLS5 Temperature <a href="#">Operand</a>
50502	Uint8	0	-128	127	LLS5 Temperature High level
50503	Uint8	0	-128	127	LLS5 Temperature Low level
50504	Uint8	0	0	1	LLS5 Temperature <a href="#">Event only</a>
50505	Uint16	1	0	65535	LLS5 Temperature Average
50780	Uint8	0	0	3	Ultrasonic UL202 Fuel level 1 <a href="#">Priority</a>
50781	Uint8	3	0	6	Ultrasonic UL202 Fuel level 1 <a href="#">Operand</a>
50782	Uint8	0	-20	32767	Ultrasonic UL202 Fuel level 1 High level
50783	Uint8	0	-20	32767	Ultrasonic UL202 Fuel level 1 Low level
50784	Uint8	0	0	1	Ultrasonic UL202 Fuel level 1 <a href="#">Event only</a>
50785	Uint16	1	0	65535	Ultrasonic UL202 Fuel level 1 Average
50790	Uint8	0	0	3	Ultrasonic UL202 Fuel level 2 <a href="#">Priority</a>
50791	Uint8	3	0	6	Ultrasonic UL202 Fuel level 2 <a href="#">Operand</a>
50792	Uint8	0	-20	32767	Ultrasonic UL202 Fuel level 2 High level
50793	Uint8	0	-20	32767	Ultrasonic UL202 Fuel level 2 Low level
50794	Uint8	0	0	1	Ultrasonic UL202 Fuel level 2 <a href="#">Event only</a>
50795	Uint16	1	0	65535	Ultrasonic UL202 Fuel level 2 Average
50800	Uint8	0	0	3	Ultrasonic UL202 Status 1 <a href="#">Priority</a>
50801	Uint8	3	0	6	Ultrasonic UL202 Status 1 <a href="#">Operand</a>
50802	Uint8	0	0	255	Ultrasonic UL202 Status 1 High level
50803	Uint8	0	0	255	Ultrasonic UL202 Status 1 Low level
50804	Uint8	0	0	1	Ultrasonic UL202 Status 1 <a href="#">Event only</a>
50805	Uint16	1	0	65535	Ultrasonic UL202 Status 1 Average
50810	Uint8	0	0	3	Ultrasonic UL202 Status 2 <a href="#">Priority</a>
50811	Uint8	3	0	6	Ultrasonic UL202 Status 2 <a href="#">Operand</a>
50812	Uint8	0	0	255	Ultrasonic UL202 Status 2 High level
50813	Uint8	0	0	255	Ultrasonic UL202 Status 2 Low level
50814	Uint8	0	0	1	Ultrasonic UL202 Status 2 <a href="#">Event only</a>
50815	Uint16	1	0	65535	Ultrasonic UL202 Status 2
50650	Uint8	0	0	3	Network type <a href="#">Priority</a>
50651	Uint8	3	0	6	Network type <a href="#">Operand</a>
50652	Uint8	0	0	1	Network type High level
50653	Uint8	0	0	1	Network type Low level
50654	Uint8	0	0	1	Network type <a href="#">Event only</a>



- I/O parameters and types

Parameter name	Value
<b>Priority</b>	0 - Disabled
	1 - Low
	2 - High
	3 - Panic
<b>Operand</b>	0 - On Exit
	1 - On Entrance
	2 - On Both
	3 - Monitoring
	4 - On Hysteresis
	5 - On Change
<b>Event only</b>	0 - Disabled
	1 - Enabled

## LVCAN

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
45000	Uint8	0	0	2	0 - Auto detect 1 - LV-CAN200 2 - ALL-CAN300	LVCAN Mode
45001	Uint8	0	0	1	0 - Disable 1 - Enable	Send data with 0, if ignition is off
45002	Uint16	0	0	99999	Value	Program number

- LVCAN parameter configuration

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
45100	Uint8	0	0	3	0 - Disabled 1 - Low 2 - High 3 - Panic	Priority
45101	Uint8	3	0	6	0 - On range exit 1 - On range entrance 2 - On both 3 - Monitoring 4 - Hysteresis 5 - On change 6 - On delta change	Operand
45102	Uint8	0	0	255	High value	High level
45103	Uint8	0	0	255	Low value	Low level
45104	Uint8	0	0	1	0 - Disable 1 - Enable	Event only
45105	Uint16	10	0	65535	Value	Averaging constant

Similarly to a group defined in the upper table:

# FMS

- FMS parameter configuration:

Name	Parameter				
	Priority	Operand	High level	Low level	Event only
Brake switch	46000	46001	-	-	46004
Wheel based speed	46010	46011	46012	46013	46014
Cruise control active	46020	46021	-	-	46024
Clutch switch	46030	46031	-	-	46034
PTO state	46040	46041	-	-	46044
Accelerator pedal position 1 X	46050	46051	46052	46053	46054
Engine Percent Load At Current Speed X	46060	46061	46062	46063	46064
Engine total fuel used	46070	46071	46072	46073	46074
fuel level 1 X	46080	46081	46082	46083	46084
Engine speed X	46090	46091	46092	46093	46094
Axle location (every 10)	46100-46240	46101-46241	46102-46242	46103-46243	46104-46244
Tire location	-	-	-	-	-
Axle weight	-	-	-	-	-
Engine total hours of Operation X	46250	46251	46252	46253	46254
vehicle identification number X	46260	46261	-	-	46264
SW-version supported X	46270	46271	-	-	46274
Diagnostics supported X	46280	46281	-	-	46284
Requests supported X	46290	46291	-	-	46294
Service distance	46310	46311	46312	46313	46314
Direction indicator	46400	46401	-	-	46404
Tachograph performance X	46410	46411	-	-	46414
Handling information X	46420	46421	-	-	46424
System event X	46430	46431	-	-	46434
engine coolant temperature X	46450	46451	46452	46453	46454
Ambient Air Temperature X	46460	46461	46462	46463	46464
Fuel rate	46490	46491	46492	46493	46494
Instantaneous Fuel Economy	46500	46501	46502	46503	46504
PTO drive engagement	46510	46511	-	-	46514
High resolution engine total fuel used	46520	46521	46522	46523	46524
Combined vehicle weight	46530	46531	46532	46533	46534
AdBlue Status	46550	46551	-	-	46554
Fuel Level 2	46560	46561	-	-	46564
Engine MIL Indicator	46570	46571	-	-	46574
Tell Tale ID0	46580	46581	-	-	46584
Tell Tale ID1	46590	46591	-	-	46594
Tell Tale ID2	46600	46601	-	-	46604
Tell Tale ID3	46610	46611	-	-	46614

## Manual CAN

- Manual CAN parameter configuration:

Example: setparam 47290:2;47291:96;47292:218047805;47293:0;47294:5

CAN9	0	Disabled	Standard (11-bit)	Extended (29-bit)	MSB <input type="checkbox"/>	8 <input type="checkbox"/>	7 <input checked="" type="checkbox"/>	6 <input checked="" type="checkbox"/>	5 <input type="checkbox"/>	4 <input type="checkbox"/>	3 <input type="checkbox"/>	2 <input type="checkbox"/>	1 <input type="checkbox"/>	LSB	On Change	0CFF253D	CAN1	CAN2
<b>Priority</b>	<b>Output Data Mask</b>				<b>CAN ID</b>					<b>CAN SOURCE</b>		<b>Operand</b>						

0 - Disable  
 1 - 11bit  
 2 - 29bit

Decimal value

4 bytes HEX identifier.

For more information check [Manual CAN page](#)

0 - CAN1  
 1 - CAN2

3 - Monitoring  
 5 - OnChange

Name	Parameter				
	Priority	Output Data Mask	CAN ID	CAN Source	Operand
CAN0	47000	47001	47002	47003	47004
CAN1	47010	47011	47012	47013	47014
CAN2	47020	47021	47022	47023	47024
CAN3	47030	47031	47032	47033	47034
CAN4	47040	47041	47042	47043	47044
CAN5	47050	47051	47052	47053	47054
CAN6	47060	47061	47062	47063	47064
CAN7	47070	47071	47072	47073	47074
CAN8	47080	47081	47082	47083	47084
CAN9	47090	47091	47092	47093	47094
CAN10	47200	47201	47202	47203	47204
CAN11	47210	47211	47212	47213	47214
CAN12	47220	47221	47222	47223	47224
CAN13	47230	47231	47232	47233	47234
CAN14	47240	47241	47242	47243	47244
CAN15	47250	47251	47252	47253	47254
CAN16	47260	47261	47262	47263	47264
CAN17	47270	47271	47272	47273	47274
CAN18	47280	47281	47282	47283	47284
CAN19	47290	47291	47292	47293	47294
CAN20	90000	90001	90002	90003	90004
CAN21	90010	90011	90012	90013	90014
CAN22	90020	90021	90022	90023	90024
CAN23	90030	90031	90032	90033	90034
CAN24	90040	90041	90042	90043	90044
CAN25	90050	90051	90052	90053	90054
CAN26	90060	90061	90062	90063	90064
CAN27	90070	90071	90072	90073	90074
CAN28	90080	90081	90082	90083	90084
CAN29	90090	90091	90092	90093	90094
CAN30	90100	90101	90102	90103	90104
CAN31	90110	90111	90112	90113	90114
CAN32	90120	90121	90122	90123	90124
CAN33	90130	90131	90132	90133	90134
CAN34	90140	90141	90142	90143	90144
CAN35	90150	90151	90152	90153	90154
CAN36	90160	90161	90162	90163	90164
CAN37	90170	90171	90172	90173	90174
CAN38	90180	90181	90182	90183	90184
CAN39	90190	90191	90192	90193	90194
CAN40	90200	90201	90202	90203	90204
CAN41	90210	90211	90212	90213	90214
CAN42	90220	90221	90222	90223	90224
CAN43	90230	90231	90232	90233	90234
CAN44	90240	90241	90242	90243	90244
CAN45	90250	90251	90252	90253	90254
CAN46	90260	90261	90262	90263	90264
CAN47	90270	90271	90272	90273	90274

CAN48	90280	90281	90282	90283	90284
CAN49	90290	90291	90292	90293	90294
CAN50	90300	90301	90302	90303	90304
CAN51	90310	90311	90312	90313	90314
CAN52	90320	90321	90322	90323	90324
CAN53	90330	90331	90332	90333	90334
CAN54	90340	90341	90342	90343	90344
CAN55	90350	90351	90352	90353	90354
CAN56	90360	90361	90362	90363	90364
CAN57	90370	90371	90372	90373	90374
CAN58	90380	90381	90382	90383	90384
CAN59	90390	90391	90392	90393	90394
CAN60	90400	90401	90402	90403	90404
CAN61	90410	90411	90412	90413	90414
CAN62	90420	90421	90422	90423	90424
CAN63	90430	90431	90432	90433	90434
CAN64	90440	90441	90442	90443	90444
CAN65	90450	90451	90452	90453	90454
CAN66	90460	90461	90462	90463	90464
CAN67	90470	90471	90472	90473	90474
CAN68	90480	90481	90482	90483	90484
CAN69	90490	90491	90492	90493	90494

## Tachograph data

- Vehicle Data Priority Settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
71090	Uint8	0	0	4	0 - Disable	K-line priority
					1 - Priority 1	
					2 - Priority 2	
					3 - Priority 3	
					4 - Priority 4	
71091	Uint8	0	0	4	0 - Disable	ALLCAN priority
					1 - Priority 1	
					2 - Priority 2	
					3 - Priority 3	
					4 - Priority 4	
71092	Uint8	0	0	4	0 - Disable	TachoCAN priority
					1 - Priority 1	
					2 - Priority 2	
					3 - Priority 3	
					4 - Priority 4	
71093	Uint8	0	0	4	0 - Disable	FMS priority
					1 - Priority 1	
					2 - Priority 2	
					3 - Priority 3	
					4 - Priority 4	

- Tachograph Settings

Parameter ID	Parameter Type	Default value	Value range		Parameter name
			Min	Max	

230	Uint32	0	0	99999999	Tachograph periodic record timeout	Parameter ID	Parameter Type	Default value	Value range	Value	Parameter name
Min	Max										
231	Uint8	0	0	1		0 - Disable 1 - Enable	Send data with last good value				
Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name					
			Min	Max							
232	Uint8	0	0	1	0 - Disable 1 - Enable	Include Tachograph data into regular record					

- Tachograph parameter configuration

Name	Parameter				
	Priority	Operand	High level	Low level	Event only
Timestamp	47500	475001	-	-	47504
Drive recognize	47510	47511	-	-	47514
Over speeding	47520	47521	-	-	47524
Vehicle speed	47530	47531	47532	47533	47534
Odometer	47540	47541	-	-	47544
Distance	47550	47551	-	-	47554
VIN	47560	47561	-	-	47564
VRN	47570	47571	-	-	47574
Driver 1 working state	47580	47581	-	-	47583
Driver 2 working state	47591	47592	-	-	47583
Driver 1 card	47600	47601	-	-	47604
Driver 2 card	47610	47611	-	-	47514
Driver 1 Time related states	47620	47621	-	-	47624
Driver 2 Time related states	47630	47631	-	-	47634
Driver 1 identification number	47640	47641	-	-	47644
Driver 2 identification number	47650	47651	-	-	47654
Card 1 issuing member state	47660	47661	-	-	47664
Card 2 issuing member state	47670	47671	-	-	47674
Driver 1 Continuous Drive time	47680	47681	-	-	47684
Driver 2 Continuous Drive time	47690	47691	-	-	47694
Driver 1 Cumulative Break time	47700	47701	-	-	47704
Driver 2 Cumulative Break time	47710	47711	-	-	47714
Driver 1 Selected activity duration	47720	47721	-	-	47724
Driver 2 Selected activity duration	47730	47731	-	-	47734
Driver 1 Cumulative Driving time	47740	47741	-	-	47744
Driver 2 Cumulative Driving time	47750	47751	-	-	47754
Data Source	47770	47771	-	-	47774
Drivers hours rules pre warning time delay	47780	47781	-	-	47784
Out of scope condition	47790	47791	-	-	47794
Next calibration date	47800	47801	-	-	47804
Driver 1 end of last daily rest report	47810	47811	-	-	47814
Driver 2 end of last daily rest report	47880	47881	-	-	47884
Driver 1 end of last weekly rest period	47820	47821	-	-	47824
Driver 2 end of last weekly rest period	47890	47891	-	-	47894
Driver 1 end of second last weekly rest period	47830	47831	-	-	47834
Driver 2 end of second last weekly rest period	47900	47901	-	-	47904
Driver 1 current daily driving time	47840	47841	-	-	47844
Driver 2 current daily driving time	47910	47911	-	-	47914
Driver 1 current weekly driving time	47850	47851	-	-	47854
Driver 2 current weekly driving time	47920	47921	-	-	47924
Driver 1 time left until new daily rest period	47860	47861	-	-	47864
Driver 2 time left until new daily rest period	47930	47931	-	-	47934
Driver 1 number of times 9h daily driving time exceeds	47870	47871	-	-	47874
Driver 2 number of times 9h daily driving time exceeds	47940	47941	-	-	47944
Driver 1 Name	47950	47951	-	-	47954

Driver 1 Surname	47960	47961	-	-	47964
Driver 2 Name	47970	47971	-	-	47974
Driver 2 Surname	47980	47981	-	-	47984

## RS232/RS485

- Garmin

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
157	Uint8	0	0	3	0 - No filter 1 - Ping filter 2 - Unicode filter 3 - Ping and Unicode filters	Garmin Features

- RS485

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
160	Uint8	0	0	8	0 - Disable 1 - Silent 2 - Log Mode 3 - NMEA 4 - LLS 5 - TCP ASCII 6 - TCP Binary 7 - TCP ASCII Buffered 8 - TCP Binary Buffered	RS485 working mode
161	Uint8	Depends on selected Mode	0	115200	0 - Default 1200 2400 9600 14400 19200 38400 57600 115200	Baudrate

- LLS

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
162	Uint8	0	0	254	Number	LLS 1 Address
163	Uint8	0	0	254	Number	LLS 2 Address
164	Uint8	0	0	254	Number	LLS 3 Address
165	Uint8	0	0	254	Number	LLS 4 Address
166	Uint8	0	0	254	Number	LLS 5 Address

- RS232 COM1

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		

<b>151</b>	UInt8	0	0	14	0 - Silent 1 - Log Mode 2 - NMEA 3 - LLS 4 - LCD 5 - RFID HID 6 - RFID MF7 7 - Garmin FMI 8 - TCP ASCII 9 - TCP Binary 10 - TCP ASCII Buffered 11 - TCP Binary Buffered 12 - REC to LCD 13 - ATOL tachograph 14 - UL202-2 Fuel Sensor	Mode
<b>152</b>	UInt8	Depends on selected Mode	0	115200	0 - Default 1200 2400 9600 4400 19200 38400 57600 115200	Baudrate

• RS232 COM2

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
<b>173</b>	UInt8	0	0	14	0 - Silent 1 - Log Mode 2 - NMEA 3 - LLS 4 - LCD 5 - RFID HID 6 - RFID MF7 7 - Garmin FMI 8 - TCP ASCII 9 - TCP Binary 10 - TCP ASCII Buffered 11 - TCP Binary Buffered 12 - REC to LCD 13 - ATOL tachograph 14 - UL202-2 Fuel Sensor	Mode

174	Uint8	Depends on selected Mode	0	115200	0 - Default 1200 2400 9600 14400 19200 38400 57600 115200	Baudrate
-----	-------	--------------------------	---	--------	---	----------

## CAN \ Tachograph

- CAN1 Bus Settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
205	Uint16	250	0	1000	Bus speed	CAN1 Bus Speed
206	Uint8	0	0	1	0 - Silent 1 - Normal	CAN1 Bus Mode

- CAN2 Bus Settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
207	Uint16	250	0	1000	Bus speed	CAN2 Bus Speed
208	Uint8	0	0	1	0 - Silent 1 - Normal	CAN2 Bus Mode

- Tachograph Settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
209	Uint8	1	0	1	0 - CAN1 1 - CAN2	Tachograph DDD download source
200	Uint8	0	0	1	Boolean	Tachograph WEB Enable
201	S8[55]	empty	empty	55 symbols	Internet address	WEB Tacho Domain
202	Uint16	0	0	65535	Port number	WEB Tacho Port
203	Uint8	0	0	255	Minutes	WEB Tacho start delay
204	Uint8	0	0	4	0 - Ignition 1 - DIN1 2 - DIN2 3 - DIN3 4 - DIN4	Tachograph ignition source

- FMS Settings

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
210	Uint8	0	0	1	0 - CAN1 1 - CAN2	FMS data source
212	Uint8	0	0	1	0 - CAN1 1 - CAN2	Manual CAN Settings



# Continental TPMS

- TPMS Request Period

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
65026	Uint16	0	0	65535	Time	TPMS Period

- Continental TPMS parameter configuration

Name	Parameter				
	Priority	Operand	High level	Low level	Event only
Total Tire Controlled	80000	80001	80002	80003	80004
Total Number of AXL	80010	80011	80012	80013	80014
Graphical Position	80020	80021	80022	80023	80024
Tire 1	80030	80031	80032	80033	80034
Tire 2	80040	80041	80042	80043	80044
Tire 3	80050	80051	80052	80053	80054
Tire 4	80060	80061	80062	80063	80064
Tire 5	80070	80071	80072	80073	80074
Tire 6	80080	80081	80082	80083	80084
Tire 7	80090	80091	80092	80093	80094
Tire 8	80100	80101	80102	80103	80104
Tire 9	80110	80111	80112	80113	80114
Tire 10	80120	80121	80122	80123	80124
Tire 11	80130	80131	80132	80133	80134
Tire 12	80140	80141	80142	80143	80144
Tire 13	80150	80151	80152	80153	80154
Tire 14	80160	80161	80162	80163	80164
Tire 15	80170	80171	80172	80173	80174
Tire 16	80180	80181	80182	80183	80184
Tire 17	80190	80191	80192	80193	80194
Tire 18	80200	80201	80202	80203	80204
Tire 19	80210	80211	80212	80213	80214
Tire 20	80220	80221	80222	80223	80224
Tire 21	80230	80231	80232	80233	80234
Tire 22	80240	80241	80242	80243	80244
Tire 23	80250	80251	80252	80253	80254
Tire 24	80260	80261	80262	80263	80264

# Mobileye

- Mobileye parameter configuration:

Name	Parameter				
	Priority	Operand	High level	Low level	Event only
ME Sound Type	73000	73001	73002	73003	73004
ME Pedestrians in DZ	73010	73011	73012	73013	73014
ME Pedestrians in FCW	73020	73021	73022	73023	73024
ME Time Indicator	73030	73031	73032	73033	73034
ME Error Valid	73040	73041	73042	73043	73044
ME Error Code	73050	73051	73052	73053	73054
ME Zero Speed	73060	73061	73062	73063	73064
ME Headway Valid	73070	73071	73072	73073	73074
ME Headway Measurement	73080	73081	73082	73083	73084

ME LDW Off	73090	73091	73092	73093	73094
ME Left LDW On	73100	73101	73102	73103	73104
ME Right LDW On	73110	73111	73112	73113	73114
ME Maintenance	73120	73121	73122	73123	73124
ME Fail Safe	73130	73131	73132	73133	73134
ME FCW On	73140	73141	73142	73143	73144
ME TSR Enabled	73150	73151	73152	73153	73154
ME Headway Warning Repeat Enabled	73160	73161	73162	73163	73164
ME Headway Warning Level	73170	73171	73172	73173	73174
ME TSR Warning Level	73180	73181	73182	73183	73184
ME Tamper Alert	73190	73191	73192	73193	73194
ME High Beam	73200	73201	73202	73203	73204
ME Low Beam	73210	73211	73212	73213	73214
ME Wipers	73220	73221	73222	73223	73224
ME Right Signal	73230	73231	73232	73233	73234
ME Left Signal	73240	73241	73242	73243	73244
ME Brake Signal	73250	73251	73252	73253	73254
ME Wipers Available	73260	73261	73262	73263	73264
ME Low Beam Available	73270	73271	73272	73273	73274
ME High Beam Available	73280	73281	73282	73283	73284
ME Speed Available	73290	73291	73292	73293	73294
ME Speed	73300	73301	73302	73303	73304
ME TSR 01	73310	73311	73312	73313	73314
ME TSR 02	73320	73321	73322	73323	73324
ME TSR 03	73330	73331	73332	73333	73334
ME TSR 04	73340	73341	73342	73343	73344
ME TSR 05	73350	73351	73352	73353	73354
ME TSR 06	73360	73361	73362	73363	73364
ME TSR 07	73370	73371	73372	73373	73374
ME TSR VO	73380	73381	73382	73383	73384

## Reefer

- Reefer parameter configuration:

Name	Parameter				
	Priority	Operand	High level	Low level	Event only
Zone 1 Return Air Temperature 1	48270	48271	48272	48273	48274
Zone 1 Return Air Temperature 2	48310	48311	48312	48313	48314
Zone 1 Supply Air Temperature 1	48280	48281	48282	48283	48284
Zone 1 Supply Air Temperature 2	48320	48321	48322	48323	48324
Zone 1 Set Temperature	48290	48291	48292	48293	48294
Zone 2 Supply Air Temperature 1	48370	48371	48372	48373	48374
Zone 2 Return Air Temperature 1	48360	48361	48362	48363	48364
Zone 2 Set Temperature	48380	48381	48382	48383	48384
Ambient Air Temperature	48510	48511	48512	48513	48514
Compressor Coolant Temperature	48520	48521	48522	48523	48524
Compressor RPM	48540	48541	48542	48543	48544
Compressor Config	48550	48551	48552	48553	48554
Battery Voltage (V*10)	48210	48211	48212	48213	48214
Compressor Motor Work Minutes (HM)	48241	48241	48242	48243	48244
Reefer work Minutes (HMT)	48230	48231	48232	48233	48234
Electric Minutes (HME)	48220	48221	48222	48223	48224
Door Status	48560	48561	48562	48563	48564
Installation Serial	48570	48571	48572	48573	48574

<b>Trailer Registration Number</b>	<b>48580</b>	<b>48581</b>	<b>48582</b>	<b>48583</b>	<b>48584</b>
<b>Error Count</b>	<b>48530</b>	<b>48530</b>	<b>48530</b>	<b>48530</b>	<b>48530</b>
<b>Alarm 1</b>	<b>48260</b>	<b>48261</b>	<b>48262</b>	<b>48263</b>	<b>48264</b>
<b>Alarm 2</b>	<b>48350</b>	<b>48351</b>	<b>48352</b>	<b>48353</b>	<b>48354</b>
<b>Alarm 3</b>	<b>48440</b>	<b>48441</b>	<b>48442</b>	<b>48443</b>	<b>48444</b>

## Custom scenario

- Custom scenario 1

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
99440	Unit8	0	0	4	0 - Disabled 1 - None 2 - DOUT1 3 - DOUT2 4 - DOUT3	DOUT Control
99441	Unit8	2	0	2	0 - Low 1 - High 2 - Panic	Priority

239 - Ignition  
 240 - Movement  
 22 - Data Mode  
 21 - GSM Signal  
 200 - Sleep Mode  
 71 - GNSS Status  
 181 - GNSS PDOP  
 182 - GNSS HDOP  
 66 - External Voltage  
 24 - Speed  
 205 - GSM Cell ID  
 206 - GSM Area Code  
 67 - Battery Voltage  
 68 - Battery Current  
 241 - Active GSM Operator  
 199 - Trip Odometer  
 216 - Total Odometer  
 1 - Digital Input 1  
 2 - Digital Input 2  
 3 - Digital Input 3  
 4 - Digital Input 4  
 9 - Analog Input 1  
 10 - Analog Input 2  
 11 - Analog Input 3  
 245 - Analog Input 4  
 179 - Digital Output 1  
 180 - Digital Output 2  
 50 - Digital Output 3  
 51 - Digital Output 4  
 236 - Axis X  
 237 - Axis Y  
 238 - Axis Z  
 218 - IMSI  
 05 - ICCID  
 144 - SD Status  
 72 - Dallas Temperature 1  
 73 - Dallas Temperature 2  
 74 - Dallas Temperature 3  
 75 - Dallas Temperature 4  
 6 - Dallas Temperature 5  
 8 - Dallas Temperature 6  
 62 - Dallas Temperature ID 1  
 63 - Dallas Temperature ID 2  
 64 - Dallas Temperature ID 3  
 65 - Dallas Temperature ID 4  
 5 - Dallas Temperature ID 5  
 7 - Dallas Temperature ID 6  
 3 - Online Deep Sleep  
 78 - iButton  
 70 - PCB Temperature  
 76 - Fuel Counter  
 207 - RFID  
 217 - RFID COM2  
 201 - LLS 1 Fuel Level  
 203 - LLS 2 Fuel Level  
 210 - LLS 3 Fuel Level  
 212 - LLS 4 Fuel Level  
 214 - LLS 5 Fuel Level  
 201 - LLS 1 Temperature  
 204 - LLS 2 Temperature  
 211 - LLS 3 Temperature  
 213 - LLS 4 Temperature  
 215 - LLS 5 Temperature  
 224 - Ultrasonic Fuel Level 1  
 225 - Ultrasonic Fuel Level 2  
 208 - Ultrasonic Software Status 1  
 209 - Ultrasonic Software Status 2  
 178 - Network Type

99446	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #2
99449	Uint8	-	0	1	0 - Yes 1 - None	Ignore
99450	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #3
99453	Uint8	-	0	1	0 - Yes 1 - None	Ignore

• Custom scenario 2

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
99454	Uint8	0	0	4	0 - Disabled 1 - None 2 - DOUT1 3 - DOUT2 4 - DOUT3	DOUT Control
99455	Uint8	2	0	2	0 - Low 1 - High 2 - Panic	Priority

239 - Ignition  
 240 - Movement  
 22 - Data Mode  
 21 - GSM Signal  
 200 - Sleep Mode  
 71 - GNSS Status  
 181 - GNSS PDOP  
 182 - GNSS HDOP  
 66 - External Voltage  
 24 - Speed  
 205 - GSM Cell ID  
 206 - GSM Area Code  
 67 - Battery Voltage  
 68 - Battery Current  
 241 - Active GSM Operator  
 199 - Trip Odometer  
 216 - Total Odometer  
 1 - Digital Input 1  
 2 - Digital Input 2  
 3 - Digital Input 3  
 4 - Digital Input 4  
 9 - Analog Input 1  
 10 - Analog Input 2  
 11 - Analog Input 3  
 245 - Analog Input 4  
 179 - Digital Output 1  
 180 - Digital Output 2  
 50 - Digital Output 3  
 51 - Digital Output 4  
 236 - Axis X  
 237 - Axis Y  
 238 - Axis Z  
 218 - IMSI  
 05 - ICCID  
 144 - SD Status  
 72 - Dallas Temperature 1  
 73 - Dallas Temperature 2  
 74 - Dallas Temperature 3  
 75 - Dallas Temperature 4  
 6 - Dallas Temperature 5  
 8 - Dallas Temperature 6  
 62 - Dallas Temperature ID 1  
 63 - Dallas Temperature ID 2  
 64 - Dallas Temperature ID 3  
 65 - Dallas Temperature ID 4  
 5 - Dallas Temperature ID 5  
 7 - Dallas Temperature ID 6  
 3 - Online Deep Sleep  
 78 - iButton Temperature  
 70 - PCB Temperature  
 76 - Fuel Counter  
 207 - RFID  
 217 - RFID COM2  
 201 - LLS 1 Fuel Level  
 203 - LLS 2 Fuel Level  
 210 - LLS 3 Fuel Level  
 212 - LLS 4 Fuel Level  
 214 - LLS 5 Fuel Level  
 201 - LLS 1 Temperature  
 204 - LLS 2 Temperature  
 211 - LLS 3 Temperature  
 213 - LLS 4 Temperature  
 215 - LLS 5 Temperature  
 224 - Ultrasonic Fuel Level 1  
 225 - Ultrasonic Fuel Level 2  
 208 - Ultrasonic Software Status 1  
 209 - Ultrasonic Software Status 2  
 178 - Network Type

99460	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #2
99463	Uint8	-	0	1	0 - Yes 1 - None	Ignore
99464	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #3
99467	Uint8	-	0	1	0 - Yes 1 - None	Ignore

• Custom scenario 3

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
99468	Uint8	0	0	4	0 - Disabled 1 - None 2 - DOUT1 3 - DOUT2 4 - DOUT3	DOUT Control
99469	Uint8	2	0	2	0 - Low 1 - High 2 - Panic	Priority

239 - Ignition  
 240 - Movement  
 22 - Data Mode  
 21 - GSM Signal  
 200 - Sleep Mode  
 71 - GNSS Status  
 181 - GNSS PDOP  
 182 - GNSS HDOP  
 66 - External Voltage  
 24 - Speed  
 205 - GSM Cell ID  
 206 - GSM Area Code  
 67 - Battery Voltage  
 68 - Battery Current  
 241 - Active GSM Operator  
 199 - Trip Odometer  
 216 - Total Odometer  
 1 - Digital Input 1  
 2 - Digital Input 2  
 3 - Digital Input 3  
 4 - Digital Input 4  
 9 - Analog Input 1  
 10 - Analog Input 2  
 11 - Analog Input 3  
 245 - Analog Input 4  
 179 - Digital Output 1  
 180 - Digital Output 2  
 50 - Digital Output 3  
 51 - Digital Output 4  
 236 - Axis X  
 237 - Axis Y  
 238 - Axis Z  
 218 - IMSI  
 05 - ICCID  
 144 - SD Status  
 72 - Dallas Temperature 1  
 73 - Dallas Temperature 2  
 74 - Dallas Temperature 3  
 75 - Dallas Temperature 4  
 6 - Dallas Temperature 5  
 8 - Dallas Temperature 6  
 62 - Dallas Temperature ID 1  
 63 - Dallas Temperature ID 2  
 64 - Dallas Temperature ID 3  
 65 - Dallas Temperature ID 4  
 5 - Dallas Temperature ID 5  
 7 - Dallas Temperature ID 6  
 3 - Online Deep Sleep  
 78 - iButton  
 70 - PCB Temperature  
 76 - Fuel Counter  
 207 - RFID  
 217 - RFID COM2  
 201 - LLS 1 Fuel Level  
 203 - LLS 2 Fuel Level  
 210 - LLS 3 Fuel Level  
 212 - LLS 4 Fuel Level  
 214 - LLS 5 Fuel Level  
 201 - LLS 1 Temperature  
 204 - LLS 2 Temperature  
 211 - LLS 3 Temperature  
 213 - LLS 4 Temperature  
 215 - LLS 5 Temperature  
 224 - Ultrasonic Fuel Level 1  
 225 - Ultrasonic Fuel Level 2  
 208 - Ultrasonic Software Status 1  
 209 - Ultrasonic Software Status 2  
 178 - Network Type



99474	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #2
99477	Uint8	-	0	1	0 - Yes 1 - None	Ignore
99478	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #3
99481	Uint8	-	0	1	0 - Yes 1 - None	Ignore

• Custom scenario 4

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
99482	Uint8	0	0	4	0 - Disabled 1 - None 2 - DOUT1 3 - DOUT2 4 - DOUT3	DOUT Control
99483	Uint8	2	0	2	0 - Low 1 - High 2 - Panic	Priority

239 - Ignition  
 240 - Movement  
 22 - Data Mode  
 21 - GSM Signal  
 200 - Sleep Mode  
 71 - GNSS Status  
 181 - GNSS PDOP  
 182 - GNSS HDOP  
 66 - External Voltage  
 24 - Speed  
 205 - GSM Cell ID  
 206 - GSM Area Code  
 67 - Battery Voltage  
 68 - Battery Current  
 241 - Active GSM Operator  
 199 - Trip Odometer  
 216 - Total Odometer  
 1 - Digital Input 1  
 2 - Digital Input 2  
 3 - Digital Input 3  
 4 - Digital Input 4  
 9 - Analog Input 1  
 10 - Analog Input 2  
 11 - Analog Input 3  
 245 - Analog Input 4  
 179 - Digital Output 1  
 180 - Digital Output 2  
 50 - Digital Output 3  
 51 - Digital Output 4  
 236 - Axis X  
 237 - Axis Y  
 238 - Axis Z  
 218 - IMSI  
 05 - ICCID  
 144 - SD Status  
 72 - Dallas Temperature 1  
 73 - Dallas Temperature 2  
 74 - Dallas Temperature 3  
 75 - Dallas Temperature 4  
 6 - Dallas Temperature 5  
 8 - Dallas Temperature 6  
 62 - Dallas Temperature ID 1  
 63 - Dallas Temperature ID 2  
 64 - Dallas Temperature ID 3  
 65 - Dallas Temperature ID 4  
 5 - Dallas Temperature ID 5  
 7 - Dallas Temperature ID 6  
 3 - Online Deep Sleep  
 78 - iButton  
 70 - PCB Temperature  
 76 - Fuel Counter  
 207 - RFID  
 217 - RFID COM2  
 201 - LLS 1 Fuel Level  
 203 - LLS 2 Fuel Level  
 210 - LLS 3 Fuel Level  
 212 - LLS 4 Fuel Level  
 214 - LLS 5 Fuel Level  
 201 - LLS 1 Temperature  
 204 - LLS 2 Temperature  
 211 - LLS 3 Temperature  
 213 - LLS 4 Temperature  
 215 - LLS 5 Temperature  
 224 - Ultrasonic Fuel Level 1  
 225 - Ultrasonic Fuel Level 2  
 208 - Ultrasonic Software Status 1  
 209 - Ultrasonic Software Status 2  
 178 - Network Type

99488	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #2
99491	Uint8	-	0	1	0 - Yes 1 - None	Ignore
99492	Uint8	-	-	-	The selected source parameter ID corresponds to ALV ID. The same options are possible as for source #1	Source #3
99495	Uint8	-	0	1	0 - Yes 1 - None	Ignore

## FMS ECO driving

- FMS ECO driving parameter configuration:

Parameter ID	Parameter Type	Default value	Value range		Value	Parameter name
			Min	Max		
125000	Uint8	0	0	3	0 - Disabled 1 - Low Priority 2 - High Priority 3 - Panic Priority	FMS ED Priority
125001	Uint32	0	0	86400	Amount	Periodic trigger timer in seconds
125010	Uint8	0	0	3	0x00 - None 0x01 - Distance 0x02 - Fuel used 0x04 - Time	Coasting - Units (type of IO)
125011	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Coasting - Extra Triggers
125012	Uint16	1	0	65000	Amount	Coasting - Fuel rate (L/h)
125013	Uint8	1	0	100	Amount	Coasting - Engine Torque (%)
125014	Uint8	10	0	255	Amount	Coasting - Speed (km/h)
125020	Uint8	0	0	3	0x00 - None 0x01 - Distance 0x02 - Fuel used 0x04 - Time	EcoRoll - Units (type of IO)
125021	Uint8	0	0	2	0 - Disabled 1 - Trip 2 - Distance	EcoRoll - Extra Triggers
125022	Uint16	1	0	65000	Amount	EcoRoll - Fuel rate (L/h)
125023	Uint8	1	0	100	Amount	EcoRoll - Engine Torque (%)
125024	Uint8	10	0	255	Amount	EcoRoll - Speed (km/h)
125025	Uint8	0	0	1	0 - Disable 1 - Enable	EcoRoll - Cruise Control State
125030	Uint8	0	0	4	0x00 - None 0x01 - Distance 0x02 - Fuel used 0x04 - Time 0x08 - Count	Braking - Units (type of IO)
125031	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Braking - Extra Triggers
125040	Uint8	0	0	3	0x00 - Disabled 0x01 - Distance 0x02 - Fuel used 0x04 - Time	Retarder - Units
125041	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Retarder - Extra Triggers

<b>125050</b>	Uint8	0	0	3	0x00 - Disabled 0x01 - Distance 0x02 - Fuel used 0x04 - Time	Cruise - Units
<b>125051</b>	Uint8	0	0	2	0 - Disabled 1 - Trip 2 - Periodic	Cruise - Extra Triggers
<b>125060</b>	Uint8	0	0	3	0x00 - Disabled 0x01 - Distance 0x02 - Fuel 0x04 - Time	Torque - Units
<b>125061</b>	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Torque - Extra Triggers
<b>125062</b>	Uint8	1	0	100	Amount	Torque - Accelerator pedal position (%)
<b>125063</b>	Uint8	1	0	100	Amount	Torque - Engine Torque (%) (non-configurable via configurator)
<b>125070</b>	Uint8	0	0	3	0x00 - None 0x01 - Distance 0x02 - Fuel 0x04 - Time	PTO - Units
<b>125071</b>	Uint8	0	0	2	0 - Disabled 1 - Trip 2 - Distance	PTO - Extra Triggers
<b>125080</b>	Uint8	0	0	1	0x00 - Disabled 0x01 - Fuel	Fuel While Driving - Units
<b>125081</b>	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Fuel While Driving - Extra Triggers
<b>125090</b>	Uint8	0	0	1	0x00 - Disabled 0x01 - Fuel used	Fuel While Idle - Units
<b>125091</b>	Uint8	0	0	2	0 - Disabled 1 - Trip 2 - Distance	Fuel While Idle - Extra Triggers
<b>125100</b>	Unit8	0	0	1	0x00 - Disabled 0x02 - Fuel	Fuel Consumption Under Load - Units
<b>125101</b>	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Fuel Consumption Under Load - Extra Triggers
<b>125102</b>	Unit8	1	0	100	Amount	Fuel Consumption Under Load - Engine Load (%)
<b>125110</b>	Uint8	0	0	3	0x00 - Disabled 0x01 - Distance 0x02 - Fuel used 0x04 - Time	Total - Units
<b>125111</b>	Uint8	0	0	2	0 - None 1 - Trip 2 - Distance	Total - Extra Triggers
<b>125250</b>	Uint8	0	0	1	0x00 - Disabled 0x08 - Count	Number of Stops - Units
<b>125251</b>	Uint8	0	0	2	0 - Disabled 1 - Trip 2 - Distance	Number of Stops - Extra Triggers
<b>125252</b>	Uint8	0	0	255	Amount	Number of stops - Brake time (s)
<b>125253</b>	Uint8	0	0	255	Amount	Number of stops - Stop speed (km/h)

<b>125500</b>	UInt8	0	0	3	0x00 - Disabled 0x01 - Distance 0x02 - Fuel used 0x04 - Time	Speed Range - Units
<b>125501</b>	UInt8	0	0	2	0 - Disabled 1 - Trip 2 - Distance	Speed Range - Extra Triggers
<b>125502</b>	String	-	-	-	0...10 ranges 0...60 characters 0...65534 for each value	Speed range - Ranges list km/h comma-separated values, each number represents a start of the next speed range.
<b>125511</b>	UInt8	0	0	2	0 - None 1 - Trip 2 - Periodic	RPMRange - Extra Triggers
<b>125512</b>	String	-	-	-	0...10 ranges 0...60 characters 0...65534 for each value	RPMRange - Ranges list RPM comma-separated values, each number represents a start of the next RPM range.
<b>125521</b>	UInt8	0	0	2	0 - None 1 - Trip 2 - Periodic	TorqueRange- Extra Triggers
<b>125522</b>	String	-	-	-	0...10 ranges 0...60 characters 0...65534 for each value	TorqueRange- Ranges list % comma-separated values, each number represents a start of the next Torque range.
<b>125531</b>	UInt8	0	0	2	0 - None 1 - Trip 2 - Periodic	BrakingRange- Extra Triggers
<b>125532</b>	String	-	-	-	0...10 ranges 0...60 characters 0...65534 for each value	BrakingRange- Ranges list % comma-separated values, each number represents a start of the next braking range.
<b>125541</b>	UInt8	0	0	2	0 - None 1 - Trip 2 - Periodic	FuelRateRange- Extra Triggers
<b>125542</b>	String	-	-	-	0...10 ranges 0...60 characters 0...65534 for each value	FuelRateRange- Ranges list L/h comma-separated values, each number represents a start of the next fuel rate range.