

# Pay as You Drive

□

## Contents

- [1 Introduction](#)
- [2 Solution description](#)
- [3 What you need for a solution?](#)
- [4 Installation](#)
- [5 Configuration](#)
  - [5.1 1. Prerequisites](#)
  - [5.2 2. Configuring scenario](#)
  - [5.3 3. FMBT Mobile application](#)
  - [5.4 4. Teltonika Data Sending Parameters](#)
- [6 Parsing information](#)
  - [6.1 1. Prerequisites](#)
    - [6.1.1 1.1. Open TCP/UDP port](#)
    - [6.1.2 1.2. Read Java parser first start guide](#)
  - [6.2 2. Parsing example](#)
- [7 Demonstration on Platform](#)
- [8 FAQ](#)

## Introduction

With the market penetration of telematics companies in the B2C segment being quite limited, this use case is a great platform for Telematics Service Providers to reach new target groups such as the owners of private vehicles. Pay As You Drive is a fairly well-known business model, which provides better risk management tools for insurance companies and better service quality and commercial conditions to the drivers willing to install GPS trackers and comply to road rules.

## Solution description

This solution allows vehicles to be used in Pay As You Drive applications by retrieving the **total driven distance**, also known as odometer data directly from vehicle's CAN-BUS. Therefore, it is no longer necessary to obtain this value from GPS calculations. The accuracy of GPS calculations is suitable in most of the applications, but it still has some limitations - driving in tunnels and other locations where GPS signal is blocked might affect the overall value of a driven distance. Also, to calculate the total driven distance via GPS, a driver needs to enter the first value manually and synchronize it later. It might become a major administrative task. One of the most important features needed in Pay As You Drive applications is the ability to analyze a driver's performance - harsh acceleration, harsh braking and harsh cornering. This can be analyzed with [Overspeeding](#) and [Green Driving](#) scenarios. [Crash detection](#) is another helpful scenario for insurance companies. It is a practical solution that collects and analyzes data right before the crash happened and during the crash. Even more, FMB003 has a unique feature providing a driver with both **Real Fuel** and **Real Odometer** data. It means you can read an actual odometer data from your vehicle dashboard now

and get the correct data online.

## What you need for a solution?

- **FMB003** to read the real odometer data from the vehicle dashboard via the vehicle's OBD port.

**Other devices that work with this solution:** **FMP100**/ *It has the advantage of simple installation.*

- **Teltonika Configurator** to set up FM device correctly for the solution.
- **FOTA WEB** to remotely send the configuration to the device for cloud-based VIN decoding combined with OEM data requests database.
- **SIM card** to access FOTA WEB and send data to the server by accessing the GSM network.

## Installation

FMB003, our new generation ultra-small, plug and play OBDII tracker with the benefits of very fast and easy installation. Even end-users can install the device themselves. The new housing of FMB003 device is remarkably small which is advantageous in vehicles with limited space for GPS tracker installation.

Installing the OBDII device to the vehicle:

- Find OBDII connector in your vehicle (Figure 1). if you need more accurate location, please visit [Location of OBD plug](#).
- Before connecting the device to the OBDII socket, make sure that  $\geq 3A$  fuse is present on OBD connector power supply.



Figure 1. Most common OMBDII connector locations

## Configuration

### 1. Prerequisites

- The vehicle must be supported by the FMB003 device. *How to learn?* Please contact your Teltonika Sales Manager with the make, model and model year of your vehicle.
- Turn the ignition ON.
- FMB003 must get VIN from the vehicle ([AVL ID: 256](#)). If not? Check the [FAQ](#) section.
- FMB003 must connect to [FOTA WEB](#) to get the OBD configuration for the vehicle. Please make sure [the device configuration settings for FOTA WEB](#) are correct.
- FMB003 must get OBD OEM Total Mileage from the vehicle ([AVL ID: 389](#)). If not? Check the [FAQ](#) section.

### 2. Configuring scenario

- Configure the APN in **GPRS settings**.



- 2001 - APN
- 2002 - APN username (No APN username > leave the field blank)
- 2003 - APN password (No APN password > leave the field blank)

- Configure the server in **GPRS settings**.



- 2004 - Domain
- 2005 - Port
- 2006 - Data sending protocol (0 - TCP, 1 - UDP)

- Enable Codec 8 Extended in **System settings**.



- Parameter ID: 113 - Codec 8 Extended (0 - Codec 8, 1 - Codec 8 Extended)

AVL parameters greater than 255 (HEX 0xFF) require "Codec 8 extended" to be sent to the server.

- Enable OBD Feature in **OBD II settings**.



- Parameter ID: 40000 - OBD Feature (0 - Disable, 1 - Enable)

- Select Auto for VIN Source in **OBD II settings**.



- Parameter ID: 40005 - OBD Feature (0 - Auto, 1 - Manual)

- Enable (i.e. set a Priority for) OEM Total Mileage in **OBD II settings**.



- **Parameter ID: 40430** - OBD Feature (Priorities: 0 - None, 1 - Low, 2 - High, 3 - Panic)

**Quickstart:** From default configuration to Pay As You Drive solution in one SMS:

<SMS Login> <SMS Password> **setparam 113:1;40000:1;40005:0;40430:1**

Please review other features to improve this use case:

- [Overspeeding](#)
- [Eco/Green Driving](#)
- [Crash detection](#) for the corresponding configuration settings.

**Configuration changes also can be made via [FOTA WEB](#) or to some extent via *FMBT Mobile application*.**

### **3. FMBT Mobile application**

You can view the current status of the parameters *including AVL ID: 389 - OBD OEM Total Mileage*.

The application can also configure:



- APN (APN, APN username, APN password)
- Server (domain, port, data sending protocol)

## 4. Teltonika Data Sending Parameters

Teltonika Data Sending Parameter for OBD OEM Total Mileage is AVL ID 389 (Unit: km). You can get the current value from the vehicle with **Ignition ON**:

<SMS Login> <SMS Password> [readio 389](#)

## Parsing information

### 1. Prerequisites

1.1. Open [TCP/UDP port](#)

1.2. Read Java parser [first start guide](#)

### 2. Parsing example

#### Unparsed received data in hexadecimal stream

```
00000000000000548E010000017CA68CAE50010F0E4D4D209A8D40005C00000B0000000000B000500EF0100F0010015  
0300C8000025000004004238DD0043102F0044002800240340000201850003DC0C0186000000C8000000000100003C34
```

AVL Data Packet Part	HEX Code Part
Zero Bytes	00 00 00 00
Data Field Length	00 00 00 54
Codec ID	8E (Codec 8 Extended)
Number of Data 1 (Number of Total Records)	01
Timestamp	00 00 01 7C A6 8C AE 50
Priority	01
Longitude	0F 0E 4D 4D
Latitude	20 9A 8D 40
Altitude	00 5C
Angle	00 00
Satellites	0B
Speed	00 00
Event IO ID	00 00
N of Total ID	00 0B
N1 of One Byte IO	00 05
1'st IO ID	00 EF (AVL ID: 239, Name: Ignition)
1'st IO Value	01
2'nd IO ID	00 F0 (AVL ID: 240, Name: Movement)
2'nd IO Value	01
3'rd IO ID	00 15 (AVL ID: 21, Name: GSM Signal)
3'rd IO Value	03
4'th IO ID	00 C8 (AVL ID: 200, Name: Sleep Mode)
4'th IO Value	00
5'th IO ID	00 25 (AVL ID: 37, Name: Vehicle Speed)
5'th IO Value	00
N2 of Two Bytes IO	00 04

1'st IO ID	00 42 (AVL ID: 66, Name: External Voltage)
1'st IO Value	38 DD
2'nd IO ID	00 43 (AVL ID: 67, Name: Battery Voltage)
2'nd IO Value	10 2F
3'rd IO ID	00 44 (AVL ID: 68, Name: Battery Current)
3'rd IO Value	00 28
4'th IO ID	00 24 (AVL ID: 36, Name: Engine RPM)
4'th IO Value	03 40
N4 of Two Bytes IO	00 02
1'st IO ID	<b>01 85</b> (AVL ID: 389, Name: OBD OEM Total Mileage)
1'st IO Value	<b>00 03 DC 0C</b>
2'nd IO ID	01 86 (AVL ID: 134, Name: Trip Distance)
2'nd IO Value	00 00 00 C8
N8 of Two Bytes IO	00 00
NX of X Byte IO	00 00
Number of Data 2 (Number of Total Records)	01
CRC-16	00 00 3C 34

Server response: 00000001

Please see [Codec 8 Extended](#) for more information.

## Demonstration on Platform

For [TAVL](#) Users:

- \* **TAVL** > Select Client
- \* **Objects** > Press "Filter" > Find Object
- \* **Track** > Choose dates > Press "Advanced" > Press "Show"



# FAQ

Question	How to check?	What to do next?
How can I find out if my FMB003 device is correctly configured to receive OBDII parameters (with OBD OEM Total Mileage) from the vehicle?	Check the section <a href="#">Configuring scenario</a> .	<ul style="list-style-type: none"> <li>Make any necessary corrections in the configuration.</li> </ul>
How can I find out if my FMB003 device can receive data from the vehicle?	Send the following SMS/GPRS command to the device with <b>Ignition ON</b> : <SMS Login> <SMS Password> <b>obdinfo</b>	<ul style="list-style-type: none"> <li>The device response of the p1-4 protocols consisting of data indicates that data is received. <i>Prot:6,VIN:WVWZZZAUZFW125650, TM:15, CNT:12, ST:DATA REQUESTING, P1:0xBFBFB993, P2:0x8007E019, P3:0xFED00000, P4:0x0, MIL:0, DTC:0, ID3, Hdr:7E8, Phy:0</i></li> <li>The device response of the p1-4 protocols consisting of zeros indicates that no data is received. <i>Prot:0,VIN:N/A, TM:10, CNT:0, ST:OFF, P1:0x0, P2:0x0, P3:0x0, P4:0x0, MIL:0, DTC:0, ID0, Hdr:0, Phy:0</i></li> <li>The device response with VIN:&lt;VIN&gt; indicates that VIN is received. <i>Prot:6,VIN:WVWZZZAUZFW125650, TM:15, CNT:12, ST:DATA REQUESTING, P1:0xBFBFB993, P2:0x8007E019, P3:0xFED00000, P4:0x0, MIL:0, DTC:0, ID3, Hdr:7E8, Phy:0</i></li> <li>The device response with VIN:N/A indicates that no VIN is received. <i>Prot:0,VIN:N/A, TM:10, CNT:0, ST:OFF, P1:0x0, P2:0x0, P3:0x0, P4:0x0, MIL:0, DTC:0, ID0, Hdr:0, Phy:0</i></li> <li>Configure VIN manually if vehicle does not return VIN.</li> </ul>
How can I find out if <b>VIN</b> (Vehicle Identification Number) has been received from the vehicle by my FMB003 device so that the correct configuration can be obtained from FOTA WEB?	Send the following SMS/GPRS command to the device with <b>Ignition ON</b> : <SMS Login> <SMS Password> <b>obdinfo</b>	<ul style="list-style-type: none"> <li>The device response with VIN:&lt;VIN&gt; indicates that VIN is received. <i>Prot:6,VIN:WVWZZZAUZFW125650, TM:15, CNT:12, ST:DATA REQUESTING, P1:0xBFBFB993, P2:0x8007E019, P3:0xFED00000, P4:0x0, MIL:0, DTC:0, ID3, Hdr:7E8, Phy:0</i></li> <li>The device response with VIN:N/A indicates that no VIN is received. <i>Prot:0,VIN:N/A, TM:10, CNT:0, ST:OFF, P1:0x0, P2:0x0, P3:0x0, P4:0x0, MIL:0, DTC:0, ID0, Hdr:0, Phy:0</i></li> <li>Configure VIN manually if vehicle does not return VIN.</li> </ul>
How can I find out if <b>OBD OEM Total Mileage</b> can be received from the vehicle?	<p><b>Turn the ignition ON.</b></p> <ul style="list-style-type: none"> <li><b>Configurator:</b> Check if the device is configured correctly. Check the section <a href="#">Configuring scenario</a>.</li> <li><b>Server:</b> Check if OBD OEM Total Mileage (AVL ID: 389) is coming to your server.</li> <li><b>SMS/GPRS command:</b> Check with <b>readio</b> SMS/GPRS command if OBD OEM Total Mileage can be received from the vehicle. <i>SMS command structure: &lt;SMS Login&gt; &lt;SMS Password&gt; readio 389</i></li> </ul>	<p>If the device is configured correctly and OBD OEM Total Mileage cannot be received from the vehicle:</p> <ul style="list-style-type: none"> <li>Contact your Teltonika Sales Manager with the make, model and model year of your vehicle.</li> <li>You can also contact Teltonika support via HelpDesk with the make, model and model year of your vehicle. Please also share device response to <b>obdinfo</b> SMS/GPRS command with ignition ON.</li> </ul>