https://wiki.teltonika-gps.com/view/Sending_Codec12_commands_using_Hercules

Sending Codec12 commands using Hercules

General Technical Questions > Sending Codec12 commands using Hercules □

Contents

- <u>1 Description</u>
- 2 Setting up for connection with Hercules Software
- <u>3 Hercules Software</u>
- <u>4 How to create a HEX command</u>

Description

Hercules SETUP utility is useful serial port terminal (RS-485 or RS-232 terminal), UDP/IP terminal and TCP/IP Client Server terminal.It was created for HW group internal use only, but today it's includes many functions in one utility and it's Freeware! With our original devices (Serial/Ethernet Converter, RS-232/Ethernet Buffer or I/O Controller) it can be used for the UDP Config.

Setting up for connection with Hercules Software

×

1. Press GPRS tab

• *GPRS Context* field requires you to enter your SIM providers' APN settings. Make sure to fill this in based on the SIM provider you are using with your Teltonika device. More information about *GPRS* panel and it's parameters for each device can be found here: <u>TST100 | TFT100 | GH5200 | TMT250</u>

Server Settings —	
Domain	
Port	0 🗢
Protocol	
тср	UDP
Encryption	
None	TLS/DTLS

2. In **GPRS->Server settings -> Domain** field, **External IP** of your **PC** must be entered. There are several ways to find out your machine's external IP address:

• Visit the link provided to find out external IP address via website: pingEU

• If you do not want to use a website you can find your IP through Windows Command Prompt.

• **Open Start** Click the Windows logo in the bottom-left corner of the screen, or press the **Win** key. You can search for Command Prompt on all supported versions of Windows.

• In the **Command Prompt** enter the following: nslookup myip.opendns.com

resolver1.opendns.com

Example window:

×

Copy Non-Authoritative answer Address

• Paste Non-Authoritative answer Address in *Teltonika Configurator* Server settings -> Domain field

• In **Port** field, enter an open port.

If it is unknown if the port is open, to check if the port is open click <u>pingEU</u> and enter **external IP** address and **port** and click **Go** button.

×

Example window:

×

• Save settings to the device

Hercules Software

1. Click TCP Server

2. Enter **Port** and click Listen

- When device connects to Hercules, device *IMEI* is sent and is displayed in *Received data* window
- 4. Tick HEX box

6. Click Send button

Note: To make device connect to Hercules faster, click any button, that has an event configured. In the example below, a button was pressed to send an SMS message.

Note: Hercules SETUP utility by HW-group.com		- 0 X
UDP Setup Serial TCP Client TCP Server UDP	Test Mode About	
0 devices were found:	Required parameters Module name:	End devices
	Module IP	Sectore default values
	Port	Device type:
	Module IP mask	FW version: Unknown
	Gateway	IP Filter
	Settings	IP Filter Address Range
	TCP TEA authorization Enable NVT Enable TCP setup	I IP Filter MASK
TCP Setup configuration	☐ Enable DHCP	
<u>Connect</u> with TCP Client	Your PC network settings	HW group
B Open in the WEB Browser	GW: 192.168.1.254	Hercules SETUP utility
		Version 3.2.8

How to create a HEX command

- Data size is calculated by the sum of bytes from **Codec ID** to **Command Quantity 2**. In this case it is 15 (**DEC**) or F (**HEX**)bytes.
- CRC-16 is calculated also by the sum of bytes from Codec ID to Command Quantity 2.
- To find out CRC-16 go to <u>CRC-16 calculator</u> page
- In HEX field enter the following 0C01050000007676574696E666F01 getinfo All bytes in HEX from Codec ID to Command Quantity 2
- Find CRC-16-IBM table
- Reversed 0xA001 Little Endian (DCBA) shows CRC-16, which is 43 12

CRC-16-IBM

(Bisync, Modbus, USB, ANSI X3.28, many others; also known as CRC-16 and CRC-16-ANSI)

Generator Type	Big Endian (ABCD)	Little Endian (DCBA)
Normal 0x8005	FE 8D	8D FE
Reversed 0xA001	12 43	43 12
Reversed Reciprocal 0xC002	64 22	22 64

Hexadecimal stream of GPRS command and answer in these examples are given in hexadecimal form. The different fields of messages are separate into different table columns for better readability and some of them are converted to ASCII values for better understanding.

Parsed:

Server Command		
Server Command Part	HEX Code Part	
Zero Bytes	00 00 00 00	
Data Size	00 00 00 0F	
Codec ID	0C	
Command Quantity 1	01	
Command Type	05	
Command Size	00 00 00 07	
Command	67 65 74 69 6E 66 6F	
Command Quantity 2	01	
CRC-16	00 00 43 12	

Note: that Server Command converted from HEX to ASCII means getinfo

Example:

When creating getstatus Codec 12 command:

- Codec 12 in HEX is 0C 1 byte
- Command Quantity 1 is 01 1 byte
- Command Type is 05 1 byte
- Command Size is 00 00 00 09, because getstatus converted in HEX is 9 bytes. 4 bytes
- Command getstatus converted to HEX format is 67 65 74 73 74 61 74 75 73 9 bytes
- Command Quantity 2 is 01 1 byte
- CRC-16 converted from 0C0105000000967657473746174757301 is 00 00 8C D7 is 4 bytes

Server Command		
Server Command Part	HEX Code Part	
Zero Bytes	00 00 00 00	
Data Size	00 00 00 11	
Codec ID	0C	
Command Quantity 1	01	
Command Type	05	
Command Size	00 00 00 09	
Command	67 65 74 73 74 61 74 75 73	
Command Quantity 2	01	
CRC-16	00 00 8C D7	