

FMB lvcancheck

Possible responses:

- From [ALL-CAN300](#):
 - `CANX:0xYY[,]`, where:
 - **X** - CAN number
 - **YY** - the status of CAN line:
 - **00** - CAN not connected, connection not required
 - **01** - CAN connected, but currently module is not receiving data
 - **02** - CAN not connected, requires connection
 - **03** - CAN connected
 - Examples of responses:
 - CAN1:0x03,CAN2:0x02,CAN3:0x03
 - CAN line flags are empty!
 - LVCAN not detected
- From [CAN-CONTROL](#), [FMB140](#):
 - `CANX:0xYY[,]`, where:
 - **X** - CAN number
 - **YY** - the status of CAN line:
 - **00** - CAN connected, but currently module not received data
 - **01** - CAN connected, the module is currently receiving data
 - **02** - CAN not connected, requires connection
 - **03** - CAN not connected, connection not required
 - Examples of responses:
 - CAN1:0x03,CAN2:0x02,CAN3:0x03
 - CAN line flags are empty!
 - LVCAN not detected
- From [FMB150](#), [FMC150](#), [FMM150](#):
 - `CANX:0xYY[,]`, where:
 - **X** - CAN number
 - **YY** - the status of CAN line:
 - **00** - CAN connected, but currently module not received data
 - **01** - CAN connected, the module is currently receiving data
 - **02** - CAN not connected, requires connection
 - **03** - CAN not connected, connection not required
 - Examples of responses:
 - CAN1:0x03,CAN2:0x02,CAN3:0x03
 - CAN line flags are empty!