

TCT Search

[Main Page](#) > [Software & Applications](#) > [Telematics Configuration Tool \(TCT\)](#) > **TCT Search**



Contents

- [1 Searching by Parameter Name](#)
- [2 Searching by Parameter ID](#)
- [3 Recents](#)

The **Telematics Configuration Tool (TCT)** brings a new way of finding settings - by introducing a **Search** option. This new feature allows users to quickly find the necessary settings and parameters without the need of going through various tabs. We believe this will not only help the more experienced users to setup the device faster but will also greatly assist the new users, who are just starting their journey with Teltonika Telematics devices.

Searching by Parameter Name

1. At the top of the TCT window, click on the **Search** field, this will open up a new window.
2. In the newly opened window, type anything that you are looking for. In the provided example we are searching for 'APN' settings. After typing the word 'APN' the search window displays a parameter list which contains the word 'APN'.
3. Choose the parameter you were looking for and click on it - **TCT** will direct you straight to the requested parameter configuration window.

Note: Search by Parameter Name requires at least three characters.


The screenshot shows the TCT Search interface. At the top, there is a search bar with the text "Search" and a magnifying glass icon. To the right of the search bar are icons for notifications (6), a bell, settings, and a globe. Below the search bar is a notification box that says "Device is not connected" and "You can proceed to configure device offline on other pages". The main content area is divided into three panels: "Device information", "GNSS information", and "Cellular information". Each panel has a title, a description, and a "Device is not connected" message with a satellite icon. The "Device information" panel says "Device needs to be connected to see this information". The "GNSS information" panel says "Check current status of GNSS module to make sure device mounted in correct place. Following information contains device location with all GNSS data and satellites in use." and "Device needs to be connected to see this information". The "Cellular information" panel says "Check the current status of the cellular modem and other cellular-related information. The following information contains cellular status, network traffic, sockets, records, and SMS." and "Device needs to be connected to see this information". At the bottom right, there is a "Save to file" button.

Searching by Parameter ID

In addition to searching the wanted parameters by keyword, it is possible to search them by parameter ID as well. The full parameter ID list can be found [here](#).

1. At the top of the TCT window, click on the "Search" field, this will open up a new window.
2. In the newly opened window, type any parameter ID that you are looking for. In the provided example we are searching for parameter '2004' which corresponds to 'Main Server Domain'. After typing '2004' the search window displays a parameter with the associated ID value.
3. Choose the parameter you were looking for and click on it - **TCT** will direct you straight to the requested parameter configuration window.

Note: Important to mention, that you must search by the **exact parameter ID**, otherwise, the related parameter won't be returned.



The screenshot displays the TCT interface with a search bar at the top. Below the search bar, a notification states "Device is not connected" and "You can proceed to configure device offline on other pages". The main content area is divided into three sections: "Device information", "GNSS information", and "Cellular information". Each section contains a satellite icon and a message indicating that the device is not connected and needs to be connected to view the information. A "Save to file" button is located in the bottom right corner.

Search

Device is not connected
You can proceed to configure device offline on other pages

Device information

Device is not connected
Device needs to be connected to see this information

GNSS information

Check current status of GNSS module to make sure device mounted in correct place. Following information contains device location with all GNSS data and satellites in use.

Device is not connected
Device needs to be connected to see this information

Cellular information

Check the current status of the cellular modem and other cellular-related information. The following information contains cellular status, network traffic, sockets, records, and SMS.

Save to file

Recents

Device is not connected
You can proceed to configure device offline on other pages

Device information



Device is not connected

Device needs to be connected to see this information

GNSS information

Check current status of GNSS module to make sure device mounted in correct place. Following information contains device location with all GNSS data and satellites in use.



Device is not connected

Device needs to be connected to see this information

Cellular information

Check the current status of the cellular modem and other cellular-related information. The following information contains cellular status, network traffic, sockets, records, and SMS.



Save to file

Another feature that we added is called **Recents**. **TCT** remembers the last parameters you searched and displays them in a list for a session (device configuration session).