

TFT100 Beacon List

[Main Page](#) > [E-Mobility Trackers](#) > [TFT100](#) > [TFT100 Configuration](#) > **TFT100 Beacon List**



Contents

- [1 Beacon Settings](#)
 - [1.1 Beacon Detection](#)
 - [1.2 Beacon Record](#)
- [2 Beacon List](#)

Beacon Settings



Beacon Detection

- Disabled - Functionality disabled.
- All - Any visible beacon is detected (Max. 100).
- Configured - Only data received from listed beacons in **Beacon List** is sent to server.

Beacon Record

- Eventual - Record is sent after the scanning procedure is completed. This parameter depends on **Update Frequency** that is configured in [Bluetooth 4.0](#)
- Periodic - Record will be saved based on configured time period.
 - Record Period on Move - Timer for record generation when the device is moving.
 - Record Period on Stop - Timer for record generation when the device is staying at the place.

Beacon List



List of authorized beacons. **Eddystone** and **iBeacon** protocols are supported. Beacon IDs can be entered the following way:

- Namespace:InstanceID
- UUID:Major:Minor

Any of the ID parts can be omitted. Ex. Namespace:, UUID:., UUID:Minor, etc.

Note! *UUID, Namespace or Major/Minor for iBeacon and Namespace for Eddystone.*

If **Beacon Detection** selected as Configured, then beacons will be detected and their data transmitted to the server only if their IDs are included in **Beacon List**.

iBeacon and **Eddystone** data frame has the following structure:

- **iBeacon** - 20 Bytes (UUID(16 Bytes):major(2 Bytes):minor(2 Bytes))
- **Eddystone** - 16 Bytes (Namespace(10 Bytes):Instance ID(6 Bytes))