

# Template:FMM640 Jamming

## Jamming

| Jamming                                   |  |
|---|--|
| Output Control                            |  |
| <input checked="" type="radio"/> Disabled | <input type="radio"/> No Dout control      |
| <input type="checkbox"/> DOUT 1           | <input type="checkbox"/> DOUT 2            |
| <input type="checkbox"/> DOUT 3           |  |
| Sensitivity                               |  |
| <input checked="" type="radio"/> Low      | <input type="radio"/> Normal               |
| <input type="checkbox"/> High             |  |
| Eventual Records                          |  |
| <input type="checkbox"/> Disable          | <input checked="" type="checkbox"/> Enable |
| DOUT ON Duration (ms)                     | <input type="text" value="0"/>             |
| DOUT OFF Duration (ms)                    | <input type="text" value="0"/>             |
| Time Until Jamming Event Detection (s)    | <input type="text" value="60"/>            |

When jamming is detected the scenario is activated, an event record is generated and digital output status is changed to 1 when configured once *Jamming* timeout runs out. If jamming ends during timeout countdown no event will be generated and output will not be controlled.

*Eventual Records* parameter can be configured: when it is disabled scenario status value will appear in each AVL record, otherwise it will be appended only to eventual records.