https://wiki.teltonika-gps.com/view/FMB640_J1708

FMB640 J1708

 $\frac{\text{Main Page}}{\square} > \frac{\text{EOL Products}}{PMB640} > \frac{\text{FMB640 Manual}}{PMB640} > \frac{\text{FMB640 J1708}}{PMB640}$

Contents

- <u>1 Description</u>
- 2 Software Configuration of FMB640 with J1708
- <u>3 Connection with Vehicle port</u>

Description

SAE J1708 is a standard used for serial communications between ECUs on heavy-duty. The hardware utilized is RS-485 transceivers wired for open collector operation through the use of a pullup and pulldown of the separate data lines.

With FMB640, J1708 functionality is used to read vehicle's Fuel Level and Fuel consumption.

Because J1708 is not a CAN-BUS protocol, <u>FMB640</u> CAN1 and CAN2 lines cannot be used to read J1708 information. <u>FMB640</u> has a special J1708 Port, which utilizes an RJ9 4P4C connector.

×

Software Configuration of FMB640 with J1708

Firmware version: 00.00.11 or above **Configurator version:** 0.13.35.29297 or above

J1708 configuration is done in the $\underline{FMS IO}$ Tab.

FMS Fuel Settings					
Fuel level source		Fuel consumption source		High resolution engine total fuel used	
CAN	J1708	CAN	J1708	Liters	Milliliters

When J1708 is enabled as a Fuel Level source, Fuel-related data will be taken from the J1708 line, FMS Fuel data will be ignored.

Connection with Vehicle port

 $J1708\ connector$ is not supported by all vehicles. Only VOLVO, RENAULT, and American truck manufacturers implement the J1708\ connector.

Trucks utilize *Deutsch 6-PIN or Deutsch 9-PIN connector*, which are used to connect FMB640 to J1708.

××

NOTE: Most of the Volvo trucks need an J1708 connection to be able to receive fuel level data