

# FMB641 J1708

[Main Page](#) > [EOL Products](#) > [FMB641](#) > [FMB641 Manual](#) > **FMB641 J1708**



## Contents

- [1 Description](#)
- [2 Software Configuration of FMB641 with J1708](#)
- [3 Connection with Vehicle port](#)

## Description

SAE J1708 is a standard used for serial communications between ECUs on heavy-duty. The hardware utilized is RS-485 transceivers wired for open collector operation through the use of a pullup and pulldown of the separate data lines.

With [FMB641](#), J1708 functionality is used to read vehicle's Fuel Level and Fuel consumption.

Because J1708 is not a CAN-BUS protocol, [FMB641](#) CAN1 and CAN2 lines cannot be used to read J1708 information. [FMB641](#) has a special J1708 Port, which utilizes an RJ9 4P4C connector.



## Software Configuration of FMB641 with J1708

**Firmware version:** 00.00.11 or above

**Configurator version:** 0.13.35.29297 or above

J1708 configuration is done in the [FMS IO](#) Tab.

FMS Fuel Settings					
Fuel level source	Fuel consumption source		High resolution engine total fuel used		
CAN	J1708	CAN	J1708	Liters	Milliliters


When J1708 is enabled as a Fuel Level source, Fuel-related data will be taken from the J1708 line, FMS Fuel data will be ignored.

## Connection with Vehicle port

J1708 connector is not supported by all vehicles. Only VOLVO, RENAULT, and American truck manufacturers implement the J1708 connector.

Trucks utilize *Deutsch 6-PIN or Deutsch 9-PIN connector*, which are used to connect FMB641 to J1708.



 **NOTE: Most of the Volvo trucks need an J1708 connection to be able to receive fuel level data**